

CHASSIS SECTION

This service manual has been prepared to provide SUBARU service personnel with the necessary information and data for the correct maintenance and repair of SUBARU vehicles.

This manual includes the procedures for maintenance, disassembling, reassembling, inspection and adjustment of components and diagnostics for guidance of experienced mechanics.

Please peruse and utilize this manual fully to ensure complete repair work for satisfying our customers by keeping their vehicle in optimum condition. When replacement of parts during repair work is needed, be sure to use SUBARU genuine parts.

All information, illustration and specifications contained in this manual are based on the latest product information available at the time of publication approval.

FRONT SUSPENSION

FS

REAR SUSPENSION

RS

WHEEL AND TIRE SYSTEM

WT

DIFFERENTIALS

DI

TRANSFER CASE

TC

DRIVE SHAFT SYSTEM

DS

ABS

ABS

ABS (DIAGNOSTICS)

ABS

BRAKE

BR

PARKING BRAKE

PB

**POWER ASSISTED SYSTEM
(POWER STEERING)**

PS

DIFFERENTIALS

DI

	Page
1. General Description	2
2. Differential Gear Oil.....	23
3. Front Differential.....	24
4. Rear Differential for T-type.....	25
5. Rear Differential for VA-type	40
6. Rear Differential Front Oil Seal	57
7. Rear Differential Side Oil Seal	59
8. Rear Differential Member	64
9. General Diagnostic Table.....	65

GENERAL DESCRIPTION

DIFFERENTIALS

1. General Description

A: SPECIFICATIONS


MODEL	Non-Turbo		Turbo	
	1.6 L	2.0 L		
		AT		MT
Rear differential type	VA type		T type	
	XN		EG EF (with LSD)	
Type of gear	Hypoid gear			
Gear ratio (Number of gear teeth)	4.111 (37/9)		3.900 (39/10) 3.545 (39/11)	
Oil capacity	0.8 \varnothing (0.8 US qt, 0.7 Imp qt)			
Rear differential gear oil	GL-5			

• Identification

When replacing a rear differential assembly, select the correct one according to the following table.

CAUTION:

Using the different rear differential assembly causes the drive line and tires to “drag” or emit abnormal noise when AWD is selected.



• Rear differential gear oil

Recommended oil

CAUTION:

Each oil manufacturer has its base oil and additives. Thus, do not mix two or more brands.

ITEM	
• Rear differential gear oil	
API Classification	
GL-5	
SAE Viscosity No. and Application Temperature	
(°C)	-30 -26 -15 -5 0 15 25 30
(°F)	-22 -15 5 23 32 59 77 86
	90
	85W
	80W
	75W-90

H3M1272A

GENERAL DESCRIPTION

DIFFERENTIALS

1. SERVICE DATA

Front and rear bearing preload at companion flange bolt hole N (kgf, lb)	New bearing	T-type	19.6 — 28.4 (2.0 — 2.9, 4.4 — 6.4)
		VA-type	12.7 — 32.4 (1.3 — 3.3, 2.9 — 7.3)
Side gear backlash mm (in)	Used bearing	T-type	0.10 — 0.20 (0.0039 — 0.0079)
		VA-type	0.05 — 0.15 (0.0020 — 0.0059)
Side bearing standard width mm (in)			20.00 (0.7874)
Crown gear to drive pinion backlash mm (in)		T-type	0.10 — 0.20 (0.0039 — 0.0079)
		VA-type	0.10 — 0.15 (0.0039 — 0.0059)
Crown gear runout on its back surface mm (in)			Less than 0.05 (0.0020)

2. ADJUSTING PARTS

• VA-type

Front and rear bearing preload at companion flange bolt hole	New bearing	12.7 — 32.4 N (1.3 — 3.3 kgf, 2.9 — 7.3 lb)
Preload adjusting spacer	Part No.	Length
	32288AA040	52.3 mm (2.059 in)
	32288AA050	52.5 mm (2.067 in)
	31454AA100	52.6 mm (2.071 in)
	32288AA060	52.7 mm (2.075 in)
	31454AA110	52.8 mm (2.079 in)
	32288AA070	52.9 mm (2.083 in)
	31454AA120	53.0 mm (2.087 in)
	32288AA080	53.1 mm (2.091 in)
	32288AA090	53.3 mm (2.098 in)
Preload adjusting washer	Part No.	Thickness
	38336AA000	1.500 mm (0.0591 in)
	38336AA120	1.513 mm (0.0596 in)
	38336AA010	1.525 mm (0.0600 in)
	38336AA130	1.538 mm (0.0606 in)
	38336AA020	1.550 mm (0.0610 in)
	38336AA140	1.563 mm (0.0615 in)
	38336AA030	1.575 mm (0.0620 in)
	38336AA150	1.588 mm (0.0625 in)
	38336AA040	1.600 mm (0.0630 in)
	38336AA160	1.613 mm (0.0635 in)
	38336AA050	1.625 mm (0.0640 in)
	38336AA170	1.638 mm (0.0645 in)
	38336AA060	1.650 mm (0.0650 in)
	38336AA180	1.663 mm (0.0655 in)
	38336AA070	1.675 mm (0.0659 in)
	38336AA190	1.688 mm (0.0665 in)
	38336AA080	1.700 mm (0.0669 in)
	38336AA200	1.713 mm (0.0674 in)
	38336AA090	1.725 mm (0.0679 in)
38336AA210	1.738 mm (0.0684 in)	
38336AA100	1.750 mm (0.0689 in)	
38336AA220	1.763 mm (0.0694 in)	
38336AA110	1.775 mm (0.0699 in)	

GENERAL DESCRIPTION

DIFFERENTIALS

	Part No.	Thickness.
Pinion height adjusting shim	32295AA200	0.150 mm (0.0059 in)
	32295AA210	0.175 mm (0.0069 in)
	32295AA220	0.200 mm (0.0079 in)
	32295AA230	0.225 mm (0.0089 in)
	32295AA240	0.250 mm (0.0098 in)
	32295AA250	0.275 mm (0.0108 in)
	Side gear thrust washer	0.05 — 0.15 mm (0.0020 — 0.0059 in)
Side gear thrust washer	803135011	0.925 — 0.950 mm (0.0364 — 0.0374 in)
	803135012	0.950 — 0.975 mm (0.0374 — 0.0384 in)
	803135013	0.975 — 1.000 mm (0.0384 — 0.0394 in)
	803135014	1.000 — 1.025 mm (0.0394 — 0.0404 in)
	803135015	1.025 — 1.050 mm (0.0404 — 0.0413 in)
Crown gear to drive pinion backlash	Limit	0.10 — 0.15 mm (0.0039 — 0.0059 in)
Crown gear runout on its back surface		0.05 mm (0.0020 in)

• T-type

Front and rear bearing preload at companion flange bolt hole	New bearing	19.6 — 28.4 N (2.0 — 2.9 kgf, 4.4 — 6.4 lb)
	Used bearing	8.34 — 16.67 N (0.85 — 1.7 kgf, 1.87 — 3.75 lb)
Preload adjusting spacer	Part No.	Length
	383695201	56.2 mm (2.213 in)
	383695202	56.4 mm (2.220 in)
	383695203	56.6 mm (2.228 in)
	383695204	56.8 mm (2.236 in)
	383695205	57.0 mm (2.244 in)
	383695206	57.2 mm (2.252 in)
Preload adjusting washer	Part No.	Length
	383705200	2.59 mm (0.1020 in)
	383715200	2.57 mm (0.1012 in)
	383725200	2.55 mm (0.1004 in)
	383735200	2.53 mm (0.0996 in)
	383745200	2.51 mm (0.0988 in)
	383755200	2.49 mm (0.0980 in)
	383765200	2.47 mm (0.0972 in)
	383775200	2.45 mm (0.0965 in)
	383785200	2.43 mm (0.0957 in)
	383795200	2.41 mm (0.0949 in)
	383805200	2.39 mm (0.0941 in)
	383815200	2.37 mm (0.0933 in)
	383825200	2.35 mm (0.0925 in)
	383835200	2.33 mm (0.0917 in)
383845200	2.31 mm (0.0909 in)	

GENERAL DESCRIPTION

DIFFERENTIALS


Pinion height adjusting shim	Part No.	Thickness
	383495200	3.09 mm (0.1217 in)
	383505200	3.12 mm (0.1228 in)
	383515200	3.15 mm (0.1240 in)
	383525200	3.18 mm (0.1252 in)
	383535200	3.21 mm (0.1264 in)
	383545200	3.24 mm (0.1276 in)
	383555200	3.27 mm (0.1287 in)
	383565200	3.30 mm (0.1299 in)
	383575200	3.33 mm (0.1311 in)
	383585200	3.36 mm (0.1323 in)
	383595200	3.39 mm (0.1335 in)
	383605200	3.42 mm (0.1346 in)
	383615200	3.45 mm (0.1358 in)
	383625200	3.48 mm (0.1370 in)
	383635200	3.51 mm (0.1382 in)
	383645200	3.54 mm (0.1394 in)
	383655200	3.57 mm (0.1406 in)
	383665200	3.60 mm (0.1417 in)
	383675200	3.63 mm (0.1429 in)
383685200	3.66 mm (0.1441 in)	
Side gear backlash	0.1 — 0.2 mm (0.0039 — 0.0079 in)	
Side gear thrust washer (Non-Turbo model)	Part No.	Thickness
	383445201	0.75 — 0.80 mm (0.0295 — 0.0315 in)
	383445202	0.80 — 0.85 mm (0.0315 — 0.0335 in)
	383445203	0.85 — 0.90 mm (0.0335 — 0.0354 in)
	383445204	0.90 — 0.95 mm (0.0354 — 0.0374 in)
	383445205	0.95 — 1.0 mm (0.0374 — 0.0394 in)
Side bearing standard width	—	20.00 mm (0.7874 in)
Side bearing retainer shim	Part No.	Thickness
	383475201	0.20 mm (0.0079 in)
	383475202	0.25 mm (0.0098 in)
	383475203	0.30 mm (0.0118 in)
	383475204	0.40 mm (0.0157 in)
	383475205	0.50 mm (0.0197 in)
Crown gear to drive pinion backlash	Limit	0.10 — 0.20 mm (0.0039 — 0.0079 in)
Crown gear runout on its back surface		0.05 mm (0.0020 in)

GENERAL DESCRIPTION

DIFFERENTIALS

B: COMPONENT

1. REAR DIFFERENTIAL FOR T-TYPE WITHOUT LSD



B3M0130C

- | | | |
|--------------------------------------|---------------------------------|------------------------|
| (1) Pinion crown gear set | (13) Side bearing | (25) Air breather cap |
| (2) Pinion height adjusting washer | (14) O-ring | (26) Stud bolt |
| (3) Rear bearing | (15) Side bearing retainer shim | (27) Oil filler plug |
| (4) Bearing preload adjusting spacer | (16) Side bearing retainer | (28) Oil drain plug |
| (5) Bearing preload adjusting washer | (17) Side oil seal | (29) Rear cover |
| (6) Differential carrier | (18) Side gear thrust washer | (30) Differential case |
| (7) Front bearing | (19) Side gear | |
| (8) Spacer | (20) Pinion mate gear | |
| (9) Pilot bearing | (21) Pinion mate gear washer | |
| (10) Front oil seal | (22) Pinion shaft lock pin | |
| (11) Companion flange | (23) Circlip | |
| (12) Self-locking nut | (24) Pinion mate shaft | |

Tightening torque: N-m (kgf-m, ft-lb)

T1: 10.3 (1.05, 7.6)


T2: 29.4 (3.00, 21.7)

T3: 49.0 (5.0, 36.2)

T4: 103.0 (10.50, 75.9)

T5: 181.4 (18.50, 133.8)

2. REAR DIFFERENTIAL FOR T-TYPE WITH LSD



B3M1662A

- | | |
|--------------------------------------|---------------------------------|
| (1) Pinion crown gear set | (12) Self-locking nut |
| (2) Pinion height adjusting shim | (13) Side bearing |
| (3) Rear bearing | (14) O-ring |
| (4) Bearing preload adjusting spacer | (15) Side bearing retainer shim |
| (5) Bearing preload adjusting washer | (16) Side bearing retainer |
| (6) Differential carrier | (17) Side oil seal |
| (7) Front bearing | (18) Gasket |
| (8) Collar | (19) Differential case |
| (9) Pilot bearing | (20) Rear cover |
| (10) Front oil seal | (21) Air breather cap |
| (11) Companion flange | (22) Stud bolt |

- | |
|----------------------|
| (23) Oil filler plug |
| (24) Oil drain plug |


Tightening torque: N-m (kgf-m, ft-lb)

- | |
|---------------------------------|
| T1: 10.3 (1.05, 7.6) |
| T2: 29.4 (3.00, 21.7) |
| T3: 49.0 (5.00, 36.2) |
| T4: 103.0 (10.50, 75.9) |
| T5: 181.4 (18.50, 133.8) |

GENERAL DESCRIPTION

DIFFERENTIALS

3. REAR DIFFERENTIAL FOR VA-TYPE



H3M1663A

- | | | |
|--------------------------------------|------------------------------|----------------------|
| (1) Pinion crown gear set | (13) Lock plate | (25) Stud bolt |
| (2) Pinion height adjusting shim | (14) Side bearing | (26) Gasket |
| (3) Rear bearing | (15) O-ring | (27) Oil filler plug |
| (4) Bearing preload adjusting spacer | (16) Axle shaft holder | (28) Oil drain plug |
| (5) Bearing preload adjusting washer | (17) Side oil seal | (29) Rear cover |
| (6) Differential carrier | (18) Side gear thrust washer | |
| (7) Front bearing | (19) Side gear | |
| (8) Collar | (20) Pinion mate gear | |
| (9) Pilot bearing | (21) Pinion shaft lock pin | |
| (10) Front oil seal | (22) Differential case | |
| (11) Companion flange | (23) Pinion mate shaft | |
| (12) Self-locking nut | (24) Air breather cap | |

Tightening torque: N·m (kgf·m, ft·lb)

T1: 25 (2.5, 18.1)


T2: 25 (2.5, 18.1)

T3: 34 (3.5, 25.3)

T4: 62 (6.3, 45.6)

T5: 188 (19.2, 139)

4. REAR DIFFERENTIAL MOUNTING SYSTEM



- | | |
|---|-------------------------------------|
| (1) Differential front member | (7) Stopper |
| (2) Plate | (8) Dynamic damper |
| (3) Crossmember | (9) Differential mount bracket |
| (4) Differential rear member | (10) Differential mount front cover |
| (5) Differential mount lower bracket
(TURBO model) | |
| (6) Differential mount lower bracket
(Non-turbo model) | |

Tightening torque: N·m (kgf·m, ft·lb)





- | | |
|------------|-------------------------|
| T1: | 20 (2.0, 14.5) |
| T2: | 33 (3.4, 24.3) |
| T3: | 65 (6.6, 47.9) |
| T4: | 70 (7.1, 51.6) |
| T5: | 90 (9.2, 66.4) |
| T6: | 100 (10.2, 73.8) |

C: CAUTION

- Wear working clothing, including a cap, protective goggles, and protective shoes during operation.
- Remove contamination including dirt and corrosion before removal, installation or disassembly.
- Keep the disassembled parts in order and protect them from dust or dirt.
- Before removal, installation or disassembly, be sure to clarify the failure. Avoid unnecessary removal, installation, disassembly, and replacement.
- Be careful not to burn your hands, because each part on the vehicle is hot after running.
- Use SUBARU genuine gear oil, grease etc. or the equivalent. Do not mix gear oil, grease etc. with that of another grade or from other manufacturers.
- Be sure to tighten fasteners including bolts and nuts to the specified torque.
- Place shop jacks or safety stands at the specified points.
- Apply gear oil onto sliding or revolution surfaces before installation.
- Before installing O-rings or snap rings, apply sufficient amount of gear oil to avoid damage and deformation.
- Before securing a part on a vice, place cushioning material such as wood blocks, aluminum plate, or shop cloth between the part and the vice.
- Avoid damaging the mating face of the case.





D: PREPARATION TOOL

1. SPECIAL TOOLS

ILLUSTRATION	TOOL NUMBER	DESCRIPTION	REMARKS
 <p style="text-align: right;">B3M1893</p>	398477701	HANDLE	Used for installing front and rear bearing cone.
 <p style="text-align: right;">B3M1894</p>	398477702	DRIFT	Used for press-fitting the bearing cone of differential carrier (rear).
 <p style="text-align: right;">B3M1895</p>	398217700	ATTACHMENT SET	Stand for rear differential carrier disassembly and assembly.
 <p style="text-align: right;">B3M1896</p>	498447120	DRIFT	Used for installing front oil seal.





GENERAL DESCRIPTION

DIFFERENTIALS

ILLUSTRATION	TOOL NUMBER	DESCRIPTION	REMARKS
 <p style="text-align: center;">B3M1897</p>	498427200	FLANGE WRENCH	Used for stopping rotation of companion flange when loosening and tightening self-lock nut.
 <p style="text-align: center;">B3M1898</p>	398467700	DRIFT	Used for removing pinion, pilot bearing and front bearing cone.
 <p style="text-align: center;">B3M1899</p>	399780104	WEIGHT	Used for installing front bearing cone, pilot bearing companion flange.
 <p style="text-align: center;">B3M1900</p>	899580100	INSTALLER	Used for press-fitting the front bearing cone, pilot bearing.





GENERAL DESCRIPTION

DIFFERENTIALS

ILLUSTRATION	TOOL NUMBER	DESCRIPTION	REMARKS
 <p style="text-align: right;">B3M1901</p>	899904100	STRAIGHT PIN REMOVER	Used for driving out differential pinion shaft lock pin.
 <p style="text-align: right;">B3M1902</p>	498247001	MAGNET BASE	<ul style="list-style-type: none"> • Used for measuring backlash between side gear and pinion, and hypoid gear.. • Used with DIAL GAUGE (498247100).
 <p style="text-align: right;">B3M1903</p>	498247100	DIAL GAUGE	<ul style="list-style-type: none"> • Used measuring backlash between side gear and pinion, hypoid gear. • Used with MAGNET BASE (498247001).
 <p style="text-align: right;">B3M1904</p>	398507704	BLOCK	Used for adjusting pinion height and preload.





GENERAL DESCRIPTION

DIFFERENTIALS

ILLUSTRATION	TOOL NUMBER	DESCRIPTION	REMARKS
 <p style="text-align: right;">B3M1905</p>	398177700	INSTALLER	<ul style="list-style-type: none"> • Used for installing rear bearing cone. • For T-type.
 <p style="text-align: right;">B3M1906</p>	398457700	ATTACHMENT	<ul style="list-style-type: none"> • Used for removing side bearing retainer. • For T-type.
 <p style="text-align: right;">B3M1907</p>	398477703	DRIFT2	<ul style="list-style-type: none"> • Used for press-fitting the bearing race (rear) of differential carrier. • For T-type.
 <p style="text-align: right;">B3M1908</p>	398437700	DRIFT	<ul style="list-style-type: none"> • Used for installing side oil seal. • For T-type.





GENERAL DESCRIPTION

DIFFERENTIALS

ILLUSTRATION	TOOL NUMBER	DESCRIPTION	REMARKS
 <p style="text-align: center;">B3M1909</p>	398507702	DUMMY SHAFT	<ul style="list-style-type: none"> • Used for adjusting pinion height and preload. • For T-type.
 <p style="text-align: center;">B3M1910</p>	398507703	DUMMY COLLAR	<ul style="list-style-type: none"> • Used for adjusting pinion height and preload. • For T-type.
 <p style="text-align: center;">B3M1911</p>	398517700	REPLACER	<ul style="list-style-type: none"> • Used for removing rear bearing cone. • For T-type.
 <p style="text-align: center;">B3M1912</p>	398487700	DRIFT	<ul style="list-style-type: none"> • Used for press-fitting the side bearing cone. • For T-type.





GENERAL DESCRIPTION

DIFFERENTIALS

ILLUSTRATION	TOOL NUMBER	DESCRIPTION	REMARKS
 <p style="text-align: center;">B3M1913</p>	398507701	DIFFERENTIAL CARRIER GAUGE	<ul style="list-style-type: none"> • Used for adjusting pinion height. • For T-type.
 <p style="text-align: center;">B3M1914</p>	398527700	PULLEY ASSY	<ul style="list-style-type: none"> • Used for removing front oil seal. • Used for removing side bearing cup. (T-type)
 <p style="text-align: center;">B3M1915A</p>	398527700	PULLER SET	<ul style="list-style-type: none"> • Used for extracting side bearing cone. (1) BOLT (899521412) (2) PULLER (399527702) (3) HOLDER (399527703) (4) ADAPTER (398497701) (5) BOLT (899520107) (6) NUT (021008000) • For T-type.
 <p style="text-align: center;">B3M1916</p>	398227700	WEIGHT	<ul style="list-style-type: none"> • Used for installing side bearing. • For T-type.





GENERAL DESCRIPTION

DIFFERENTIALS

ILLUSTRATION	TOOL NUMBER	DESCRIPTION	REMARKS
 <p style="text-align: center;">B3M1917</p>	28099PA090	OIL SEAL PROTECTOR	<ul style="list-style-type: none"> • Used for installing rear drive shaft into rear differential. • For protecting oil seal.
 <p style="text-align: center;">B3M1918</p>	398237700	GAUGE	<ul style="list-style-type: none"> • Used for installing side bearing. • For T-type.
 <p style="text-align: center;">B3M1919</p>	28099PA100	DRIVE SHAFT REMOVER	<ul style="list-style-type: none"> • Used for removing rear drive shaft from rear differential. • For T-type.
 <p style="text-align: center;">B3M1920</p>	498175500	INSTALLER	<ul style="list-style-type: none"> • Used for installing rear bearing cone. • For VA-type.





GENERAL DESCRIPTION

DIFFERENTIALS

ILLUSTRATION	TOOL NUMBER	DESCRIPTION	REMARKS
 <p style="text-align: center;">B3M1921</p>	499785500	WRENCH ASSY	<ul style="list-style-type: none"> • Used for removing and installing side oil seal holder. • For VA-type.
 <p style="text-align: center;">B3M1922</p>	498447100	DRIFT	<ul style="list-style-type: none"> • Used for installing oil seal. • For VA-type.
 <p style="text-align: center;">B3M1923</p>	399520105	SEAT	<ul style="list-style-type: none"> • Used for removing side bearing cone. • Used with PULLER SET (899524100). • For VA-type.
 <p style="text-align: center;">B3M1930</p>	399703602	PULLEY ASSY	<ul style="list-style-type: none"> • Used for removing companion flange





GENERAL DESCRIPTION

DIFFERENTIALS

ILLUSTRATION	TOOL NUMBER	DESCRIPTION	REMARKS
 <p style="text-align: center;">B3M1924</p>	498485400	DRIFT	<ul style="list-style-type: none"> • Used for installing side bearing cone. • For VA-type.
 <p style="text-align: center;">B3M1925</p>	498505501	DIFFERENTIAL CARRIER GAUGE	<ul style="list-style-type: none"> • Used for adjusting pinion height. • For VA-type.
 <p style="text-align: center;">B3M1926</p>	498447110	DRIFT	<ul style="list-style-type: none"> • Used for press-fitting the bearing race (front) of differential carrier. • For VA-type.
 <p style="text-align: center;">B3M1927</p>	498447150	DUMMY SHAFT	<ul style="list-style-type: none"> • Used for adjusting pinion height and Pre-load. • For VA-type.



GENERAL DESCRIPTION

DIFFERENTIALS

ILLUSTRATION	TOOL NUMBER	DESCRIPTION	REMARKS
 <p style="text-align: center;">B3M1911</p>	498515500	REPLACER	<ul style="list-style-type: none"> • Used for removing rear bearing cone. • For VA-type.
 <p style="text-align: center;">B3M1977</p>	32285AA000	DUMMY COLLAR	<ul style="list-style-type: none"> • Used for adjusting pinion height and Pre-load. • For VA-type.
 <p style="text-align: center;">B3M1928</p>	499705404	SEAT	<ul style="list-style-type: none"> • Used for removing side bearing race. • Used with PULLEY ASSY (499705401). • For VA-type.
 <p style="text-align: center;">B3M1930</p>	499705401	PULLEY ASSY	<ul style="list-style-type: none"> • Used for removing side bearing race. • Used with SEAT (499705404). • For VA-type.

GENERAL DESCRIPTION

DIFFERENTIALS

ILLUSTRATION	TOOL NUMBER	DESCRIPTION	REMARKS
 <p>B3M1931</p>	899874100	INSTALLER	<ul style="list-style-type: none">• Used for installing companion flange.
 <p>B3M1932A</p>	899524100	PULLER SET	<ul style="list-style-type: none">• Used for removing side bearing cone of differential.• For VA-type.(1) Puller(2) Cap

GENERAL DESCRIPTION

DIFFERENTIALS


2. GENERAL PURPOSE TOOLS

TOOL NAME	REMARKS
Transmission jack	Used for assembly/disassembly of rear differential.
Puller	Used for removal of side bearing retainer. (T-type)
Thickness gauge	Used for measuring clearance.
Tire lever	Used for removal of rear drive shaft. (VA-type)

2. Differential Gear Oil

A: INSPECTION

- 1) Take out filler plug, and replace gear oil if it is contaminated or deteriorated. <Ref. to DI-23, REPLACEMENT, Differential Gear Oil.>
- 2) Check gear oil level is up to the bottom part of filler bolt. If the level is low, refill up to the bottom of filler bolt.




(A) Filler plug
(B) Drain plug

B: REPLACEMENT

- 1) Disconnect ground terminal from battery.
- 2) Jack-up vehicle and support it with sturdy racks.
- 3) Remove the oil drain plug and filler plug, and drain the gear oil.

CAUTION:

Be careful not to burn your hands, because gear oil becomes extremely hot after running.



(A) Filler plug
(B) Drain plug

- 4) Tighten oil drain plug.

NOTE:

- Apply fluid packing to drain plug in T-type.
- VA-type uses a new aluminum gasket.

Fluid packing:

THREE BOND 1105 or equivalent

Tightening torque:

T-type;

49.0 N·m (5.0 kgf-m, 36.2 ft-lb)

VA-type;

34 N·m (3.5 kgf-m, 25.3 ft-lb)


- 5) Fill differential carrier with gear oil to the upper plug level.

CAUTION:

Carefully refill oil while watching the level. Excess or insufficient oil must be avoided.

Oil capacity:

0.8 ℓ (0.8 US qt, 0.7 Imp qt)



- 6) Install filler plug.

CAUTION:

- Apply fluid packing to drain plug in T-type.
- VA-type uses a new aluminum gasket.

Fluid packing:

THREE BOND 1105 or equivalent

Tightening torque:

T-type;

49.0 N·m (5.0 kgf-m, 36.2 ft-lb)

VA-type;

34 N·m (3.5 kgf-m, 25.3 ft-lb)

3. Front Differential

A: NOTE

1. AT MODEL

Refer to AUTOMATIC TRANSMISSION in separate publication "AUTOMATIC TRANSMISSION for Front Differential.

2. MT MODEL

For front differential of manual transmission, refer to "MT" section. <Ref. to MT-102, Front Differential Assembly.>

4. Rear Differential for T-type

A: REMOVAL

- 1) Set the vehicle on the lift.
- 2) Disconnect ground terminal from battery.
- 3) Move select lever or gear shift lever to "N".
- 4) Release the parking brake.
- 5) Loosen wheel nuts.
- 6) Jack-up vehicle and support it with sturdy racks.
- 7) Remove wheels.
- 8) Remove rear exhaust pipe and muffler.

Non-turbo model without OBD

<Ref. to EX(SOHCw/oOBD)-13, REMOVAL, Rear Exhaust Pipe.> and <Ref. to EX(SOHCw/oOBD)-14, REMOVAL, Muffler.>


Non-turbo model with OBD

<Ref. to EX(SOHC)-11, REMOVAL, Rear Exhaust Pipe.> and <Ref. to EX(SOHC)-12, REMOVAL, Muffler.>

Turbo model

<Ref. to EX(DOHC TURBO)-13, REMOVAL, Rear Exhaust Pipe.> and <Ref. to EX(DOHC TURBO)-14, REMOVAL, Muffler.>

- 9) Remove front cover of rear differential mount.




- 10) Remove propeller shaft.

CAUTION:


When removing propeller shaft, pay attention not to damage the sliding surfaces of rear drive shaft (extension) spline, oil seal and sleeve yoke.

NOTE:

- Prepare an oil can and cap since the transmission oil flows out from the extension at removing propeller shaft.
- Insert the cap into the extension to prevent transmission oil from flowing out immediately after removing the propeller shaft.
- If extension cap is not available, cover the opening with a vinyl bag in order to prevent transmission gear oil or ATF leakage.




- 11) Remove heat sealed cover.
- 12) Remove clamps and bracket of parking brake cable.



REAR DIFFERENTIAL FOR T-TYPE


DIFFERENTIALS

13) Remove DOJ of rear drive shaft from rear differential using ST. <Ref. to DI-59, REPLACE-
MENT, Rear Differential Side Oil Seal.>
ST 28099PA100 DRIVE SHAFT REMOVER




(A) Bolt


14) Secure rear drive shaft to rear crossmember using wire.




15) Remove lower differential bracket.



16) Support rear differential with transmission jack.



17) Remove self-locking nuts connecting rear differential to rear crossmember.




18) Remove bolts which secure rear differential front member to body.

Loosen bolt A first, then remove bolts B.

NOTE:

Support front member with the use of a helper to prevent it from dropping.




(A) Bolt A



(B) Bolt B

19) Remove bolt A.

20) While slowly lowering transmission jack, move rear differential forward and remove front member and rear differential from body.



21) Remove rear differential from front member.



- (A) Filler plug
- (B) Drain plug

B: INSTALLATION

To install, reverse the removal sequence.

1) Install the air breather cap tapping with a plastic hammer.

CAUTION:

Be sure to install new air breather cap.


2) Position front member on body by passing it under parking brake cable and securing to rear differential.

NOTE:

When installing rear differential front member, do not confuse the installation sequence of the upper and lower stoppers.

3) Install DOJ of drive shaft into rear differential. <Ref. to DI-59, REPLACEMENT, Rear Differential Side Oil Seal.>

ST 28099PA090 SIDE OIL SEAL PROTECTOR




C: DISASSEMBLY

To detect real cause of trouble, inspect the following items before disassembling.

- Tooth contact of crown gear and pinion, and backlash
- Runout of crown gear at its back surface
- Turning resistance of drive pinion

1) Set ST on vise and install the differential assembly to ST.

ST 398217700 ATTACHMENT



- 2) Drain gear oil by removing plug.
- 3) Remove the air breather cap.

NOTE:

Do not attempt to replace the air breather cap unless necessary.

4) Installing procedure hereafter is in reverse order of removal.

5) After installation, fill differential carrier with gear oil to the filler plug level.

NOTE:

Apply fluid packing to plug.

Fluid packing:


THREE BOND 1105 or equivalent

Oil capacity:

0.8 ℓ (0.8 US qt, 0.7 Imp qt)

Tightening torque:

49 N·m (5.0 kgf·m, 36.2 ft·lb)




- (A) Air breather cap
- (B) Rear cover

REAR DIFFERENTIAL FOR T-TYPE

DIFFERENTIALS

4) Remove rear cover by loosening retaining bolts.




- (A) Rear cover
- (B) Differential carrier

5) Make right and left side bearing retainers in order to identify them at reassembly. Remove side bearing retainer attaching bolts, set ST to differential case, and extract right and left side bearing retainers with a puller.


CAUTION:
Each shim, which is installed to adjust the side bearing preload, should be kept together with its mating retainer.

ST 398457700 ATTACHMENT




6) Pull out differential case assembly from differential carrier.

CAUTION:
Be careful not to hit the teeth against the case.



7) When replacing side bearing, pull bearing cup from side bearing retainer using ST.

ST 398527700 PULLER ASSY




8) Extract bearing cone with ST.

CAUTION:
Do not attempt to disassemble the parts unless necessary.

NOTE:


- Set puller so that its claws catch the edge of the bearing cone.
- Never mix up the right and left hand bearing races and cones.

ST 398527700 PULLER SET



9) Remove crown gear by loosening crown gear bolts.

CAUTION:
Further disassembling is not allowed.



REAR DIFFERENTIAL FOR T-TYPE


DIFFERENTIALS

10) Drive out pinion shaft lock pin from crown gear side. (Without LSD)

NOTE:

The lock pin is staked at the pin hole end on the differential carrier; do not drive it out forcibly before unstaking it.


ST 899904100 STRAIGHT PIN REMOVER



11) Draw out pinion mate shaft and remove pinion mate gears, side gears and thrust washers. (Without LSD)

NOTE:


The gears as well as thrust washers should be marked or kept separated left and right, and front and rear.




- (A) Side gear
- (B) Pinion mate gear
- (C) Thrust washer
- (D) Differential case
- (E) Pinion mate shaft

12) Hold companion flange with ST and remove drive pinion nut.

ST 498427200 FLANGE WRENCH



13) Extract the companion flange with a puller.




14) Press the end of drive pinion shaft and extract it together with rear bearing cone, preload adjusting spacer and washer.

NOTE:

Hold the drive pinion so as not to drop it.

ST 398467700 DRIFT




15) Remove rear bearing cone from drive pinion by supporting cone with ST.

NOTE:

Place the replacer so that its center-recessed side faces the pinion gear.

ST 398517700 REPLACER




REAR DIFFERENTIAL FOR T-TYPE

DIFFERENTIALS


16) Remove front oil seal from differential carrier using ST.

ST 398527700 PULLER ASSY




17) Remove pilot bearing together with front bearing cone using ST.

ST 398467700 DRIFT



- (A) Pinion bearing
- (B) Front bearing
- (C) Rear bearing cup

18) When replacing bearings, tap front bearing cup and rear bearing cup in this order out of case by using a brass bar.




- (A) 2 cutouts along diagonal lines
- (B) Tap alternately with brass bar.

D: ASSEMBLY

1) Precautions for assembling

- Assemble in the reverse order of disassembling.
- Check and adjust each part during assembly.
- Keep the shims and washers in order, so that they are not misinstalled.
- Thoroughly clean the surfaces on which the shims, washers and bearings are to be installed.
- Apply gear oil when installing the bearings and thrust washers.
- Be careful not to mix up the right and left hand races of the bearings.
- Replace the oil seal with new one at every disassembly. Apply chassis grease between the lips when installing the oil seal.




2) Adjusting preload for front and rear bearings

Adjust the bearing preload with spacer and washer between front and rear bearings. Pinion height adjusting washer are not affected by this adjustment. The adjustment must be carried out without oil seal inserted.

(1) Press rear bearing race into differential carrier with ST1 and ST2.

ST1 398477701 HANDLE

ST2 398477703 DRIFT 2




(2) Insert ST1 into carrier with pinion height adjusting washer and rear bearing cone fitted onto it.

CAUTION:

- Re-use the used washer if not deformed.
- Use a new rear bearing cone.

(3) Then install preload adjusting spacer and washer, front bearing cone, ST2, companion flange, and washer and drive pinion nut.

ST1 398507702 DUMMY SHAFT
 ST2 398507703 DUMMY COLLAR



- (A) Pinion height adjusting shim
- (B) Preload adjusting spacer
- (C) Preload adjusting washer

(4) Turn ST1 with hand to make it seated, and tighten drive pinion nut while measuring the preload with spring balance. Select preload adjusting washer and spacer so that the specified preload is obtained when nut is tightened to the specified torque.


CAUTION:
 Use a new lock nut.

NOTE:


- Be careful not to give excessive preload.
- When tightening the drive pinion nut, lock ST1 with ST2 as shown in the figure.

ST1 398507704 BLOCK
 ST2 398507702 DUMMY SHAFT

Tightening torque:
 181 N·m (18.5 kgf·m, 134 ft·lb)



Front and rear bearing preload
For new bearing: 19.6 — 28.4 N (2.0 — 2.9 kgf, 4.4 — 6.4 lb) at companion flange bolt hole
For used bearing: 8.34 — 16.67 N (0.85 — 1.7 kgf, 1.87 — 3.75 lb) at companion flange bolt hole



	Part No.	Thickness mm (in)
	Preload adjusting washer	383705200
383715200		2.57 (0.1012)
383725200		2.55 (0.1004)
383735200		2.53 (0.0996)
383745200		2.51 (0.0988)
383755200		2.49 (0.0980)
383765200		2.47 (0.0972)
383775200		2.45 (0.0965)
383785200		2.43 (0.0957)
383795200		2.41 (0.0949)
383805200		2.39 (0.0941)
383815200		2.37 (0.0933)
383825200		2.35 (0.0925)
Preload adjusting spacer	Part No.	Length mm (in)
	383695201	56.2 (2.213)
	383695202	56.4 (2.220)
	383695203	56.6 (2.228)
	383695204	56.8 (2.236)
	383695205	57.0 (2.244)
	383695206	57.2 (2.252)

3) Adjusting drive pinion height
 Adjust drive pinion height with shim installed between rear bearing cone and the back of pinion gear.

(1) Install ST1, ST2 and ST3, as shown in the figure, and apply the specified preload on the bearings.

Front and rear bearing preload
For new bearing: 19.6 — 28.4 N (2.0 — 2.9 kgf, 4.4 — 6.4 lb) at companion flange bolt hole
For used bearing: 8.34 — 16.67 N (0.85 — 1.7 kgf, 1.87 — 3.75 lb) at companion flange bolt hole

Adjusting preload for front and rear bearings


REAR DIFFERENTIAL FOR T-TYPE

DIFFERENTIALS

NOTE:

At this time, install a pinion height adjusting shim which is temporarily selected or the same as that used before. Measure and record the thickness.

- ST1 398507702 DUMMY SHAFT
- ST2 398507701 DIFFERENTIAL CARRIER GAUGE
- ST3 398507703 DUMMY COLLAR




(A) Pinion height adjusting shim

(2) Measure the clearance N between the end of ST2 and the end surface of ST1 by using a thickness gauge.

NOTE:

Make sure there is no clearance between the case and ST2.

- ST1 398507702 DUMMY SHAFT
- ST2 398507701 DIFFERENTIAL CARRIER GAUGE



(3) Obtain the thickness of pinion height adjusting shim to be inserted from the following formula, and replace the temporarily installed shim with this one.

$$T = T_o + N - (H \times 0.01) - 0.20 \text{ mm (0.0079 in)}$$

NOTE:

Use copies of this page.

T	Thickness of shim temporarily inserted mm (in)	
To	Thickness of pinion height adjusting shim mm (in)	
N	Reading of thickness gauge mm (in)	
H	Figure marked on drive pinion head	
Memo:		

(Example of calculation)

$$T_o = 2.20 + 1.20 = 3.40 \text{ mm}$$

$$N = 0.23 \text{ mm } H = + 1,$$

$$T = 3.40 + 0.23 - 0.01 - 0.20 = 3.42$$


Result: Thickness = 3.42 mm

Therefore use the shim 383605200.


Pinion height adjusting shim	
Part No.	Thickness mm (in)
383495200	3.09 (0.1217)
383505200	3.12 (0.1228)
383515200	3.15 (0.1240)
383525200	3.18 (0.1252)
383535200	3.21 (0.1264)
383545200	3.24 (0.1276)
383555200	3.27 (0.1287)
383565200	3.30 (0.1299)
383575200	3.33 (0.1311)
383585200	3.36 (0.1323)
383595200	3.39 (0.1335)
383605200	3.42 (0.1346)
383615200	3.45 (0.1358)
383625200	3.48 (0.1370)
383635200	3.51 (0.1382)
383645200	3.54 (0.1394)
383655200	3.57 (0.1406)
383665200	3.60 (0.1417)
383675200	3.63 (0.1429)
383685200	3.66 (0.1441)

4) Install the selected pinion height adjusting shim on drive pinion, and press the rear bearing cone into position with ST.

ST 398177700 INSTALLER




5) Insert drive pinion into differential carrier, install the previously selected bearing preload adjusting spacer and washer.



- (A) Drive pinion
- (B) Bearing adjusting spacer
- (C) Washer
- (D) Differential carrier


6) Press-fit front bearing cone into case with ST1, ST2 and ST3.

- ST1 398507703 DUMMY COLLAR
- ST2 399780104 WEIGHT
- ST3 899580100 INSTALLER



7) Insert spacer, then press-fit pilot bearing with ST1 and ST2.

- ST1 399780104 WEIGHT
- ST2 899580100 INSTALLER




8) Fit a new oil seal with ST.

NOTE:

- Press-fit until end of oil seal is 1 mm (0.04 in) inward from end of carrier.
- Apply grease between the oil seal lips.

ST 498447120 DRIFT




9) Press-fit companion flange with ST1 and ST2.

CAUTION:

Be careful not to damage bearing.

- ST1 899874100 INSTALLER
- ST2 399780104 WEIGHT




10) Install self-locking nut. Then tighten it with ST.

ST 498427200 FLANGE WRENCH

Tightening torque:

181 N·m (18.5 kgf-m, 134 ft-lb)



11) Assembling differential case


Install side gears and pinion mate gears, with their thrust washers and pinion mate shaft, into differential case. (Without LSD)

REAR DIFFERENTIAL FOR T-TYPE

DIFFERENTIALS

CAUTION:

- Apply gear oil on both sides of the washer and on the side gear shaft before installing.
- Insert the pinion mate shaft into the differential case by aligning the lock pin holes.




G3M0089

(1) Measure the side gear backlash.

Side gear back clearance:

0.10 — 0.20 mm (0.0039 — 0.0079 in)



B3M1933

(2) Adjust the backlash as specified by selecting side gear thrust washer.

Side gear thrust washer	
Part No.	Thickness mm (in)
383445201	0.75 — 0.80 (0.0295 — 0.0315)
383445202	0.80 — 0.85 (0.0315 — 0.0335)
383445203	0.85 — 0.90 (0.0335 — 0.0354)
383445204	0.90 — 0.95 (0.0354 — 0.0374)
383445205	0.95 — 1.00 (0.0374 — 0.0394)

(3) Check the condition of rotation after applying oil to the gear tooth surfaces and thrust surfaces.

(4) After inserting pinion shaft lock pin into differential case, stake the both sides of the hole to prevent pin from falling off.

12) Install crown gear on differential case.

CAUTION:

Before installing bolts, apply Lock Tite to bolt threads.

Lock Tite:


THREE BOND 1324 or equivalent

NOTE:

Tighten diagonally while tapping the bolt heads.

Tightening torque:


103 N·m (10.5 kgf·m, 76 ft·lb)



S3M0509

13) Press side bearing cone onto differential case with ST.

ST 398487700 DRIFT




G3M0091

14) Adjusting side bearing retainer shims

(1) The driven gear backlash and side bearing preload can be determined by the side bearing retainer shim thickness.

(2) Install the differential case assembly into differential carrier in the reverse order of disassembly.



S3M0533

(3) Install side retainer shims and O-rings to the left and right retainers from which they were removed.

NOTE:


- Replace broken or cracked O-ring with new one.
- Replace broken or corroded side retainer shim with new one of same thickness.

Side bearing retainer shim	
Part No.	Thickness mm (in)
383475201	0.20 (0.0079)
383475202	0.25 (0.0098)
383475203	0.30 (0.0118)
383475204	0.40 (0.0157)
383475205	0.50 (0.0197)

(4) Align arrow marked on differential carrier with that marked on side retainer during installation.

CAUTION:

Be careful that side bearing outer race is not damaged by bearing roller.



(A) Arrow mark

(5) Tighten side bearing retainer bolts.

CAUTION:


Before tightening the two side bearing retainer bolts, apply Lock Tite to bolt threads.

⇒ **Lock Tite:**

THREE BOND 1105 or equivalent

Tightening torque:


10.3 N·m (1.05 kgf·m, 7.6 ft·lb)



(6) Measure the crown gear-to-drive pinion backlash. Set magnet base on differential carrier. Align contact point of dial gauge with tooth face of crown gear, and move crown gear while holding drive pinion still. Read value indicated on dial gauge.

Backlash:

0.10 — 0.20 mm (0.0039 — 0.0079 in)



(7) At the same time, measure the turning resistance of drive pinion. Compared with the resistance when differential case is not installed, if the increase of the resistance is not within the specified range, readjust side bearing retainer shims.


Turning resistance increase:

2.9 — 10.8 N (0.3 — 1.1 kgf, 0.7 — 2.4 lb)

15) Re-check crown gear-to-pinion backlash.

Backlash:

0.10 — 0.20 mm (0.0039 — 0.0079 in)




REAR DIFFERENTIAL FOR T-TYPE

DIFFERENTIALS

16) Check the crown gear runout on its back surface, and make sure pinion and crown gear rotate smoothly.

Limit of runout:


Less than 0.05 mm (0.0020 in)



(2) Hypoid gear backlash

Backlash:

0.10 — 0.20 mm (0.0039 — 0.0079 in)



17) Checking and adjusting tooth contact of crown gear

- (1) Apply an even coat of red lead on both sides of three or four teeth on the crown gear. Check the contact pattern after rotating crown gear several revolutions back and forth until a definite contact pattern appears on the crown gear.
- (2) When the contact pattern is incorrect, readjust according to the instructions given in "TOOTH CONTACT PATTERN".


NOTE:

Be sure to wipe off red lead completely after adjustment is completed.

18) If proper tooth contact is not obtained, once again adjust the drive pinion height changing RH and LH side bearing retainer shims and the hypoid gear backlash.

(1) Drive pinion height

- ST1 398507702 DUMMY SHAFT
- ST2 398507701 DIFFERENTIAL CARRIER GAUGE














$$T = T_o + N - (H \times 0.01) - 0.20 \text{ (mm)}$$

Where:

- T = Thickness of pinion height adjusting shim (mm)
- T_o = Thickness of shim temporarily inserted (mm)
- N = Reading of thickness gauge (mm)
- H = Figure marked on drive pinion head

REAR DIFFERENTIAL FOR T-TYPE

TOOTH CONTACT PATTERN		
Condition	Contact pattern	Adjustment
<p>Correct tooth contact Tooth contact pattern slightly shifted towards toe under no load rotation. (When loaded, contact pattern moves toward heel.)</p>	 <p style="text-align: center;">G3M0098A</p>	—
<p>Face contact Backlash is too large.</p>	 <p style="text-align: center;">G3M0098B</p>	<p>Increase thickness of drive pinion height adjusting shim in order to bring drive pinion closer to crown gear center.</p>  <p style="text-align: right;">G3M0098F</p>
<p>F flank contact Backlash is too small.</p>	 <p style="text-align: center;">G3M0098C</p>	<p>Reduce thickness of drive pinion height adjusting shim in order to move drive pinion away from crown gear center.</p>  <p style="text-align: right;">G3M0098G</p>
<p>Toe contact Contact area is small.</p>	 <p style="text-align: center;">G3M0098D</p>	<p>Adjust as for flank contact.</p>  <p style="text-align: right;">G3M0098G</p>
<p>Heel contact Contact area is small.</p>	 <p style="text-align: center;">G3M0098E</p>	<p>Adjust as for face contact.</p>  <p style="text-align: right;">G3M0098F</p>

 : Adjusting direction of drive pinion
 : Adjusting direction of crown gear

REAR DIFFERENTIAL FOR T-TYPE

DIFFERENTIALS


19) Install rear cover and tighten bolts to specified torque.

CAUTION:

Securely connect ground terminal of rear differential temperature sensor.

Tightening torque:

29 N·m (3.0 kgf·m, 21.7 ft·lb)



E: INSPECTION

Wash all the disassembled parts clean, and examine them for wear, damage, or other defects. Repair or replace defective parts as necessary.

1) Crown gear and drive pinion

- If abnormal tooth contact is evident, find out the cause and adjust to give correct tooth contact at assembly. Replace the gear if excessively worn or incapable of adjustment.
- If crack, score, or seizure is evident, replace as a set. Slight damage of tooth can be corrected by oil stone or the like.

2) Side gear and pinion mate gear

- Replace if crack, score, or other defects are evident on tooth surface.
- Replace if thrust washer contacting surface is worn or seized. Slight damage of the surface can be corrected by oil stone or the like.

3) Bearing

Replace if seizure, peeling, wear, rust, dragging during rotation, abnormal noise or other defect is evident.

4) Thrust washers of side gear and pinion mate gear

Replace if seizure, flaw, abnormal wear or other defect is evident.

5) Oil seal

Replace if deformed or damaged, and at every disassembling.

6) Differential carrier

Replace if the bearing bores are worn or damaged.

7) Differential case

Replace if its sliding surfaces are worn or cracked.

8) Companion flange

Replace if the oil seal lip contacting surfaces have flaws.


1. SIDE GEAR BACKLASH

Using a dial gauge, check the backlash of the side gear.

Side gear backlash:

0.1 — 0.2 mm (0.004 — 0.008 in)

If side gear backlash is not within the specification, adjust clearance as specified by selecting side gear thrust washer.




2. CROWN GEAR BACKLASH

Using a dial gauge, check the backlash of the crown gear.

Crown gear backlash:

0.1 — 0.2 mm (0.004 — 0.008 in)

If crown gear backlash is not within the specification, adjust the side bearing preload or repair if necessary.




3. CROWN GEAR RUNOUT

Using a dial gauge, check the crown gear runout.

Crown gear runout:

Less than 0.05 mm (0.0020 in)

If the crown gear runout exceeds 0.05 mm (0.0020 in), replace the crown gear.



4. TOOTH CONTACT BETWEEN CROWN GEAR AND DRIVE PINION

Inspect tooth contact between crown gear and driven pinion. <Ref. to DI-30, ASSEMBLY, Rear Differential for T-type.>


5. TOTAL PRELOAD

Using a gauge, check the turning resistance increase.

Total preload:

2.9 — 10.8 N·m (0.3 — 1.1 kgf, 0.7 — 2.4 lb)

If the increase of the resistance is not within the specification, adjust the side bearing retainer shims.



F: ADJUSTMENT

1. SIDE GEAR BACKLASH

Adjust side gear backlash.

<Ref. to DI-30, ASSEMBLY, Rear Differential for T-type.>

2. CROWN GEAR BACKLASH

Adjust crown gear backlash.

<Ref. to DI-30, ASSEMBLY, Rear Differential for T-type.>

3. TOOTH CONTACT BETWEEN CROWN GEAR AND DRIVE PINION

Adjust the tooth contact between crown gear and drive pinion gear.

<Ref. to DI-30, ASSEMBLY, Rear Differential for T-type.>

4. TOTAL PRELOAD

Adjust side bearing shim.

<Ref. to DI-30, ASSEMBLY, Rear Differential for T-type.>

REAR DIFFERENTIAL FOR VA-TYPE

DIFFERENTIALS

5. Rear Differential for VA-type

A: REMOVAL

- 1) Set the vehicle on the lift.
- 2) Disconnect ground terminal from battery.
- 3) Move select lever or gear shift lever to "N".
- 4) Release the parking brake.
- 5) Loosen wheel nuts.
- 6) Jack-up vehicle and support it with sturdy racks.
- 7) Remove wheels.
- 8) Remove rear exhaust pipe and muffler.

Non-turbo model without OBD

<Ref. to EX(SOHCw/oOBD)-13, REMOVAL, Rear Exhaust Pipe.> and <Ref. to EX(SOHCw/oOBD)-14, REMOVAL, Muffler.>


Non-turbo model with OBD

<Ref. to EX(SOHC)-11, REMOVAL, Rear Exhaust Pipe.> and <Ref. to EX(SOHC)-12, REMOVAL, Muffler.>

Turbo model

<Ref. to EX(DOHC TURBO)-13, REMOVAL, Rear Exhaust Pipe.> and <Ref. to EX(DOHC TURBO)-14, REMOVAL, Muffler.>

- 9) Remove front cover of rear differential mount.




- 10) Remove propeller shaft.

CAUTION:

When removing propeller shaft, pay attention not to damage the sliding surfaces of rear drive shaft (extension) spline, oil seal and sleeve yoke.


NOTE:

- Prepare an oil can and cap since the transmission oil flows out from the extension at removing propeller shaft.
- Insert the cap into the extension to prevent transmission oil from flowing out immediately after removing the propeller shaft.




- 11) Remove heat sealed cover.

- 12) Remove clamps and bracket of parking brake cable.




REAR DIFFERENTIAL FOR VA-TYPE


13) Remove DOJ of rear drive shaft from rear differential.<Ref. to DI-59, REPLACEMENT, Rear Differential Side Oil Seal.>




14) Secure rear drive shaft to rear crossmember using wire.




15) Remove lower differential bracket..



16) Support rear differential with transmission jack.




17) Remove self-locking nuts connecting rear differential to rear crossmember.



18) Remove bolts which secure rear differential front member to bolts B.

NOTE:

Support front member with the use A first, then removal bolts B.




- (A) Bolt A
- (B) Bolt B

19) Remove bolt A.

20) While slowly lowering transmission jack, move rear differential forward and remove bolts from rear crossmember.



21) Remove front member from body.



REAR DIFFERENTIAL FOR VA-TYPE

DIFFERENTIALS

22) Remove rear differential from body.



B: INSTALLATION

To install, reverse the removal sequence.


1) Position front member on body by passing it under parking cable and securing to rear differential.

NOTE:

When installing rear differential front member, do not confuse the installation sequence of the upper and lower stoppers.

2) Install DOJ of rear drive shaft into rear differential. <Ref. to DI-59, REPLACEMENT, Rear Differential Side Oil Seal.>

ST 28099PA090 SIDE OIL SEAL PROTECTOR



3) Install in the reverse order of removal.

4) After installation, fill differential carrier with gear oil to the upper plug level.

NOTE:

Use a new aluminum gasket when installing the plug.

Oil capacity:

0.8 ℓ (0.8 US qt, 0.7 Imp qt)

Tightening torque:

34 N·m (3.5 kgf·m, 25.3 ft·lb)


C: DISASSEMBLY

To detect real cause of trouble, inspect the following items before disassembling.

- Tooth contact of crown gear and pinion, and backlash
- Runout of crown gear at its back surface
- Turning resistance of drive pinion


1) Set ST on vise and install the differential assembly to ST.

ST 398217700 ATTACHMENT



2) Drain gear oil by removing plug.

3) Remove rear cover by loosening retaining bolts.




REAR DIFFERENTIAL FOR VA-TYPE

4) Replace air breather cap.


NOTE:

Do not attempt to replace the air breather cap unless necessary.




(A) Air breather cap
(B) Rear cover

5) Remove right and left lock plates.




6) Remove right and left holders with ST.
ST 499785500 WRENCH



7) Pull out differential assembly from differential case.


CAUTION:

Be careful not to hit the teeth against the case.



8) Remove bearing race from right and left holders with ST1 and ST2.

ST1 499705401 PULLEY ASSY
ST2 499705404 SEAT




(A) Bearing race
(B) Holder

9) Remove oil seal from right and left holders with screwdriver.

CAUTION:

Perform this operation only when changing oil seal.



REAR DIFFERENTIAL FOR VA-TYPE

DIFFERENTIALS

10) Extract bearing cone with ST1 and ST2.


CAUTION:

Do not attempt to disassemble the parts unless necessary.


NOTE:

- Set Puller so that its claws catch the edge of the bearing cone.
- Never mix up the right and left hand bearing races and cones.

ST1 899524100 PULLER SET
ST2 399520105 SEAT



11) Remove crown gear by loosening crown gear bolts.




12) Drive out pinion shaft lock pin from crown gear side.

NOTE:

The lock pin is staked at the pin hole end on the differential case; do not drive it out forcibly before unstaking it.


ST 899904100 STRAIGHT PIN REMOVER



13) Draw out pinion mate shaft and remove pinion mate gears, side gears and thrust washers.

NOTE:


The gears as well as thrust washers should be marked or kept separated left and right, and front and rear.




- (A) Side gear
- (B) Pinion mate gear
- (C) Thrust washer
- (D) Differential case
- (E) Pinion mate shaft

14) Hold companion flange with ST and remove self-locking nut.

ST 498427200 FLANGE WRENCH



15) Extract the companion flange with a puller.



- (A) Companion
- (B) Puller


REAR DIFFERENTIAL FOR VA-TYPE

16) Press the end of drive pinion shaft and extract it together with rear bearing cone, preload adjusting spacer and washer.

NOTE:

Hold the drive pinion so as not to drop it.

ST 398467700 DRIFT




17) Remove rear bearing cone from drive pinion by supporting cone with ST.

NOTE:


Place the replacer so that its center-recessed side faces the pinion gear.

ST 498515500 REPLACER



18) Remove front oil seal from differential carrier using ST.


ST 398527700 PULLER SET



- (A) Differential carrier
- (B) Front oil seal


19) Remove pilot bearing together with front bearing cone using ST.

ST 398467700 DRIFT



- (A) Pilot bearing
- (B) Front bearing
- (C) Rear bearing cup

20) When replacing bearings, tap front bearing cup and rear bearing cup in this order out of case by using a brass bar.



- (A) 2 cutouts along diagonal lines
- (B) Tap alternately with brass bar.


REAR DIFFERENTIAL FOR VA-TYPE

DIFFERENTIALS

D: ASSEMBLY

1) Precautions for assembling

- Assemble in the reverse order of disassembling.
- Check and adjust each part during assembly.
- Keep the shims and washers in order, so that they are not misinstalled.
- Thoroughly clean the surfaces on which the shims, washers and bearings are to be installed.
- Apply gear oil when installing the bearings and thrust washers.
- Be careful not to mix up the right and left hand races of the bearings.
- Replace the oil seal with new one at every disassembly. Apply chassis grease between the lips when installing the oil seal.



2) Adjust preload for front and rear bearings.

Adjust the bearing preload with spacer and washer between front and rear bearings. Pinion height adjusting washer are not affected by this adjustment. The adjustment must be carried out without oil seal inserted.

- (1) Press rear bearing race into differential carrier with ST1 and ST2.


ST1 398477701 HANDLE

ST2 398477702 DRIFT

- (2) Press front bearing race into differential carrier with ST1 and ST2.

ST1 398477701 HANDLE

ST2 498447110 DRIFT



- (3) Insert front bearing cone.

CAUTION:

Use a new front bearing cone.

- (4) Insert ST1 into case with pinion height adjusting shim and rear bearing cone fitted onto it.


CAUTION:

- Re-use the used washer if not deformed.
- Use a new rear bearing cone.

- (5) Then install preload adjusting spacer and washer, front bearing cone, ST2, companion flange, and washer and self-locking nut.

ST1 498447150 DUMMY SHAFT

ST2 32285AA000 DUMMY COLLAR



- (A) Pinion height adjusting shim
- (B) Preload adjusting spacer
- (C) Preload adjusting washer

- (6) Turn ST1 with hand to make it seated, and tighten drive pinion nut while measuring the preload with spring balance. Select preload adjusting washer and spacer so that the specified preload is obtained when nut is tightened to the specified torque.

CAUTION:

Use a new self-locking nut.

NOTE:


- Be careful not to give excessive preload.
- When tightening the drive pinion nut, lock ST1 with ST2 as shown in the figure.

ST1 398507704 BLOCK

ST2 498447150 DUMMY SHAFT

Tightening torque:


188 N·m (19.2 kgf·m, 139 ft·lb)



REAR DIFFERENTIAL FOR VA-TYPE

DIFFERENTIALS

Front and rear bearing preload
 For new bearing:
 12.7 — 32.4 N (1.3 — 3.3 kgf, 2.9 — 7.3 lb)
 at companion flange bolt hole



	Part No.	Thickness mm (in)
Preload adjusting washer	38336AA000	1.500 (0.0591)
	38336AA120	1.513 (0.0596)
	38336AA010	1.525 (0.0600)
	38336AA130	1.538 (0.0606)
	38336AA020	1.550 (0.0610)
	38336AA140	1.563 (0.0615)
	38336AA030	1.575 (0.0620)
	38336AA150	1.588 (0.0625)
	38336AA040	1.600 (0.0630)
	38336AA160	1.613 (0.0635)
	38336AA050	1.625 (0.0640)
	38336AA170	1.638 (0.0645)
	38336AA060	1.650 (0.0650)
	38336AA180	1.663 (0.0655)
	38336AA070	1.675 (0.0659)
	38336AA190	1.688 (0.0665)
	38336AA080	1.700 (0.0669)
	38336AA200	1.713 (0.0674)
	38336AA090	1.725 (0.0679)
	38336AA210	1.738 (0.0684)
38336AA100	1.750 (0.0689)	
38336AA220	1.763 (0.0694)	
38336AA110	1.775 (0.0699)	
Preload adjusting spacer	Part No.	Length mm (in)
	32288AA040	52.3 (2.059)
	32288AA050	52.5 (2.067)
	31454AA100	52.6 (2.071)
	32288AA060	52.7 (2.075)
	31454AA110	52.8 (2.079)
	32288AA070	52.9 (2.083)
	31454AA120	53.0 (2.087)
	32288AA080	53.1 (2.091)
32288AA090	53.3 (2.098)	

REAR DIFFERENTIAL FOR VA-TYPE

DIFFERENTIALS

3) Adjusting drive pinion height

Adjust drive pinion height with shim installed between rear bearing cone and the back of pinion gear.

- (1) Install ST1, ST2 and ST3, as shown in the figure, and apply the specified preload on the bearings


Front and rear bearing preload
For new bearing: 12.7 — 32.4 N (1.3 — 3.3 kgf, 2.9 — 7.3 lb) at companion flange bolt hole

Adjusting preload for front and rear bearings

NOTE:

At this time, install an original pinion height adjusting shim.

ST1	498447150	DUMMY SHAFT
ST2	32285AA000	DUMMY COLLAR
ST3	498505501	DIFFERENTIAL CARRIER GAUGE




(A) Pinion height adjusting shim

- (2) Measure the clearance N between the end of ST3 and the end surface of ST1 by using a thickness gauge.

NOTE:

Make sure there is no clearance between the case and ST3.

ST1	498447150	DUMMY SHAFT
ST2	498505501	DIFFERENTIAL CARRIER GAUGE



- (3) Obtain the thickness of pinion height adjusting washer to be inserted from the following formula, and replace the temporarily installed shim with this one.

NOTE:

Use 1 to 3 shims as required for adjustment.

$$T = To + N - 0.05 \text{ (mm)}$$

where

T = Thickness of pinion height adjusting shim (mm)

To = Thickness of shim originally installed (mm)

N = Reading of thickness gauge (mm)

H = Figure marked on drive pinion head

(Example of calculation)

$$To = 0.15 \text{ mm}$$

$$N = 0.1 \text{ mm}$$

$$T = 0.15 + 0.1 - 0.05 = 0.2 \text{ mm}$$


Result: Thickness = 0.2 mm

Therefore use the 32295AA220.

Pinion height adjusting shim	
Part No.	Thickness mm (in)
32295AA200	0.150 (0.0059)
32295AA210	0.175 (0.0069)
32295AA220	0.200 (0.0079)
32295AA230	0.225 (0.0089)
32295AA240	0.250 (0.0098)
32295AA250	0.275 (0.0108)


- 4) Install the selected pinion height adjusting shim on drive pinion, and press the rear bearing cone into position with ST.

ST 498175500 INSTALLER



REAR DIFFERENTIAL FOR VA-TYPE


5) Insert drive pinion into differential carrier, install the previously selected bearing preload adjusting spacer and washer.



- (A) Drive pinion
- (B) Bearing preload adjusting spacer
- (C) Bearing preload adjusting washer
- (D) Differential carrier


6) Press-fit front bearing cone into carrier with ST1, ST2 and ST3.

- ST1 32285AA000 DUMMY COLLAR
- ST2 399780104 WEIGHT
- ST3 899580100 INSTALLER



7) Insert spacer, then press-fit pilot bearing with ST1 and ST2.

- ST1 399780104 WEIGHT
- ST2 899580100 INSTALLER




8) Fit a new oil seal with ST.

NOTE:

- Press-fit until end of oil seal is 1 mm (0.04 in) inward from end of carrier.
- Apply grease between the oil seal lips.

- ST 498447120 DRIFT




9) Press-fit companion flange with ST1 and ST2.

CAUTION:

Be careful not to damage bearing.


- ST1 899874100 INSTALLER
- ST2 399780104 WEIGHT



10) Install self-locking nut. Then tighten it with ST.

Tightening torque:

188 N·m (19.2 kgf·m, 139 ft·lb)




REAR DIFFERENTIAL FOR VA-TYPE

DIFFERENTIALS

11) Assembling differential case
Install side gears and pinion mate gears, with their thrust washers and pinion mate shaft, into differential case.


NOTE:

- Apply gear oil on both sides of the washer and on the side gear shaft before installing.
- Insert the pinion mate shaft into the differential case by aligning the lock pin holes.



(1) Measure the side gear backlash.

Side gear back clearance:
0.05 — 0.15 mm (0.0020 — 0.0059 in)



(2) Adjust the side gear backlash as specified by selecting side gear thrust washer.

Side gear thrust washer	
Part No.	Thickness mm (in)
803135011	0.925 — 0.950 (0.0364 — 0.0374)
803135012	0.950 — 0.975 (0.0374 — 0.0384)
803135013	0.975 — 1.000 (0.0384 — 0.0394)
803135014	1.000 — 1.025 (0.0394 — 0.0404)
803135015	1.025 — 1.050 (0.0404 — 0.0413)

- (3) Check the condition of rotation after applying oil to the gear tooth surfaces and thrust surfaces.
- (4) After driving in pinion shaft lock pin, stake the both sides of the hole to prevent pin from falling off.
- (5) Install crown gear on differential case.

CAUTION:

Before installing bolts, apply Lock Tite to bolt threads.

Lock Tite


THREE BOND 1324 or equivalent

NOTE:

Tighten diagonally while tapping the bolt heads.


Tightening torque:

62 N·m (6.3 kgf·m, 45.6 ft·lb)



12) Press side bearing cone onto differential case with ST.


ST 498485400 DRIFT



13) Assemble holders.

(1) Install oil seal into right and left holders.


ST 498447100 DRIFT




REAR DIFFERENTIAL FOR VA-TYPE

(2) Install bearing race into right and left holders.

ST 398477702 BEARING OUTER RACE DRIFT




(3) Install the differential case assembly into differential carrier in the reverse order of disassembly.



14) Perform adjustment of backlash of pinion crown gear set and adjustment of preload of differential side bearing.


(1) Turn drive pinion with ST for better fitting of differential side bearing.

ST 498427200 FLANGE WRENCH



(2) Screw in side (left-side) holder until light contact is made with ST.

ST 499785500 WRENCH



(3) Back off side (left-side) holder approximately 1 1/2 teeth of holder, and tighten left-side holder by approximately 2 teeth (approximately 1 1/2 + 1/2 teeth).


[Back off amount of side (left-side) holder + 1/2 tooth.]

This + 1/2 tooth gives preload.

(4) Temporarily tighten lock plate.

NOTE:

Turn over lock plate to displace holder 1/2 tooth.



(5) Measure the crown gear-to-drive pinion backlash. Set magnet base on differential carrier. Align contact point of dial gauge with tooth face of crown gear, and move crown gear while holding drive pinion still. Read value indicated on dial gauge.

NOTE:


If measured backlash is not within specified range, repeat procedures for pinion crown gear set backlash adjustment and differential side bearing preload adjustment.

REAR DIFFERENTIAL FOR VA-TYPE


DIFFERENTIALS

Backlash:

0.10 — 0.15 mm (0.0039 — 0.0059 in)



15) Draw a matching mark on both differential carrier and holder. Remove holder one side at a time. Replace in the original position after inserting an O-ring and applying grease to threaded portion.




- (A) Matching mark
- (B) Holder

16) Tighten bolt of lock plate to specified torque.

Tightening torque:


25 N·m (2.5 kgf·m, 18.1 ft·lb)



17) Re-check crown gear-to-pinion backlash.

Backlash:


0.10 — 0.15 mm (0.0039 — 0.0059 in)



18) Check the crown gear runout on its back surface, and make sure pinion and crown gear rotate smoothly.

Limit of runout:

0.05 mm (0.0020 in)



19) Checking and adjusting tooth contact of crown gear.

- (1) Apply an even coat of red lead on both sides of three or four teeth on the crown gear. Check the contact pattern after rotating crown gear several revolutions back and forth until a definite contact pattern appears on the crown gear.
- (2) When the contact pattern is incorrect, readjust according to the instructions given in "TOOTH CONTACT PATTERN".


NOTE:

Be sure to wipe off red lead completely after adjustment is completed.

20) If proper tooth contact is not obtained, once again adjust the drive pinion height and the differential side bearing preload (already mentioned) and the hypoid gear backlash.

(1) Drive pinion height

- ST1 498447150 DUMMY SHAFT
- ST2 498505501 DIFFERENTIAL GAUGE



$$T = T_o + N - 0.05 \text{ (mm)}$$

where

T = Thickness of pinion height adjusting shim (mm)

T_o = Thickness of shim originally installed (mm)

N = Reading of thickness gauge (mm)

(2) Differential side bearing preload


Screw in side (left-side) holder until light contact is made with ST.

Back off side (left-side) holder approximately 1 1/2 teeth of holder, and tighten left-side holder by approximately 2 teeth (approximately 1 1/2 + 1/2 teeth).

[Back off amount of side (left-side) holder + 1/2 tooth.]

This + 1/2 tooth gives preload.


- ST 499785500 WRENCH



(3) Hypoid gear backlash










Backlash:



0.10 — 0.15 mm (0.0039 — 0.0059 in)



REAR DIFFERENTIAL FOR VA-TYPE

DIFFERENTIALS


TOOTH CONTACT PATTERN		
Condition	Contact pattern	Adjustment
<p>Correct tooth contact Tooth contact pattern slightly shifted towards toe under no load rotation. (When loaded, contact pattern moves toward heel.)</p>	 <p style="text-align: right;">G3M0098A</p>	<p style="text-align: center;">—</p>
<p>Face contact Backlash is too large.</p>	<p>This may cause noise and chipping at tooth ends.</p>  <p style="text-align: right;">G3M0098B</p>	<p>Increase thickness of drive pinion height adjusting washer in order to bring drive pinion closer to crown gear center.</p>  <p style="text-align: right;">G3M0098F</p>
<p>F flank contact Backlash is too small.</p>	<p>This may cause noise and stepped wear on surfaces.</p>  <p style="text-align: right;">G3M0098C</p>	<p>Reduce thickness of drive pinion height adjusting washer in order to move drive pinion away from crown gear center.</p>  <p style="text-align: right;">G3M0098G</p>
<p>Toe contact</p>	<p>Contact area is small. This may cause chipping at toe ends.</p>  <p style="text-align: right;">G3M0098D</p>	<p>Adjust as for flank contact.</p>  <p style="text-align: right;">G3M0098G</p>
<p>Heel contact</p>	<p>Contact area is small. This may cause chipping at heel ends.</p>  <p style="text-align: right;">G3M0098E</p>	<p>Adjust as for face contact.</p>  <p style="text-align: right;">G3M0098F</p>

 : Adjusting direction of drive pinion
 : Adjusting direction of crown gear

21) Install rear cover and tighten bolts to specified torque.

Tightening torque:

25 N·m (2.5 kgf-m, 18.1 ft-lb)



(A) Rear cover

E: INSPECTION

Wash all the disassembled parts clean, and examine them for wear, damage, or other defects. Repair or replace defective parts as necessary.

1) Crown gear and drive pinion

- If abnormal tooth contact is evident, find out the cause and adjust to give correct tooth contact at assembly. Replace the gear if excessively worn or incapable of adjustment.
- If crack, score, or seizure is evident, replace as a set. Slight damage of tooth can be corrected by oil stone or the like.

2) Side gear and pinion mate gear

- Replace if crack, score, or other defects are evident on tooth surface.
- Replace if thrust washer contacting surface is worn or seized. Slight damage of the surface can be corrected by oil stone or the like.

3) Bearing

Replace if seizure, peeling, wear, rust, dragging during rotation, abnormal noise or other defect is evident.

4) Thrust washers of side gear and pinion mate gear

Replace if seizure, flaw, abnormal wear or other defect is evident.

5) Oil seal

Replace if deformed or damaged, and at every disassembling.

6) Differential carrier

Replace if the bearing bores are worn or damaged.

7) Differential case

Replace if its sliding surfaces are worn or cracked.

8) Companion flange

Replace if the oil seal lip contacting surfaces have flaws.


1. SIDE GEAR BACKLASH

Using a dial gauge, check the backlash of the side gear.

Side gear backlash:

0.05 — 0.15 mm (0.0020 — 0.0059 in)

If side gear backlash is not within the specification, adjust clearance as specified by selecting side gear thrust washer.




2. CROWN GEAR BACKLASH

Using a dial gauge, check the backlash of the crown gear.

Crown gear backlash:

0.10 — 0.15 mm (0.0039 — 0.0059 in)

If crown gear backlash is not within the specification, adjust the side bearing preload or repair if necessary.



REAR DIFFERENTIAL FOR VA-TYPE

DIFFERENTIALS


3. CROWN GEAR RUNOUT

Using a dial gauge, check the crown gear runout.

Crown gear runout:

Less than 0.05 mm (0.0020 in)

If the crown gear runout exceeds 0.05 mm (0.0020 in), replace the crown gear.



4. TOOTH CONTACT BETWEEN CROWN GEAR AND DRIVE PINION

Inspect tooth contact between crown gear and drive pinion.

<Ref. to DI-46, ASSEMBLY, Rear Differential for VA-type.>

F: ADJUSTMENT

1. SIDE GEAR BACKLASH

Adjust side gear backlash.

<Ref. to DI-46, ASSEMBLY, Rear Differential for VA-type.>

2. CROWN GEAR BACKLASH

Adjust crown gear backlash.

<Ref. to DI-46, ASSEMBLY, Rear Differential for VA-type.>

3. TOOTH CONTACT BETWEEN CROWN GEAR AND DRIVE PINION


Adjust the tooth contact between crown gear and drive pinion gear.

<Ref. to DI-46, ASSEMBLY, Rear Differential for VA-type.>

6. Rear Differential Front Oil Seal

A: REPLACEMENT

- 1) Set the vehicle on the lift.
- 2) Disconnect ground cable from battery.
- 3) Move select lever or gear shift lever to "N".
- 4) Release the parking brake.
- 5) Remove oil drain plug, and drain gear oil.



- (A) Filler plug
- (B) Drain plug

- 6) Install oil drain plug.

NOTE:

- Apply fluid packing to drain plug in T-type.
- VA-type uses a new aluminum gasket.

Tightening torque:

T-type;

49 N·m (5.0 kgf-m, 36.2 ft-lb)


VA-type;

33 N·m (3.4 kgf-m, 24.6 ft-lb)

- 7) Jack-up rear wheels and support the vehicle body with sturdy racks.


- 8) Remove rear exhaust pipe and muffler.

- 9) Remove propeller shaft from body. <Ref. to DS-16, REMOVAL, Propeller Shaft.>




- 10) Remove self-locking nut while holding companion flange with ST.

ST 498427200 FLANGE WRENCH




- 11) Remove tank cover.




- 12) Extract companion flange using ST.

ST 399703602 PULLEY ASSY



- 13) Remove oil seal using ST.


ST 499705401 PULLER ASSY



REAR DIFFERENTIAL FRONT OIL SEAL

DIFFERENTIALS

- 14) Fit a new oil seal using ST.
ST 498447120 DRIFT



- 15) Install companion flange.

NOTE:

Use a plastic hammer to install companion flange.

- 16) Tighten self-locking nut within the specified torque range so that the turning resistance of companion flange becomes the same as that before replacing oil seal.


ST 498427200 FLANGE WRENCH

NOTE:

Use a new self-locking nut.

Tightening torque:

181.4 N·m (18.50 kgf·m, 133.8 ft·lb)



- 17) Reassembling procedure hereafter is the reverse of the disassembling.

7. Rear Differential Side Oil Seal

A: REPLACEMENT

1. T-TYPE

- 1) Disconnect ground terminal from battery.
- 2) Move select lever or gear shift lever to "N".
- 3) Release the parking brake.
- 4) Loosen both wheel nuts.
- 5) Jack-up the vehicle and support it with rigid racks.
- 6) Remove wheels.
- 7) Remove rear exhaust pipe and muffler.

Non-turbo model without OBD

<Ref. to EX(SOHCw/oOBD)-13, REMOVAL, Rear Exhaust Pipe.> and <Ref. to EX(SOHCw/oOBD)-14, REMOVAL, Muffler.>

Non-turbo model with OBD


<Ref. to EX(SOHC)-11, REMOVAL, Rear Exhaust Pipe.> and <Ref. to EX(SOHC)-12, REMOVAL, Muffler.>

Turbo model


<Ref. to EX(DOHC TURBO)-13, REMOVAL, Rear Exhaust Pipe.> and <Ref. to EX(DOHC TURBO)-14, REMOVAL, Muffler.>

- 8) Remove the DOJ of rear drive shaft from rear differential.


- (1) Remove the ABS sensor cable clamp and parking brake cable clamp from bracket.




- (2) Remove the ABS sensor cable clamp from the trailing link.




- (3) Remove the ABS sensor cable clamp and parking brake cable guide from the trailing link.




- (4) Remove the rear stabilizer link.



- (5) Remove the bolts which secure the trailing link to the housing.



- (6) Remove the bolts which secure the front and rear lateral link to the rear housing.



REAR DIFFERENTIAL SIDE OIL SEAL


DIFFERENTIALS

(7) Remove the DOJ from the rear differential by using ST.

CAUTION:


When removing the DOJ from the rear differential, fit ST to the bolts as shown in figure so as not to damage the side bearing retainer.

ST 208099PA100 DRIVE SHAFT REMOVER




(A) Bolt

9) Remove rear drive shaft to rear crossmember using wire.



10) Remove nut of protector.

ST 398527700 PULLER ASSY




11) Drive in a new side oil seal with ST.

CAUTION:

Apply chassis grease between the oil seal lips.


ST 398437700 DRIFT



12) Insert the DOJ into rear differential.


(1) Install ST to rear differential.

ST 28099PA090 SIDE OIL SEAL PROTECTOR



(2) Install the spline shaft until the spline portion is inside the side oil seal using ST.

ST 28099PA090 SIDE OIL SEAL PROTECTOR



(3) Remove ST.
ST 28099PA090 SIDE OIL SEAL PROTECTOR

13) Hereafter, re-assemble in reverse order of disassembly.

2. VA-TYPE

- 1) Disconnect ground terminal from battery.
- 2) Move select lever or gear shift lever to "N".
- 3) Release the parking brake.
- 4) Loosen both wheel nuts.
- 5) Jack-up the vehicle and support it with rigid racks.

6) Remove wheels.

7) Remove rear exhaust pipe and muffler.

Non-turbo model without OBD

<Ref. to EX(SOHCw/oOBD)-13, REMOVAL, Rear Exhaust Pipe.> and <Ref. to EX(SOHCw/oOBD)-14, REMOVAL, Muffler.>

Non-turbo model with OBD


<Ref. to EX(SOHC)-11, REMOVAL, Rear Exhaust Pipe.> and <Ref. to EX(SOHC)-12, REMOVAL, Muffler.>

Turbo model


<Ref. to EX(DOHC TURBO)-13, REMOVAL, Rear Exhaust Pipe.> and <Ref. to EX(DOHC TURBO)-14, REMOVAL, Muffler.>

8) Remove the DOJ of rear drive shaft from rear differential.


- (1) Remove the ABS sensor cable clamp and parking brake cable clamp from bracket.




- (2) Remove the ABS sensor cable clamp from the trailing link.




- (3) Remove the ABS sensor cable clamp and parking brake cable guide from the trailing link.




- (4) Remove the rear stabilizer link.



- (5) Remove the bolts which secure the trailing link to the housing.



- (6) Remove the bolts which secure the front and rear lateral link to the rear housing.



- (7) Remove the DOJ from the rear differential with tire lever.

CAUTION:



When removing the DOJ from the rear differential, fit tire lever to the bolt as shown in figure so as not to damage the axle shaft holder.

REAR DIFFERENTIAL SIDE OIL SEAL


DIFFERENTIALS

NOTE:


The side spline shaft circlip comes out together with the shaft.



9) Secure rear drive shaft to rear crossmember using wire.



10) Remove oil seal with screwdriver.




11) Drive in a new side oil seal with ST.

CAUTION:

Apply chassis grease between the oil seal lips.

ST 498447100 OIL SEAL INSTALLER




12) Insert the DOJ into rear differential.

CAUTION:


Before inserting, replace the circlip at the end of the spline shaft with a new one.

(1) Install ST to rear differential.

ST 28099PA090 SIDE OIL SEAL PROTECTOR



(2) Install the spline shaft until the spline portion is inside the side oil seal.




(3) Remove ST.

ST 28099PA090 SIDE OIL SEAL PROTECTOR

(4) Completely insert DOJ into rear differential by pressing rear housing.

NOTE:

Make sure that oil seal lip is not folded over inward.



13) Hereafter, re-assemble in reverse order of disassembly.

REAR DIFFERENTIAL MEMBER

DIFFERENTIALS

8. Rear Differential Member

A: REMOVAL

- 1) Set the vehicle on the lift.
- 2) Disconnect ground terminal from battery.
- 3) Move selector lever or gear shift lever to "N".
- 4) Release the parking brake.
- 5) Loosen wheel nuts.
- 6) Jack-up vehicle and support it with study racks.
- 7) Remove wheels.
- 8) Remove rear exhaust pipe and muffler.

Non-turbo model without OBD

<Ref. to EX(SOHCw/oOBD)-13, REMOVAL, Rear Exhaust Pipe.> and <Ref. to EX(SOHCw/oOBD)-14, REMOVAL, Muffler.>

Non-turbo model with OBD

<Ref. to EX(SOHC)-11, REMOVAL, Rear Exhaust Pipe.> and <Ref. to EX(SOHC)-12, REMOVAL, Muffler.>

Turbo model

<Ref. to EX(DOHC TURBO)-13, REMOVAL, Rear Exhaust Pipe.> and <Ref. to EX(DOHC TURBO)-14, REMOVAL, Muffler.>

- 9) Remove rear differential front member.

NOTE:

When removing rear differential front member, work the removal procedure as rear differential.

T-type

<Ref. to DI-25, REMOVAL, Rear Differential for T-type.>

VA-type

<Ref. to DI-40, REMOVAL, Rear Differential for VA-type.>

- 10) Remove differential rear member.


B: INSTALLATION

To install, reverse the removal sequence.

- 1) Position front member on body by passing it under parking brake cable and securing to rear differential.

NOTE:

When installing rear differential front member, do not confuse the installation sequence of the stopper.




- 2) Insert DOJ of rear drive shaft into rear differential. <Ref. to DI-59, REPLACEMENT, Rear Differential Side Oil Seal.>

CAUTION:

Before inserting, replace the differential side oil seal with a new one.

ST 28099PA090 SIDE OIL SEAL PROTECTOR



- 3) Installing procedure hereafter is in the reverse order of removal.

C: INSPECTION

- 1) Check rear differential member for damage, bend, or corrosion.
If damage, bend, or corrosion is excessive, replace rear differential member.
- 2) Check bushings of rear differential member for cracking, hardening, or damage.
If cracking, hardening, or damage is excessive, replace rear differential member.

9. General Diagnostic Table

A: INSPECTION

Symptom or trouble	Possible cause	Remedy
1. Oil leakage	(1) Worn, scratched, or incorrectly seated front or side oil seal. Scored, battered, or excessively worn sliding surface of companion flange.	Repair or replace.
	(2) Clogged or damaged air breather.	Clean, repair or replace.
	(3) Loose bolts on differential spindle or side retainer, or incorrectly fitted O-ring.	Tighten bolts to specified torque. Replace O-ring.
	(4) Loose rear cover attaching bolts or damaged gasket.	Tighten bolts to specified torque. Replace gasket and apply liquid packing.
	(5) Loose oil filler or drain plug.	Retighten and apply liquid packing.
	(6) Wear, damage or incorrectly fitting for spindle, side retainer and oil seal.	Repair or replace.
2. Seizure NOTE: Seized or damaged parts should be replaced, and also other parts should be thoroughly checked for any defect and should be repaired or replaced as required.	(1) Insufficient backlash for hypoid gear.	Readjust or replace.
	(2) Excessive preload for side, rear, or front bearing.	Readjust or replace.
	(3) Insufficient or improper oil used.	Replace seized part and fill with specified oil to specified level.
3. Damage NOTE: Damaged parts should be replaced, and also other parts should be thoroughly checked for any defect and should be repaired or replaced as required.	(1) Improper backlash for hypoid gear.	Replace.
	(2) Insufficient or excessive preload for side, rear, or front bearing.	Readjust or replace.
	(3) Excessive backlash for differential gear.	Replace gear or thrust washer.
	(4) Loose bolts and nuts such as crown gear bolt.	Retighten.
	(5) Damage due to overloading.	Replace.
4. Noises when starting or shifting gears NOTE: Noises may be caused by differential assembly, universal joint, wheel bearing, etc. Find out what is actually making noise before disassembly.	(1) Excessive backlash for hypoid gear.	Readjust.
	(2) Excessive backlash for differential gear.	Replace gear or thrust washer.
	(3) Insufficient preload for front or rear bearing.	Readjust.
	(4) Loose drive pinion nut.	Tighten to specified torque.
	(5) Loose bolts and nuts such as side bearing retainer attaching bolt.	Tighten to specified torque.
5. Noises when cornering	(1) Damaged differential gear.	Replace.
	(2) Excessive wear or damage of thrust washer.	Replace.
	(3) Broken pinion mate shaft.	Replace.
	(4) Seized or damaged side bearing.	Replace.

GENERAL DIAGNOSTIC TABLE

DIFFERENTIALS

Symptom or trouble	Possible cause	Remedy
6. Gear noises NOTE: Since noises from engine, muffler, transmission, propeller shaft, wheel bearings, tires, and body are sometimes mistaken for noises from differential assembly, be careful in checking them. Inspection methods to locate noises include coasting, accelerating, cruising, and jacking-up all four wheels. Perform these inspections according to condition of trouble. When listening to noises, shift gears into four wheel drive and fourth speed position, trying to pick up only differential noise.	(1) Improper tooth contact of hypoid gear.	Readjust or replace hypoid gear set.
	(2) Improper backlash for hypoid gear.	Readjust.
	(3) Scored or chipped teeth of hypoid gear.	Replace hypoid gear set.
	(4) Seized hypoid gear.	Replace hypoid gear set.
	(5) Improper preload for front or rear bearings.	Readjust.
	(6) Seized, scored, or chipped front or rear bearing.	Replace.
	(7) Seized, scored, or chipped side bearing.	Replace.
	(8) Vibrating differential carrier.	Replace.