

**ENGINE SECTION 3**

This service manual has been prepared to provide SUBARU service personnel with the necessary information and data for the correct maintenance and repair of SUBARU vehicles.

This manual includes the procedures for maintenance, disassembling, reassembling, inspection and adjustment of components and diagnostics for guidance of experienced mechanics.

Please peruse and utilize this manual fully to ensure complete repair work for satisfying our customers by keeping their vehicle in optimum condition. When replacement of parts during repair work is needed, be sure to use SUBARU genuine parts.

All information, illustration and specifications contained in this manual are based on the latest product information available at the time of publication approval.

**FUEL INJECTION (FUEL SYSTEMS) FU(H6DO)**

**EMISSION CONTROL  
(AUX. EMISSION CONTROL DEVICES) EC(H6DO)**

**INTAKE (INDUCTION) IN(H6DO)**

**MECHANICAL ME(H6DO)**

**EXHAUST EX(H6DO)**

**COOLING CO(H6DO)**

**LUBRICATION LU(H6DO)**

**SPEED CONTROL SYSTEMS SP(H6DO)**

**IGNITION IG(H6DO)**

**STARTING/CHARGING SYSTEMS SC(H6DO)**

**ENGINE (DIAGNOSTICS) EN(H6DO)(diag)**

# ENGINE (DIAGNOSTICS)

# *EN(H6DO)(diag)*

---

	Page
1. Basic Diagnostic Procedure .....	2
2. Check List for Interview .....	3
3. General Description .....	5
4. Electrical Component Location .....	8
5. Engine Control Module (ECM) I/O Signal .....	17
6. Engine Condition Data .....	21
7. Data Link Connector .....	22
8. OBD-II General Scan Tool .....	23
9. Subaru Select Monitor .....	25
10. Read Diagnostic Trouble Code (DTC) .....	32
11. Inspection Mode .....	33
12. Drive Cycle .....	38
13. Clear Memory Mode .....	40
14. Compulsory Valve Operation Check Mode .....	41
15. Malfunction Indicator Light .....	43
16. Diagnostics for Engine Starting Failure .....	52
17. List of Diagnostic Trouble Code (DTC) .....	66
18. Diagnostic Procedure with Diagnostic Trouble Code (DTC) .....	72
19. General Diagnostic Table .....	265

# Basic Diagnostic Procedure

ENGINE (DIAGNOSTICS)

## 1. Basic Diagnostic Procedure

### A: PROCEDURE

#### 1. ENGINE

Step	Check	Yes	No
<b>1 CHECK ENGINE START FAILURE.</b> 1) Ask the customer when and how the trouble occurred using the interview check list. <Ref. to EN(H6DO)(diag)-3, CHECK, Check List for Interview.> 2) Start the engine.	Does the engine start?	Go to step 2.	Inspection using "Diagnostics for Engine Start Failure". <Ref. to EN(H6DO)(diag)-52, Diagnostics for Engine Starting Failure.>
<b>2 CHECK ILLUMINATION OF MALFUNCTION INDICATOR LIGHT.</b>	Does check malfunction indicator light illuminate?	Go to step 3.	Inspection using "General Diagnostic Table". <Ref. to EN(H6DO)(diag)-265, INSPECTION, General Diagnostic Table.>
<b>3 CHECK INDICATION OF DTC ON DISPLAY.</b> 1) Turn the ignition switch to OFF. 2) Connect the Subaru Select Monitor to data link connector. 3) Turn the ignition switch to ON, and the Subaru Select Monitor switch to ON. 4) Read DTC on Subaru Select Monitor.	Is DTC displayed on the Subaru Select Monitor?	Record the DTC. Repair the trouble cause. <Ref. to EN(H6DO)(diag)-66, List of Diagnostic Trouble Code (DTC).> Go to step 4.	Repair the related parts. NOTE: If DTC is not shown on display although the malfunction indicator light illuminates, perform the diagnostics of malfunction indicator light circuit or combination meter. <Ref. to EN(H6DO)(diag)-43, Malfunction Indicator Light.>
<b>4 PERFORM THE DIAGNOSIS.</b> 1) Perform clear memory mode. <Ref. to EN(H6DO)(diag)-40, Clear Memory Mode.> 2) Perform the inspection mode. <Ref. to EN(H6DO)(diag)-33, Inspection Mode.>	Is DTC displayed on the Subaru Select Monitor?	Check on "Diagnostic Procedure with Diagnostic Trouble Code (DTC)" <Ref. to EN(H6DO)(diag)-72, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>	Finish the diagnosis.

# Check List for Interview

ENGINE (DIAGNOSTICS)

## 2. Check List for Interview

### A: CHECK

#### 1. CHECK LIST No. 1

Check the following items when problem has occurred.

NOTE:

Use copies of this page for interviewing customers.

Customer's name		Engine No.	
Date of sale		Fuel brand	
Date of repair		Odometer reading	km
V.I.N.			miles
Weather	<input type="checkbox"/> Fine <input type="checkbox"/> Cloudy <input type="checkbox"/> Rainy <input type="checkbox"/> Snowy <input type="checkbox"/> Various/Others:		
Ambient air temperature	°C (°F)		
	<input type="checkbox"/> Hot <input type="checkbox"/> Warm <input type="checkbox"/> Cool <input type="checkbox"/> Cold		
Place	<input type="checkbox"/> Highway <input type="checkbox"/> Suburbs <input type="checkbox"/> Inner city <input type="checkbox"/> Uphill <input type="checkbox"/> Downhill <input type="checkbox"/> Rough road <input type="checkbox"/> Others:		
Engine temperature	<input type="checkbox"/> Cold <input type="checkbox"/> Warming-up <input type="checkbox"/> After warming-up <input type="checkbox"/> Any temperature <input type="checkbox"/> Others:		
Engine speed	rpm		
Vehicle speed	km/h (MPH)		
Driving conditions	<input type="checkbox"/> Not affected <input type="checkbox"/> At starting <input type="checkbox"/> While idling <input type="checkbox"/> At racing <input type="checkbox"/> While accelerating <input type="checkbox"/> While cruising <input type="checkbox"/> While decelerating <input type="checkbox"/> While turning (RH/LH)		
Headlight	<input type="checkbox"/> ON / <input type="checkbox"/> OFF	Rear defogger	<input type="checkbox"/> ON / <input type="checkbox"/> OFF
Blower	<input type="checkbox"/> ON / <input type="checkbox"/> OFF	Audio	<input type="checkbox"/> ON / <input type="checkbox"/> OFF
A/C compressor	<input type="checkbox"/> ON / <input type="checkbox"/> OFF	Car phone	<input type="checkbox"/> ON / <input type="checkbox"/> OFF
Radiator fan	<input type="checkbox"/> ON / <input type="checkbox"/> OFF		
Front wiper	<input type="checkbox"/> ON / <input type="checkbox"/> OFF		
Rear wiper	<input type="checkbox"/> ON / <input type="checkbox"/> OFF		

# Check List for Interview

ENGINE (DIAGNOSTICS)

## 2. CHECK LIST No. 2

Check the following items about the vehicle's state when malfunction indicator light turns on.

NOTE:

Use copies of this page for interviewing customers.

a) Other warning lights or indicators turn on. <input type="checkbox"/> Yes / <input type="checkbox"/> No
<input type="checkbox"/> Low fuel warning light <input type="checkbox"/> Charge indicator light <input type="checkbox"/> AT diagnostic indicator light <input type="checkbox"/> ABS warning light <input type="checkbox"/> Oil pressure indicator light
b) Fuel level
<ul style="list-style-type: none"><li>• Lack of gasoline: <input type="checkbox"/> Yes / <input type="checkbox"/> No</li><li>• Indicator position of fuel gauge:</li><li>• Experienced running out of fuel: <input type="checkbox"/> Yes / <input type="checkbox"/> No</li></ul>
c) Intentional connecting or disconnecting of harness connectors or spark plug cords: <input type="checkbox"/> Yes / <input type="checkbox"/> No
<ul style="list-style-type: none"><li>• What:</li></ul>
d) Intentional connecting or disconnecting of hoses: <input type="checkbox"/> Yes / <input type="checkbox"/> No
<ul style="list-style-type: none"><li>• What:</li></ul>
e) Installing of other parts except genuine parts: <input type="checkbox"/> Yes / <input type="checkbox"/> No
<ul style="list-style-type: none"><li>• What:</li><li>• Where:</li></ul>
f) Occurrence of noise: <input type="checkbox"/> Yes / <input type="checkbox"/> No
<ul style="list-style-type: none"><li>• From where:</li><li>• What kind:</li></ul>
g) Occurrence of smell: <input type="checkbox"/> Yes / <input type="checkbox"/> No
<ul style="list-style-type: none"><li>• From where:</li><li>• What kind:</li></ul>
h) Intrusion of water into engine compartment or passenger compartment: <input type="checkbox"/> Yes / <input type="checkbox"/> No
i) Troubles occurred
<input type="checkbox"/> Engine does not start. <input type="checkbox"/> Engine stalls during idling. <input type="checkbox"/> Engine stalls while driving. <input type="checkbox"/> Engine speed decreases. <input type="checkbox"/> Engine speed does not decrease. <input type="checkbox"/> Rough idling <input type="checkbox"/> Poor acceleration <input type="checkbox"/> Back fire <input type="checkbox"/> After fire <input type="checkbox"/> Does not shift. <input type="checkbox"/> Excessive shift shock

## 3. General Description

### A: CAUTION

1) Airbag system wiring harness is routed near the ECM, main relay and fuel pump relay.

#### CAUTION:

- All air bag system wiring harnesses and connectors are yellow. Do not use the electrical test equipment on these circuits.
- Be careful not to damage the Airbag system wiring harness when servicing the ECM, TCM, main relay and fuel pump relay.

2) Never connect the battery in reverse polarity.

- The ECM will be destroyed instantly.
- The fuel injector and other part will be damaged.

3) Do not disconnect the battery terminals while the engine is running.

A large counter electromotive force will be generated in the generator, and this voltage may damage electronic parts such as ECM, etc.

4) Before disconnecting the connectors of each sensor and the ECM, be sure to turn the ignition switch to OFF. Perform the clear memory mode after connecting the connectors.

5) Poor contact has been identified as a primary cause of this problem. Measure the voltage or resistance of individual sensor or all electrical control modules using a tapered pin with a diameter of less than 0.64 mm (0.025 in). Do not insert the pin more than 5 mm (0.20 in) into the part.

6) Remove the ECM from the located position after disconnecting two cables on battery.


Otherwise, the ECM may be damaged.

#### CAUTION:

**When replacing the ECM, be careful not to use the wrong spec. ECM to avoid any damage on the fuel injection system.**


7) Connectors to each sensor in the engine compartment and the harness connectors on the engine side and body side are all designed to be waterproof. However, it is still necessary to take care not to allow water to get into the connectors when washing the vehicle, or when servicing the vehicle on a rainy day.

8) Use ECM mounting stud bolts as the grounding point to chassis when measuring voltage and resistance inside the passenger compartment.




(A) Stud bolt

9) Use engine grounding terminal or engine proper as the grounding point to chassis when measuring voltage and resistance in the engine compartment.



10) Use TCU mounting stud bolts as the body side grounding point to chassis when measuring voltage and resistance inside the passenger compartment.



(A) Stud bolt

11) Every MFI-related part is a precision part. Do not drop them.

12) Observe the following cautions when installing a radio in MFI equipped models.

#### CAUTION:

- The antenna must be kept as far apart as possible from the control unit. (The ECM is located under the steering column, inside of the instrument panel lower trim panel.)

# General Description

## ENGINE (DIAGNOSTICS)

- The antenna feeder must be placed as far apart as possible from the ECM and MFI harness.
- Carefully adjust the antenna for correct matching.
- When mounting a large power type radio, pay special attention to the three items above mentioned.
- Incorrect installation of the radio may affect the operation of the ECM.

13) Before disconnecting the fuel hose, disconnect the fuel pump connector and crank the engine for more than five seconds to release pressure in the fuel system. If engine starts during this operation, run it until it stops.

14) Problems in the electronic-controlled automatic transmission may be caused by failure of the engine, the electronic control system, the transmission proper, or by a combination of these. These three causes (engine, electrical control system, transmission) must be distinguished clearly when performing diagnostics.

15) Diagnostics should be conducted by rotating with simple, easy operations and proceeding to complicated, difficult operations. The most important thing in diagnostics is to understand the customer's complaint, and distinguish between the three causes (engine, electrical control system, transmission).

16) In AT models, do not continue the stall for more than five seconds at a time. (from closed throttle, fully open throttle to stall speed reading, and then decrease engine speed.).

17) On the model with ABS, when performing driving test in jacked-up or lifted-up position, sometimes the warning light may be lit, but this is not a malfunction of the system. The reason for this is the speed difference between the front and rear wheels. After diagnosis of engine control system, perform the ABS memory clearance procedure of self-diagnosis system.

### B: INSPECTION

Before performing diagnostics, check the following items which might affect engine problems:

#### 1. BATTERY

1) Measure battery voltage and specific gravity of electrolyte.


**Standard voltage: 12 V**

**Specific gravity: Above 1.260**

2) Check the condition of the main and other fuses, and harnesses and connectors. Also check for proper grounding.

#### 2. ENGINE GROUND

Make sure the engine grounding terminal is properly connected to the engine.



### C: NOTE

#### 1. GENERAL DESCRIPTION

- The on-board diagnostics (OBD) system detects and indicates a fault in various inputs and outputs of the complex electronic control. Malfunction indicator light in the combination meter indicates occurrence of a fault or trouble.
- Further, against such a failure or sensors as may disable the drive, the fail-safe function is provided to ensure the minimal driveability.
- The OBD system incorporated with the vehicles within this engine family complies with Section 1968.1, California Code of Regulations (OBD-II regulation). The OBD system monitors the components and the system malfunction listed in Engine Section which affects on emissions.
- When the system decides that a malfunction occurs, malfunction indicator light illuminates. At the same time of the malfunction indicator light illumination or blinking, a diagnostic DTC and a freeze frame engine conditions are stored into on-board computer.
- The OBD system stores freeze frame engine condition data (engine load, engine coolant temperature, fuel trim, engine speed and vehicle speed, etc.) into on-board computer when it detects a malfunction first.
- If the OBD system detects the various malfunctions including the fault of fuel trim or misfire, the OBD system first stores freeze frame engine conditions about the fuel trim or misfire.
- When the malfunction does not occur again for three consecutive driving cycles, malfunction indicator light is turned off, but DTC remains at on-board computer.
- The OBD-II system is capable of communication with a general scan tool (OBD-II general scan tool) formed by ISO 9141 CARB.

# General Description

ENGINE (DIAGNOSTICS)

- The OBD-II diagnostics procedure is different from the usual diagnostics procedure. When troubleshooting OBD-II vehicles, connect Subaru Select Monitor or the OBD-II general scan tool to the vehicle.

## 2. ENGINE AND EMISSION CONTROL SYSTEM

- The Multipoint Fuel Injection (MFI) system is a system that supplies the optimum air-fuel mixture to the engine for all the various operating conditions through the use of the latest electronic technology.

With this system fuel, which is pressurized at a constant pressure, is injected into the intake air passage of the cylinder head. The injection quantity of fuel is controlled by an intermittent injection system where the electro-magnetic injection valve (fuel injector) opens only for a short period of time, de-



pending on the quantity of air required for one cycle of operation. In actual operation, the injection quantity is determined by the duration of an electric pulse applied to the fuel injector and this permits simple, yet highly precise metering of the fuel.

- Further, all the operating conditions of the engine are converted into electric signals, and this results in additional features of the system, such as large improved adaptability, easier addition of compensating element, etc.

The MFI system also has the following features:

- Reduced emission of harmful exhaust gases.
- Reduced in fuel consumption.
- Increased engine output.
- Superior acceleration and deceleration.
- Superior startability and warm-up performance in cold weather since compensation is made for coolant and intake air temperature.

## D: PREPARATION TOOL

ILLUSTRATION	TOOL NUMBER	DESCRIPTION	REMARKS
 <p>ST24082AA230</p>	24082AA230	CARTRIDGE	Troubleshooting for electrical system.
 <p>ST22771AA030</p>	22771AA030	SUBARU SELECT MONITOR KIT	Troubleshooting for electrical system. <ul style="list-style-type: none"> <li>• English: 22771AA030 (Without printer)</li> <li>• German: 22771AA070 (Without printer)</li> <li>• French: 22771AA080 (Without printer)</li> <li>• Spanish: 22771AA090 (Without printer)</li> </ul>



# Electrical Component Location


ENGINE (DIAGNOSTICS)

## 4. Electrical Component Location

### A: LOCATION


#### 1. ENGINE

- Control module
  - LHD model



EN-02474

- RHD model







EN-02475

- |                                 |                         |                         |
|---------------------------------|-------------------------|-------------------------|
| (1) Engine control module (ECM) | (3) Test mode connector | (4) Data link connector |
| (2) Malfunction indicator light |                         |                         |

# Electrical Component Location


ENGINE (DIAGNOSTICS)



# Electrical Component Location

## ENGINE (DIAGNOSTICS)

- Sensor










EN-02478

- |   |                                       |                                |
|---|---------------------------------------|--------------------------------|
| (1) Mass air flow and intake air temperature sensor | (3) Engine coolant temperature sensor | (6) Camshaft position sensor   |
| (2) Manifold absolute pressure sensor               | (4) Electronic throttle control       | (7) Crankshaft position sensor |
|   | (5) Knock sensor                      | (8) Oil temperature sensor     |


# Electrical Component Location

ENGINE (DIAGNOSTICS)







# Electrical Component Location

ENGINE (DIAGNOSTICS)




- |                                  |                                  |                              |
|----------------------------------|----------------------------------|------------------------------|
| (1) Front oxygen (A/F) sensor LH | (4) Rear oxygen sensor RH        | (7) Rear catalytic converter |
| (2) Front oxygen (A/F) sensor RH | (5) Front catalytic converter LH |                              |
| (3) Rear oxygen sensor LH        | (6) Front catalytic converter RH |                              |




# Electrical Component Location

ENGINE (DIAGNOSTICS)



- Solenoid valve, actuator, emission control system parts and ignition system parts



- (1) Purge control solenoid valve
- (2) EGR valve
- (3) Ignition coil & ignitor ASSY






- (4) Oil flow control solenoid valve
- (5) Oil switching solenoid valve

- (6) Variable valve lift diagnosis oil pressure switch

EN-02481

# Electrical Component Location


ENGINE (DIAGNOSTICS)




# Electrical Component Location

ENGINE (DIAGNOSTICS)

- LHD model



- RHD model








- |                      |                                       |             |
|----------------------|---------------------------------------|-------------|
| (1) Inhibitor switch | (4) Fuel pump relay                   | (7) Starter |
| (2) Fuel pump        | (5) Electronic throttle control relay |             |
| (3) Main relay       | (6) Radiator fan relay                |             |




# Electrical Component Location

## ENGINE (DIAGNOSTICS)



## 5. Engine Control Module (ECM) I/O Signal

### A: ELECTRICAL SPECIFICATION



EN-01812

Description	Connector No.	Terminal No.	Signal (V)		Reference	
			Ignition SW ON (engine OFF)	Engine ON (idling)		
Crankshaft position sensor	Signal (+)	B135	10	0	-7 — +7	Waveform
	Signal (-)	B135	22	0	0	—
	Shield	B135	31	0	0	—
Camshaft position sensor (LH)	B135	8	0.275	0 or 5	Waveform	
Camshaft position sensor (RH)	B135	9	0.275	0 or 5	Waveform	
Electronic throttle control	Main	B136	18	0.64 — 0.94 Fully opens: 4.01	0.64 — 0.72 (After engine is warmed-up.)	Fully closed: 0.6 Fully opened: 4.01
	Sub	B136	29	1.51 — 1.76 Fully opens: 4.23	1.51 — 1.58 (After engine is warmed-up.)	Fully closed: 1.48 Fully opens: 4.23
Electronic throttle control motor (+)	B137	5	Duty waveform	Duty waveform	Drive frequency: 500 Hz	
Electronic throttle control motor (-)	B137	4	Duty waveform	Duty waveform	Drive frequency: 500 Hz	
Electronic throttle control motor power supply	B137	6	10 — 13	12 — 14	—	
Electronic throttle control motor relay	B135	35	ON: 0 OFF: 10 — 13	ON: 0 OFF: 13 — 14	When ignition switch is turned to ON: ON	
Accelerator position sensor	Main	B136	17	Fully closed: 1 Fully opens: 3.6	Fully closed: 1 Fully opens: 3.3	—
	Power supply	B136	15	5	5	—
	Ground	B136	34	0	0	—
	Sub	B136	28	Fully closed: 1 Fully opens: 3.7	Fully closed: 1 Fully opens: 3.3	—
Engine coolant temperature sensor	B136	14	1.0 — 1.4	1.0 — 1.4	After engine is warmed-up.	
Starter switch	B137	8	0	0	Cranking: 8 — 14	

## Engine Control Module (ECM) I/O Signal

### ENGINE (DIAGNOSTICS)

Description	Connector No.	Terminal No.	Signal (V)		Reference	
			Ignition SW ON (engine OFF)	Engine ON (idling)		
Starter relay	B135	32	ON: 0 OFF: 10 — 13	ON: 0 OFF: 13 — 14	—	
A/C switch	B137	17	ON: 10 — 13 OFF: 0	ON: 13 — 14 OFF: 0	—	
Ignition switch	B137	14	10 — 13	13 — 14	—	
Neutral position switch	B137	9	ON: 0 OFF: 12±0.5		Switch is ON when select lever is shifted into "P" or "N" range.	
Test mode connector	B137	15	12 — 14	12 — 14	When connected: 0	
Knock sensor 1	Signal	B136	25	2.4	2.4	—
	Shield	B136	33	0	0	—
Knock sensor 2	Signal	B136	24	2.4	2.4	—
	Shield	B136	33	0	0	—
Back-up power supply	B135	19	10 — 13	13 — 14	Ignition switch "OFF": 10 — 13	
Control module power supply	B135	6	10 — 13	13 — 14	—	
	B135	5	10 — 13	13 — 14	—	
Sensor power supply	B136	16	5	5	—	
Ignition control	#1	B135	18	0	13 — 14	Waveform
	#2	B135	17	0	13 — 14	Waveform
	#3	B135	16	0	13 — 14	Waveform
	#4	B135	15	0	13 — 14	Waveform
	#5	B135	14	0	13 — 14	Waveform
	#6	B135	13	0	13 — 14	Waveform
Fuel injector	#1	B136	6	10 — 13	1 — 14	Waveform
	#2	B136	5	10 — 13	1 — 14	Waveform
	#3	B136	4	10 — 13	1 — 14	Waveform
	#4	B136	3	10 — 13	1 — 14	Waveform
	#5	B136	2	10 — 13	1 — 14	Waveform
	#6	B136	1	10 — 13	1 — 14	Waveform
A/C relay control	B135	33	ON: 0.5, or less OFF: 10 — 13	ON: 0.5, or less OFF: 13 — 14	—	
Radiator fan control	B134	31	ON: 0.5, or less OFF: 10 — 13	ON: 0.5, or less OFF: 13 — 14	—	
Radiator fan control power supply	B135	30	ON: 0.5, or less OFF: 10 — 13	ON: 0.5, or less OFF: 13 — 14	—	
Self-shutoff control	B137	16	0	0	—	
Malfunction indicator light	B134	17	—	—	Light "ON": 1, or less Light "OFF": 10 — 14	
Engine speed output	B134	23	—	0 — 13, or more	Waveform	
Purge control solenoid valve	B134	14	ON: 1, or less OFF: 10 — 13	ON: 1, or less OFF: 13 — 14	—	
EGR solenoid valve	Signal A+	B134	11	10 — 13	10 — 13	—
	Signal A-	B134	10	10 — 13	10 — 13	—
	Signal B+	B134	9	10 — 13	10 — 13	—
	Signal B-	B134	8	10 — 13	10 — 13	—
Power steering switch	B137	10	ON: 1, or less OFF: 10 — 13	ON: 1, or less OFF: 13 — 14	—	
Manifold absolute pressure sensor	B136	22	3.5 — 4.8	1.1 — 1.9	—	

# Engine Control Module (ECM) I/O Signal

ENGINE (DIAGNOSTICS)

Description		Connector No.	Terminal No.	Signal (V)		Reference
				Ignition SW ON (engine OFF)	Engine ON (idling)	
Air flow sensor	Signal	B136	23	0.74	0.3 — 4.5	—
	Shield	B136	32	0	0	—
	Ground	B136	31	0	0	—
Intake air temperature sensor		B136	13	3.15 — 3.33	3.15 — 3.33	intake air temperature:25°C (75°F)
Front oxygen (A/F) sensor RH	Signal (+)	B134	33	2.8 — 3.2	2.8 — 3.2	—
	Signal (-)	B134	26	2.4 — 2.7	2.4 — 2.7	—
	Shield	B134	25	0	0	—
Front oxygen (A/F) sensor heater RH	Signal 1	B134	3	12 — 14	—	Waveform
	Signal 2	B134	2	12 — 14	—	Waveform
Front oxygen (A/F) sensor LH	Signal (+)	B134	34	2.8 — 3.2	2.8 — 3.2	—
	Signal (-)	B134	27	2.4 — 2.7	2.4 — 2.7	—
	Shield	B134	25	0	0	—
Front oxygen (A/F) sensor heater LH	Signal 1	B134	1	12 — 14	—	Waveform
	Signal 2	B135	7	12 — 14	—	Waveform
Rear oxygen sensor RH	Signal	B137	24	0	0 — 0.9	—
	Shield	B137	31	0	0	—
Rear oxygen sensor heater RH signal		B135	2	12 — 14	—	Waveform
Rear oxygen sensor LH	Signal	B137	25	0	0 — 0.9	—
	Shield	B137	31	0	0	—
Rear oxygen sensor heater LH signal		B135	3	12 — 14	—	Waveform
Immobilizer communication 1		B137	19	10	10	—
Immobilizer communication 2		B137	27	10	10	—
Fuel pump control unit	Signal 1	B137	28	0	13 — 14	—
	Signal 2	B135	27	0	0 or 5	—
Brake switch 1		B136	9	When brake pedal is depressed: 0 When brake pedal is released: 10 — 13	When brake pedal is depressed: 0 When brake pedal is released: 13 — 14	—
Brake switch 2		B136	8	When brake pedal is depressed: 10 — 13 When brake pedal is released: 0	When brake pedal is depressed: 13 — 14 When brake pedal is released: 0	—
Cruise control command switch		B136	11	When operating nothing: 3.5 — 4.5 When operating RES/ACC: 2.5 — 3.5 When operating SET/COAST: 0.5 — 1.5 When operating CANCEL: 0 — 0.5	When operating nothing: 3.5 — 4.5 When operating RES/ACC: 2.5 — 3.5 When operating SET/COAST: 0.5 — 1.5 When operating CANCEL: 0 — 0.5	—
Cruise control main switch		B136	7	ON: 0 OFF: 5	ON: 0 OFF: 5	—

## Engine Control Module (ECM) I/O Signal

### ENGINE (DIAGNOSTICS)

Description		Connector No.	Terminal No.	Signal (V)		Reference
				Ignition SW ON (engine OFF)	Engine ON (idling)	
Oil flow control solenoid valve RH	Signal (+)	B134	18	0	0.6	—
	Signal (-)	B134	28	0	0	—
Oil flow control solenoid valve LH	Signal (+)	B134	19	0	0.6	—
	Signal (-)	B134	29	0	0	—
Oil switching solenoid valve RH	Signal (+)	B134	21	0	1.9	—
	Signal (-)	B134	20	0	0	—
Oil switching solenoid valve LH	Signal (+)	B135	25	0	1.9	—
	Signal (-)	B135	24	0	0	—
Oil temperature sensor signal		B136	27	1.0 — 1.4	1.0 — 1.4	After engine is warmed-up.
Variable valve lift diagnosis oil pressure switch RH		B135	21	0	0	—
Variable valve lift diagnosis oil pressure switch LH		B135	29	0	0	—
Generator control		B134	22	0 — 6.5	0 — 6.5	—
SSM communication line		B137	20	Less than 1 ←→ More than 4	Less than 1 ←→ More than 4	—
GND (sensor)		B136	35	0	0	—
GND (injector)		B137	7	0	0	—
GND (ignition system)		B135	12	0	0	—
GND (power supply)		B135	4	0	0	—
		B135	1	0	0	—
GND (control system)		B137	2	0	0	—
		B137	1	0	0	—
GND (Front oxygen (A/F) sensor heater RH)		B134	7	0	0	—
GND (Front oxygen (A/F) sensor heater LH)		B134	5	0	0	—
GND (Electronic throttle control)		B137	3	0	0	—

## 6. Engine Condition Data

### A: ELECTRICAL SPECIFICATION

Remarks	Specification
Engine load	1.6 — 2.9 (%): Idling
	6.4 — 12.8 (%): 2,500 rpm racing

Measuring condition:

- After engine is warmed-up.
- Gear position is in "N" or "P" range.
- Turn the A/C to OFF.
- Turn all accessory switches to OFF.

# Data Link Connector

ENGINE (DIAGNOSTICS)


## 7. Data Link Connector

### A: NOTE

This connector is used for Subaru Select Monitor.

### CAUTION:

Do not connect any scan tools other than the Subaru Select Monitor and the OBD-II general scan tools, because the circuit for the Subaru Select Monitor may be damaged.




Terminal No.	Remarks	Terminal No.	Remarks
1	Power supply	9	Empty
2	Empty	10	Subaru Select Monitor signal
3	Empty	11	Empty
4	Empty	12	Ground
5	Empty	13	Ground
6	Empty	14	Empty
7	Empty	15	Empty
8	Empty	16	Empty

## 8. OBD-II General Scan Tool

### A: OPERATION

#### 1. HOW TO USE OBD-II GENERAL SCAN TOOL

- 1) Prepare a general scan tool (OBD-II general scan tool) required by SAE J1978.
- 2) Open the cover and connect the OBD-II general scan tool to the data link connector located in the lower portion of the instrument panel (on the driver's side).



3) Using the OBD-II general scan tool, call up DTC and freeze frame data.

OBD-II general scan tool functions consist of:

- (1) MODE \$01: Current powertrain diagnostic data
- (2) MODE \$02: Powertrain freeze frame data
- (3) MODE \$03: Emission-related powertrain DTC
- (4) MODE \$04: Clear/Reset emission-related diagnostic information

Read out data according to repair procedures. (For detailed operation procedures, refer to the OBD-II General Scan Tool Operation Manual.)

**NOTE:**

For details concerning DTCs, refer to the List of Diagnostic Trouble Code (DTC). <Ref. to EN(H6DO)(diag)-66, List of Diagnostic Trouble Code (DTC).>

#### 2. MODE \$01 (CURRENT POWERTRAIN DIAGNOSTIC DATA)

Refers to data denoting the current operating condition of analog input/output, digital input/output and/or the powertrain system.

A list of the support data and PID (Parameter Identification) codes are shown in the following table.

PID	Data	Unit of measure
01	Number of emission-related powertrain DTC and malfunction indicator light status	ON/OFF
03	Fuel system control status	—
04	Calculated engine load value	%
05	Engine coolant temperature	°C
06	Short term fuel trim (bank 1)	%
07	Long term fuel trim (bank 1)	%
08	Short term fuel trim (bank 2)	%
09	Long term fuel trim (bank 2)	%
0B	Intake manifold absolute pressure	kPa
0C	Engine revolution	rpm
0D	Vehicle speed	km/h
0E	Ignition timing advance	°
10	Air flow rate of manifold absolute pressure sensor	g/sec
11	Throttle valve opening angle	%
13	Check whether oxygen sensor is installed.	—
24	Oxygen sensor output voltage and short term fuel trim associated with oxygen sensor (bank 1)	V and %
28	Oxygen sensor output voltage and short term fuel trim associated with oxygen sensor (bank 2)	V and %
1C	On-board diagnostic system	—

**NOTE:**

Refer to OBD-II general scan tool manufacturer's instruction manual to access generic OBD-II PIDs (MODE \$01).



# OBD-II General Scan Tool

## ENGINE (DIAGNOSTICS)

### 3. MODE \$02 (POWERTRAIN FREEZE FRAME DATA)

Refers to data denoting the operating condition when trouble is sensed by the on-board diagnosis system. A list of the support data and PID (Parameter Identification) codes are shown in the following table.

PID	Data	Unit of measure
02	DTC that caused CARB required freeze frame data storage	—
03	Fuel system control status	—
04	Calculated engine load value	%
05	Engine coolant temperature	°C
06	Short term fuel trim (bank 1)	%
07	Long term fuel trim (bank 1)	%
08	Short term fuel trim (bank 2)	%
09	Long term fuel trim (bank 2)	%
0B	Intake manifold absolute pressure	kPa
0C	Engine speed	rpm
0D	Vehicle speed	km/h

**NOTE:**

Refer to OBD-II general scan tool manufacturer's instruction manual to access freeze frame data (MODE \$02).

### 4. MODE \$03 (EMISSION-RELATED POWERTRAIN DTC)

Refer to "Read Diagnostic Trouble Code" for information about data denoting emission-related powertrain DTC. <Ref. to EN(H6DO)(diag)-32, Read Diagnostic Trouble Code (DTC).>

### 5. MODE \$04 (CLEAR/RESET EMISSION-RELATED DIAGNOSTIC INFORMATION)

Refers to the mode used to clear or reset emission-related diagnostic information (OBD-II trouble diagnostic information).

**NOTE:**

Refer to OBD-II general scan tool manufacturer's instruction manual to clear or reset emission-related diagnostic information (MODE \$04).

## 9. Subaru Select Monitor

### A: OPERATION


#### 1. HOW TO USE SUBARU SELECT MONITOR

1) Prepare the Subaru Select Monitor kit. <Ref. to EN(H6DO)(diag)-7, PREPARATION TOOL, General Description.>




2) Connect the diagnosis cable to Subaru Select Monitor.

3) Insert the cartridge to Subaru Select Monitor. <Ref. to EN(H6DO)(diag)-7, PREPARATION TOOL, General Description.>



4) Connect the Subaru Select Monitor to data link connector.

(1) Data link connector located in the lower portion of the instrument panel (on the driver's side).




(2) Connect the diagnosis cable to data link connector.

#### CAUTION:

Do not connect the scan tools except for Subaru Select Monitor and OBD-II general scan tool.

5) Turn ignition switch to ON (engine OFF) and turn Subaru Select Monitor switch to ON.



(A) Power switch

6) Using the Subaru Select Monitor, call up DTC and data, then record them.

#### 2. READ DIAGNOSTIC TROUBLE CODE (DTC) FOR ENGINE (NORMAL MODE)

Refer to "Read Diagnostic Trouble Code (DTC)" for information about how to indicate DTC. <Ref. to EN(H6DO)(diag)-32, Read Diagnostic Trouble Code (DTC).>

#### 3. READ DIAGNOSTIC TROUBLE CODE (DTC) FOR ENGINE (OBD MODE)

Refer to "Read Diagnostic Trouble Code (DTC)" for information about how to indicate DTC. <Ref. to EN(H6DO)(diag)-32, Read Diagnostic Trouble Code (DTC).>

# Subaru Select Monitor

## ENGINE (DIAGNOSTICS)

### 4. READ CURRENT DATA FOR ENGINE. (NORMAL MODE)

- 1) On the «Main Menu» display screen, select the {Each System Check} and press the [YES] key.
  - 2) On the «System Selection Menu» display screen, select the {Engine} and press the [YES] key.
  - 3) Press the [YES] key after the information of engine type has been displayed.
  - 4) On the «Engine Diagnosis» display screen, select the {Current Data Display/Save}, and then press the [YES] key.
  - 5) On the «Data Display Menu» display screen, select the {Data Display} and press the [YES] key.
  - 6) Using the scroll key, scroll the display screen up or down until the desired data is shown.
- A list of the support data is shown in the following table.

Remarks	Display	Unit of measure	Note (at idling)
Engine load	Engine load	%	3.5%
Engine coolant temperature signal	Engine coolant temperature	°C	≥ 75°C (After engine is warmed-up.)
A/F compensation 1	A/F Compensation 1	%	3.1%
A/F learning 1	A/F learning 1	%	0.0%
A/F compensation 2	A/F Compensation 2	%	4.7%
A/F learning 2	A/F learning 2	%	0.0%
Intake manifold absolute pressure	Intake manifold absolute pressure	mmHg	200 — 300 mmHg
Engine speed signal	Engine speed	rpm	600 — 800 rpm
Meter vehicle speed signal	Meter vehicle speed	km/h	0 km/h
Ignition timing signal	Ignition timing	deg	13 — 15 deg
Intake air temperature signal	Intake air temperature	°C	(Ambient air temperature)
Amount of intake air	Amount of intake air	g/s	3.8 g/s
Throttle opening angle signal	Throttle valve angle	%	1.2 — 1.6%
Front oxygen sensor voltage value 1	Front oxygen sensor voltage value 1	V	0.035 V
Front oxygen sensor voltage value 2	Front oxygen sensor voltage value 2	V	0.020 V
Battery voltage	Battery Voltage	V	12 — 14 V
Mass air flow voltage	Mass air flow voltage	V	1.1 — 1.2 V
Injection 1 pulse width	Injection 1 pulse width	ms	2.82 ms
Injection 2 pulse width	Injection 2 pulse width	ms	2.82 ms
Knock sensor compensation	Knock correction	deg	0 deg
Atmospheric pressure signal	Atmospheric pressure	mmHg	(Atmospheric pressure)
Intake manifold relative pressure	Intake manifold relative pressure	mmHg	(Intake manifold absolute pressure — Atmospheric pressure)
Acceleration opening angle signal	Acceleration opening angle	%	0%
Radiator fan output	Radiator fan output	%	0%
Purge control solenoid valve duty ratio	CPC duty	%	0 — 3%
EGR step number	EGR step number	STEP	0
Generator duty	ALT duty	%	0%
Fuel pump duty	Fuel pump duty	%	33%
Variable valve timing advance angle amount R	VVT advance angle amount R	deg	0 deg
Variable valve timing advance angle amount L	VVT advance angle amount L	deg	0 deg
Oil flow control solenoid valve duty R	OCV duty R	%	9.4%
Oil flow control solenoid valve duty L	OCV duty L	%	9.4%
Oil flow control solenoid valve current R	OCV current R	mA	64 mA
Oil flow control solenoid valve current L	OCV current L	mA	64 mA

# Subaru Select Monitor

ENGINE (DIAGNOSTICS)

Remarks	Display	Unit of measure	Note (at idling)
Front oxygen (A/F) sensor current value 1	A/F sensor current value 1	mA	0.0 mA
Front oxygen (A/F) sensor current value 2	A/F sensor current value 2	mA	0.0 mA
Front oxygen (A/F) sensor resistance value 1	A/F sensor resistance value 1	Ω	31 Ω
Front oxygen (A/F) sensor resistance value 2	A/F sensor resistance value 2	Ω	31 Ω
Front oxygen (A/F) sensor output lambda 1	A/F sensor output lambda 1	—	1.01
Front oxygen (A/F) sensor output lambda 2	A/F sensor output lambda 2	—	1.00
A/F compensation 3	A/F Compensation 3	%	-0.16%
A/F learning 3	A/F learning 3	%	0.0%
Throttle motor duty	Throttle motor duty	%	-27%
Throttle power supply voltage	Throttle power supply voltage	V	(Battery voltage)
Sub throttle sensor voltage	Sub throttle sensor voltage	V	1.50 V
Main throttle sensor voltage	Main throttle sensor voltage	V	0.64 V
Sub acceleration sensor voltage	Sub acceleration sensor voltage	V	1.10 V
Main acceleration sensor voltage	Main acceleration sensor voltage	V	0.98 V
Memory vehicle speed	Memory vehicle speed	km/h	0 km/h
A/F compensation 4	A/F compensation 4	%	0.31%
A/F learning 4	A/F learning 4	%	0.0%
Fuel level sensor resistance	Fuel level resistance	Ω	4 — 96 Ω
Engine oil temperature	Oil Temperature	°C	≥ 85°C (After engine is warmed-up.)
Oil switching solenoid valve duty R	OSV duty R	%	17.3%
Oil switching solenoid valve duty L	OSV duty L	%	17.3%
Oil switching solenoid valve current R	OSV current R	mA	192 mA
Oil switching solenoid valve current L	OSV current L	mA	192 mA
Variable valve lift lift mode	VVL Lift Mode	—	1
#1 cylinder roughness monitor	#1 cylinder roughness monitor	—	0
#2 cylinder roughness monitor	#2 cylinder roughness monitor	—	0
#3 cylinder roughness monitor	#3 cylinder roughness monitor	—	0
#4 cylinder roughness monitor	#4 cylinder roughness monitor	—	0
#5 cylinder roughness monitor	#5 cylinder roughness monitor	—	0
#6 cylinder roughness monitor	#6 cylinder roughness monitor	—	0
Test mode terminal	Test mode terminal	—	U check
Neutral position switch signal	Neutral SW	—	Neutral
Idle switch signal	Soft idle SW	—	In idle
Ignition switch signal	Ignition SW	—	ON input
Power steering switch signal	Power steering SW input signal	—	OFF input (when OFF)

# Subaru Select Monitor

## ENGINE (DIAGNOSTICS)

Remarks	Display	Unit of measure	Note (at idling)
Air conditioning switch signal	A/C SW	—	OFF input (when OFF)
Steering wheel switch signal	Steering wheel SW	—	Hi input
Starter switch signal	Starter SW	—	OFF input
Front oxygen monitor 1	Front oxygen monitor 1	—	Rich
Front oxygen monitor 2	Front oxygen monitor 2	—	Rich
Knocking signal	Knock signal	—	No
Crankshaft position sensor signal	Crankshaft angle signal	—	Yes
Camshaft position sensor signal	Camshaft angle signal	—	Yes
Rear defogger switch signal	Rear defogger SW	—	OFF input (when OFF)
Blower fan switch signal	Blower fan SW	—	OFF input (when OFF)
Light switch signal	Light SW	—	OFF input (when OFF)
Wiper switch signal	Wiper SW	—	OFF input (when OFF)
A/C lock signal	A/C lock signal	—	OFF input
A/C middle pressure switch signal	A/C middle pressure SW	—	OFF input
A/C compressor relay signal	A/C compressor relay output	—	OFF output
AT coordinate retard angle demand signal	AT coordinate retard angle demand	—	Yes
AT coordinate fuel cut demand signal	AT coordinate fuel cut demand	—	No
Vehicle dynamics control (VDC) torque down prohibition output	VDC torque down prohibition output	—	ON
Vehicle dynamics control (VDC) torque down demand	VDC torque down demand	—	OFF
AT coordinate permission signal	AT coordinate permission signal	—	ON
Electronic throttle control motor relay signal	ETC motor relay	—	ON
Stop light switch signal	Stop light SW	—	OFF
SET/COAST switch signal	SET/COAST SW	—	OFF
RESUME/ACCEL switch signal	RESUME/ACCEL SW	—	OFF
Brake switch signal	Brake SW	—	OFF
Main switch signal	Main SW	—	OFF
Body integrated unit data reception	Body Int. Unit Data	—	ON
Body integrated unit counter update	Body Int. Unit Count	—	ON
Cruise control cancel switch signal	CC Cancel SW	—	OFF

## 5. READ CURRENT DATA FOR ENGINE (OBD MODE)

- 1) On the «Main Menu» display screen, select the {Each System Check} and press the [YES] key.
  - 2) On the «System Selection Menu» display screen, select the {Engine} and press the [YES] key.
  - 3) Press the [YES] key after the information of engine type has been displayed.
  - 4) On the «Engine Diagnosis» display screen, select the {OBD system} and press the [YES] key.
  - 5) On the «OBD Menu» display screen, select the {Current Data Display/Save}, and press the [YES] key.
  - 6) On the «Data Display Menu» display screen, select the {Data Display} and press the [YES] key.
  - 7) Using the scroll key, scroll the display screen up or down until the desired data is shown.
- A list of the support data is shown in the following table.

DESCRIPTION	Display	Unit of measure
Number of diagnosis code	Number of Diag. Code:	0
Condition of malfunction indicator light	MI (MIL)	OFF
Monitoring test of misfire	Misfire monitoring	No
Monitoring test of fuel system	Fuel system monitoring	Finish
Monitoring test of comprehensive component	Component monitoring	Finish
Test of catalyst	Catalyst Diagnosis	No
Test of heating-type catalyst	Heated catalyst	No
Test of evaporative emission purge control system	Evaporative purge system	No
Test of secondary air system	Secondary air system	No
Test of air conditioning system refrigerant	A/C system refrigerant	No
Test of oxygen sensor	Oxygen sensor	Finish
Test of oxygen sensor heater	Oxygen sensor heater	Finish
Test of EGR system	EGR system	Finish
A/F control #1	Fuel system for Bank 1	OPEN early period
A/F control #2	Fuel system for Bank 2	OPEN early period
Load	Calculated load valve	%
Engine coolant temperature	Coolant Temp.	°C
A/F compensation #1	Short term fuel trim B1	%
A/F learning #1	Long term fuel trim B1	%
A/F compensation #2	Short term fuel trim B2	%
A/F learning #2	Long term fuel trim B2	%
Intake manifold absolute pressure	Mani. Absolute Pressure	kPa
Engine speed	Engine Speed	rpm
Vehicle speed	Vehicle Speed	km/h
Ignition timing #1	Ignition timing adv. #1	°
Intake air temperature	Intake Air Temp.	°C
Amount of intake air	Mass Air Flow	g/s
Throttle valve angle	Throttle Opening Angle	%
Oxygen sensor #12	Oxygen sensor #12	V
A/F compensation #12	Short term fuel trim #12	%
OBD system	OBD System	—
Oxygen sensor #11	Oxygen sensor #11	Support
Oxygen sensor #12	Oxygen sensor #12	Support
A/F sensor #11	A/F sensor #11	—
A/F sensor #11	A/F sensor #11	V

**NOTE:**

For detailed operation procedures, refer to the SUBARU SELECT MONITOR OPERATION MANUAL.

# Subaru Select Monitor

## ENGINE (DIAGNOSTICS)

### 6. READ FREEZE FRAME DATA FOR ENGINE (OBD MODE)

- 1) On the «Main Menu» display screen, select the {Each System Check} and press the [YES] key.
  - 2) On the «System Selection Menu» display screen, select the {Engine} and press the [YES] key.
  - 3) Press the [YES] key after the information of engine type has been displayed.
  - 4) On the «Engine Diagnosis» display screen, select the {OBD System} and press the [YES] key.
  - 5) On the «OBD Menu» display screen, select the {Freeze Frame Data} and press the [YES] key.
- A list of the support data is shown in the following table.

DESCRIPTION	Display	Unit of measure
DTC of freeze frame data	Freeze frame data	DTC
Air fuel ratio control system for bank 1	Fuel system for Bank1	—
Air fuel ratio control system for bank 2	Fuel system for bank 2	—
Engine load data	Engine Load	%
Engine coolant temperature signal	Coolant Temp.	°C or °F
Short term fuel trim by front oxygen (A/F) sensor (bank 1)	Short term fuel trim B1	%
Long term fuel trim by front oxygen (A/F) sensor (bank 1)	Long term fuel trim B1	%
Short term fuel trim by front oxygen (A/F) sensor (bank 2)	Short term fuel trim B2	%
Long term fuel trim by front oxygen (A/F) sensor (bank 2)	Long term fuel trim B2	%
Intake manifold absolute pressure signal	Mani. Absolute Pressure	mmHg, kPa, inHg or psi
Engine speed signal	Engine Speed	rpm
Vehicle speed signal	Vehicle Speed	km/h or MPH

#### NOTE:

For detailed operation procedures, refer to the SUBARU SELECT MONITOR OPERATION MANUAL.

## 7. LED OPERATION MODE FOR ENGINE

- 1) On the «Main Menu» display screen, select the {Each System Check} and press the [YES] key.
  - 2) On the «System Selection Menu» display screen, select the {Engine} and press the [YES] key.
  - 3) Press the [YES] key after the information of engine type has been displayed.
  - 4) On the «Engine Diagnosis» display screen, select the {Current Data Display/Save}, and then press the [YES] key.
  - 5) On the «Data Display Menu» display screen, select the {Data & LED Display} and press the [YES] key.
  - 6) Using the scroll key, scroll the display screen up or down until the desired data is shown.
- A list of the support data is shown in the following table.

Remarks	Display	Message	When LED "ON" required
Test mode signal	Test mode terminal	D check/U check	D check
Neutral position switch signal	Neutral SW	Neutral/Other than neutral	Neutral
Idle switch signal	Soft idle SW	Idle/Other than idle	In idle
Ignition switch signal	Ignition SW	ON Input/OFF Input	ON input
Power steering switch signal	Power steering SW	ON Input/OFF Input	ON input
Air conditioning switch signal	A/C SW	ON Input/OFF Input	ON input
Steering wheel switch signal	Steering wheel SW	Hi input/Low input	Low input
Starter switch signal	Starter SW	ON Input/OFF Input	ON input
Front oxygen monitor 1	FtO2 monitor 1	Lean/Rich	Rich
Front oxygen monitor 2	FtO2 monitor 2	Lean/Rich	Rich
Knocking signal	Knock signal	Yes/No	Yes
Crankshaft position sensor signal	Crankshaft angle signal	Yes/No	Yes
Camshaft position sensor signal	Camshaft angle signal	Yes/No	Yes
Rear defogger switch signal	Rear defogger SW	ON Input/OFF Input	ON input
Blower fan switch signal	Blower fan SW	ON Input/OFF Input	ON input
Light switch signal	Light SW	ON Input/OFF Input	ON input
Windshield wiper switch signal	Wiper SW	ON Input/OFF Input	ON input
Air conditioning lock signal	A/C lock signal	ON Input/OFF Input	ON input
A/C middle pressure switch signal	A/C middle pressure SW	ON Input/OFF Input	ON input
Air conditioner compressor relay signal	Compressor relay	ON output/OFF output	ON output
AT retard angle demand signal	AT retard angle demand	Yes/No	Yes
AT fuel cut signal	AT fuel cut	Yes/No	Yes
VDC torque down prohibition output	Torque down output	ON/OFF	Prohibition
VDC torque down demand	Torque down demand	Yes/No	Yes
AT coordinate permission signal	AT coordinate permission signal	ON/OFF	Permission
Electronic throttle control motor relay signal	ETC motor relay	ON/OFF	ON
Stop light switch signal	Stop SW	ON Input/OFF Input	ON input
SET/COAST switch signal	SET/CST SW	ON Input/OFF Input	ON input
RESUME/ACCEL switch signal	RES/ACC SW	ON Input/OFF Input	ON input
Brake switch signal	Brake SW	ON Input/OFF Input	ON input
Main switch signal	Main SW	ON Input/OFF Input	ON input
Body integrated unit data reception	Body Int. Unit Data	Yes/No	Yes
Body integrated unit counter update	Body Int. Unit Count	Yes/No	Yes
Cruise control cancel switch signal	CC Cancel SW	ON Input/OFF Input	ON input

**NOTE:**

For detailed operation procedures, refer to the SUBARU SELECT MONITOR OPERATION MANUAL.



# Read Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

---

## 10. Read Diagnostic Trouble Code (DTC)

### A: OPERATION

#### 1. SUBARU SELECT MONITOR (NORMAL MODE)

- 1) On the «Main Menu» display screen, select the {Each System Check} and press the [YES] key.
- 2) On the «System Selection Menu» display screen, select the {Engine} and press the [YES] key.
- 3) Press the [YES] key after the information of engine type has been displayed.
- 4) On the «Engine Diagnosis» screen, select the {DTC Display}, and then press the [YES] key.
- 5) On the «Diagnostic Code(s) Display» screen, select the {Current Diagnostic Code(s)} or {History Diagnostic Code(s)}, and then press the [YES] key.

#### NOTE:

- For detailed operation procedures, refer to the SUBARU SELECT MONITOR OPERATION MANUAL.
- For details concerning DTC, refer to the List of Diagnostic Trouble Code (DTC). <Ref. to EN(H6DO)(diag)-66, List of Diagnostic Trouble Code (DTC).>

#### 2. SUBARU SELECT MONITOR (OBD MODE)

- 1) On the «Main Menu» display screen, select the {Each System Check} and press the [YES] key.
- 2) On the «System Selection Menu» display screen, select the {Engine} and press the [YES] key.
- 3) Press the [YES] key after the information of engine type was displayed.
- 4) On the «Engine Diagnosis» display screen, select the {OBD System} and press the [YES] key.
- 5) On the «OBD Menu» display screen, select the {DTC Display} and press the [YES] key.
- 6) Make sure DTC is shown on the screen.

#### NOTE:

- For detailed operation procedures, refer to the SUBARU SELECT MONITOR OPERATION MANUAL.
- For details concerning DTC, refer to the List of Diagnostic Trouble Code (DTC). <Ref. to EN(H6DO)(diag)-66, List of Diagnostic Trouble Code (DTC).>

#### 3. OBD-II GENERAL SCAN TOOL

Refers to data denoting emission-related powertrain DTC.

For details concerning DTCs, refer to the List of Diagnostic Trouble Code (DTC). <Ref. to EN(H6DO)(diag)-66, List of Diagnostic Trouble Code (DTC).>

#### NOTE:

Refer to OBD-II general scan tool manufacturer's instruction manual to access power train DTC (MODE \$03).

## 11. Inspection Mode

### A: PROCEDURE

When performing the diagnose without the “List of Diagnostic Trouble Code (DTC)”, refer the item of drive cycle. <Ref. to EN(H6DO)(diag)-38, Drive Cycle.>

DTC	Item	On condition
P0011	“A” Camshaft Position-Timing Over-Advanced or System Performance (Bank 1)	—
P0021	“A” Camshaft Position-Timing Over-Advanced or System Performance (Bank 2)	—
P0031	HO2S Heater Control Circuit Low (Bank 1 Sensor 1)	—
P0032	HO2S Heater Control Circuit High (Bank 1 Sensor 1)	—
P0037	HO2S Heater Control Circuit Low (Bank 1 Sensor 2)	—
P0038	HO2S Heater Control Circuit High (Bank 1 Sensor 2)	—
P0051	HO2S Heater Control Circuit Low (Bank 2 Sensor 1)	—
P0052	HO2S Heater Control Circuit High (Bank 2 Sensor 1)	—
P0057	HO2S Heater Control Circuit Low (Bank 2 Sensor 2)	—
P0058	HO2S Heater Control Circuit High (Bank 2 Sensor 2)	—
P0077	Intake Valve Control Solenoid Circuit High (Bank 1)	—
P0083	Intake Valve Control Solenoid Circuit High (Bank 2)	—
P0102	Mass or Volume Air Flow Circuit Low Input	—
P0103	Mass or Volume Air Flow Circuit High Input	—
P0107	Manifold Absolute Pressure/Barometric Pressure Circuit Low Input	—
P0108	Manifold Absolute Pressure/Barometric Pressure Circuit High Input	—
P0112	Intake Air Temperature Circuit Low Input	—
P0113	Intake Air Temperature Circuit High Input	—
P0117	Engine Coolant Temperature Circuit Low Input	—
P0118	Engine Coolant Temperature Circuit High Input	—
P0122	Throttle/Pedal Position Sensor/Switch “A” Circuit Low Input	—
P0123	Throttle/Pedal Position Sensor/Switch “A” Circuit High Input	—
P0131	O <sub>2</sub> Sensor Circuit Low Voltage (Bank 1 Sensor 1)	—
P0132	O <sub>2</sub> Sensor Circuit High Voltage (Bank 1 Sensor 1)	—
P0137	O <sub>2</sub> Sensor Circuit Low Voltage (Bank 1 Sensor 2)	—
P0138	O <sub>2</sub> Sensor Circuit High Voltage (Bank 1 Sensor 2)	—
P0151	O <sub>2</sub> Sensor Circuit Low Voltage (Bank 2 Sensor 1)	—
P0152	O <sub>2</sub> Sensor Circuit High Voltage (Bank 2 Sensor 1)	—
P0157	O <sub>2</sub> Sensor Circuit Low Voltage (Bank 2 Sensor 2)	—
P0158	O <sub>2</sub> Sensor Circuit High Voltage (Bank 2 Sensor 2)	—
P0171	System Too Lean (Bank 1)	—
P0172	System Too Rich (Bank 1)	—
P0174	System Too Lean (Bank 2)	—
P0175	System Too Rich (Bank 2)	—
P0197	Engine Oil Temperature Sensor Circuit Low	—
P0198	Engine Oil Temperature Sensor Circuit High	—
P0222	Throttle/Pedal Position Sensor/Switch “B” Circuit Low Input	—
P0223	Throttle/Pedal Position Sensor/Switch “B” Circuit High Input	—
P0230	Fuel Pump Primary Circuit	—
P0327	Knock Sensor 1 Circuit Low Input (Bank 1 or Single Sensor)	—
P0328	Knock Sensor 1 Circuit High Input (Bank 1 or Single Sensor)	—
P0332	Knock Sensor 2 Circuit Low Input (Bank 2)	—
P0333	Knock Sensor 2 Circuit High Input (Bank 2)	—
P0335	Crankshaft Position Sensor “A” Circuit	—
P0340	Camshaft Position Sensor “A” Circuit (Bank 1 or Single Sensor)	—

## Inspection Mode

### ENGINE (DIAGNOSTICS)

DTC	Item	On condition
P0345	Camshaft Position Sensor "A" Circuit (Bank 2)	—
P0458	Evaporative Emission Control System Purge Control Valve Circuit Low	—
P0462	Fuel Level Sensor Circuit Low Input	—
P0463	Fuel Level Sensor Circuit High Input	—
P0500	Vehicle Speed Sensor	—
P0512	Starter Request Circuit	—
P0519	Idle Control System Malfunction (Fail-Safe)	—
P0558	Generator Circuit Low Input	—
P0600	Serial Communication Link	—
P0604	Internal Control Module Random Access Memory (RAM) Error	—
P0605	Internal Control Module Read Only Memory (ROM) Error	—
P0607	Control Module Performance	—
P0638	Throttle Actuator Control Range/Performance (Bank 1)	—
P0691	Cooling Fan 1 Control Circuit Low	—
P0692	Cooling Fan 1 Control Circuit High	—
P0700	Transmission Control System (MIL Request)	—
P1160	Return Spring Failure	—
P1518	Starter Switch Circuit Low input	—
P1560	Back-up Voltage Circuit Malfunction	—
P2088	OCV Solenoid Valve Signal A Circuit Open (Bank 1)	—
P2089	OCV Solenoid Valve Signal A Circuit Short (Bank 1)	—
P2092	OCV Solenoid Valve Signal A Circuit Open (Bank 2)	—
P2093	OCV Solenoid Valve Signal A Circuit Short (Bank 2)	—
P2101	Throttle Actuator Control Motor Circuit Range/Performance	—
P2102	Throttle Actuator Control Motor Circuit Low	—
P2103	Throttle Actuator Control Motor Circuit High	—
P2109	Throttle/Pedal Position Sensor A Minimum Stop Performance	—
P2122	Throttle/Pedal Position Sensor/Switch "D" Circuit Low Input	—
P2123	Throttle/Pedal Position Sensor/Switch "D" Circuit High Input	—
P2127	Throttle/Pedal Position Sensor/Switch "E" Circuit Low Input	—
P2128	Throttle/Pedal Position Sensor/Switch "E" Circuit High Input	—
P2135	Throttle/Pedal Position Sensor/Switch "A"/"B" Voltage Rationality	—
P2138	Throttle/Pedal Position Sensor/Switch "D"/"E" Voltage Rationality	—

### 1. PREPARATION FOR THE INSPECTION MODE

1) Check battery voltage is more than 12 V and fuel remains half [20 — 40 ℓ (5.3 — 10.6 US gal, 4.4 — 8.8 Imp gal)].


2) Lift-up the vehicle using a garage jack and place it on rigid racks or drive the vehicle onto free rollers.

#### WARNING:

- Before lifting-up the vehicle, ensure parking brakes are applied.
- Do not use a pantograph jack in place of a rigid rack.
- Secure a rope or wire to the front or rear towing hooks to prevent the lateral runout of front wheels.

- Do not abruptly depress/release clutch pedal or accelerator pedal during works even when the engine is operating at low speeds since this may cause vehicle to jump off free rollers.
- In order to prevent the vehicle from slipping due to vibration, do not place any wooden blocks or similar items between the rigid racks and the vehicle.

- Since the rear wheels will also rotate, do not place anything near them. Also, make sure that nobody goes in front of the vehicle.



(A) Rigid racks  
(B) Free rollers


## 2. SUBARU SELECT MONITOR

- 1) After clearing the memory, check for any remaining unresolved trouble data. <Ref. to EN(H6DO)(diag)-40, Clear Memory Mode.>
- 2) Idle the engine.
- 3) Prepare the Subaru Select Monitor kit. <Ref. to EN(H6DO)(diag)-7, PREPARATION TOOL, General Description.>




- 4) Connect the diagnosis cable to Subaru Select Monitor.


- 5) Insert the cartridge to Subaru Select Monitor. <Ref. to EN(H6DO)(diag)-7, PREPARATION TOOL, General Description.>



- 6) Connect the test mode connector (A) located at the lower portion of glove box.



- 7) Connect the Subaru Select Monitor to data link connector located in the lower portion of the instrument panel (on the driver's side).




**CAUTION:**  
Do not connect the scan tools except for Subaru Select Monitor or OBD-II general scan tool.

## Inspection Mode

### ENGINE (DIAGNOSTICS)

8) Turn ignition switch to ON (engine OFF) and turn Subaru Select Monitor switch to ON.



(A) Power switch

9) On the «Main Menu» display screen, select the {Each System Check} and press the [YES] key.

10) On the «System Selection Menu» display screen, select the {Engine} and press the [YES] key.

11) Press the [YES] key after the information of engine type was displayed.

12) On the «Engine Diagnosis» screen, select the {D Check} and press the [YES] key.

13) When the “Perform D Check?” is shown on the screen, press the [YES] key.

14) Perform subsequent procedures as instructed on the display screen.

- If trouble still remains in the memory, the corresponding DTC appears on the display screen.

#### NOTE:

- For detailed operation procedures, refer to the SUBARU SELECT MONITOR OPERATION MANUAL.

- For details concerning DTCs, refer to the List of Diagnostic Trouble Code (DTC).

<Ref. to EN(H6DO)(diag)-66, List of Diagnostic Trouble Code (DTC).>

- Release the parking brake.


- The speed difference between front and rear wheels may light either the ABS warning light, but this indicates no malfunctions. When engine control diagnosis is finished, perform the ABS memory clearance procedure of self-diagnosis system.

### 3. OBD-II GENERAL SCAN TOOL

1) After performing the diagnostics and clearing the memory, check for any remaining unresolved trouble data: <Ref. to EN(H6DO)(diag)-40, Clear Memory Mode.>

2) Idle the engine.


3) Connect the test mode connector (A) located at the lower portion of glove box.



4) Connect the OBD-II general scan tool to its data link connector in the lower portion of the instrument panel (on the driver's side).

#### CAUTION:

**Do not connect the scan tools except for Subaru Select Monitor or OBD-II general scan tool.**



5) Start the engine.

#### NOTE:

- Ensure the select lever is placed in the “P” position before starting. (AT model)

- Depress the clutch pedal when starting the engine. (MT model)

6) Using the select lever or shift lever, turn the “P” position switch and the “N” position switch to ON.

7) Depress the brake pedal to turn the brake switch ON. (AT model)

8) Keep the engine speed in the 2,500 — 3,000 rpm range for 40 seconds.

9) Shift the select lever or shift lever in the “D” range (AT model) or “1st” gear (MT model) and drive the vehicle at 5 to 10 km/h (3 to 6 MPH).

#### NOTE:

- On AWD vehicles, release the parking brake.

- The speed difference between front and rear wheels may light either the ABS warning light, but this indicates no malfunctions. When engine control diagnosis is finished, perform the ABS memory clearance procedure of self-diagnosis system.

10) Using the OBD-II general scan tool, check for DTC and record the result(s).

NOTE:

- For detailed operation procedures, refer to the OBD-II General Scan Tool Operation Manual.
- For details concerning DTCs, refer to the List of Diagnostic Trouble Code (DTC).

<Ref. to EN(H6DO)(diag)-66, List of Diagnostic Trouble Code (DTC).>

## 12. Drive Cycle

### A: PROCEDURE

For the troubleshooting, there are three driving patterns. By driving the vehicle with specified pattern, following trouble items could be diagnosed. After the repair of following trouble items, be sure to drive the vehicle with specified patterns to check the trouble was repaired correctly.

#### 1. PREPARATION FOR DRIVE CYCLE

- 1) Check battery voltage is more than 12 V and fuel remains half [20 — 40 ℓ (5.3 — 10.6 US gal, 4.4 — 8.8 Imp gal)].
- 2) After performing the diagnostics and clearing the memory, check for any remaining unresolved trouble data: <Ref. to EN(H6DO)(diag)-40, Clear Memory Mode.>
- 3) Separate the test mode connector.

**NOTE:**

- Perform the diagnosis after warming up the engine except the engine coolant temperature was specified at engine start.
- Perform the diagnosis twice if the DTC marked with \*. After completing the first diagnosis, stop the engine and perform second diagnosis in same condition.

#### 2. DRIVE THE VEHICLE WITH 80 KM/H (50 MPH) FOR 20 MINUTES, AND THEN IDLE THE ENGINE FOR A MINUTE.

DTC	Item	On condition
*P0125	Insufficient Coolant Temperature For Closed Loop Fuel Control	Engine coolant temperature at engine start is 20°C (68°F) or less.
*P0133	O <sub>2</sub> Sensor Circuit Slow Response (Bank 1 Sensor 1)	—
*P0153	O <sub>2</sub> Sensor Circuit Slow Response (Bank 2 Sensor 1)	—
*P0420	Catalyst System Efficiency Below Threshold (Bank 1)	—


#### 3. 10 MINUTES IDLING

**NOTE:**

Drive the vehicle in more than 10 km/h (6 MPH) before diagnosis.

DTC	Item	On condition
*P0030	HO <sub>2</sub> S Heater Control Circuit (Bank 1 Sensor 1)	—
*P0050	HO <sub>2</sub> S Heater Control Circuit (Bank 2 Sensor 1)	—
*P0459	Evaporative Emission Control System Purge Control Valve Circuit High	—

## 4. DRIVE THE VEHICLE WITH FOLLOWING DRIVE PATTERNS



- |   |  |  |
|---|--|--|
| (A) Idle the engine for more than 10 seconds.                     | (D) Decelerate the vehicle to 64 km/h (40 MPH) with throttle fully closed. | (G) Stop the vehicle with throttle fully closed. |
| (B) Accelerate the vehicle to 97 km/h (60 MPH) within 20 seconds. | (E) Drive the vehicle at 64 km/h (40 MPH) for 20 seconds.                  | (H) Vehicle speed km/h (MPH)                     |
| (C) Drive the vehicle at 97 km/h (60 MPH) for 20 seconds.         | (F) Accelerate the vehicle to 97 km/h (60 MPH) within 10 seconds.          | (I) Sec.   |

DTC	Item	On condition
P0076	Intake Valve Control Solenoid Circuit Low (Bank 1)	—
P0082	Intake Valve Control Solenoid Circuit Low (Bank 2)	—
*P0101	Mass or Volume Air Flow Circuit Range/Performance	—
P0134	O <sub>2</sub> Sensor Circuit No Activity Detected (Bank 1 Sensor 1)	—
P0154	O <sub>2</sub> Sensor Circuit No Activity Detected (Bank 2 Sensor 1)	—
*P0301	Cylinder 1 Misfire Detected	Diagnosis may complete at once
*P0302	Cylinder 2 Misfire Detected	Diagnosis may complete at once
*P0303	Cylinder 3 Misfire Detected	Diagnosis may complete at once
*P0304	Cylinder 4 Misfire Detected	Diagnosis may complete at once
*P0305	Cylinder 5 Misfire Detected	Diagnosis may complete at once
*P0306	Cylinder 6 Misfire Detected	Diagnosis may complete at once
P0400	Exhaust Gas Recirculation Flow	—
P0559	Generator Circuit High Input	—
P1026	VVL System 1 Malfunction	—
P1028	VVL System 2 Malfunction	—
P1492	EGR Solenoid Valve Signal #1 Circuit Malfunction (Low Input)	—
P1493	EGR Solenoid Valve Signal #1 Circuit Malfunction (High Input)	—
P1494	EGR Solenoid Valve Signal #2 Circuit Malfunction (Low Input)	—
P1495	EGR Solenoid Valve Signal #2 Circuit Malfunction (High Input)	—
P1496	EGR Solenoid Valve Signal #3 Circuit Malfunction (Low Input)	—
P1497	EGR Solenoid Valve Signal #3 Circuit Malfunction (High Input)	—
P1498	EGR Solenoid Valve Signal #4 Circuit Malfunction (Low Input)	—
P1499	EGR Solenoid Valve Signal #4 Circuit Malfunction (High Input)	—



## 13. Clear Memory Mode

### A: OPERATION

#### 1. SUBARU SELECT MONITOR (NORMAL MODE)

- 1) On the «Main Menu» display screen, select the {Each System Check} and press the [YES] key.
- 2) On the «System Selection Menu» display screen, select the {Engine} and press the [YES] key.
- 3) Press the [YES] key after the information of engine type was displayed.
- 4) On the «Engine Diagnosis» display screen, select the {Memory Clear} and press the [YES] key.
- 5) When the “Done” and “Turn Ignition Switch OFF” are shown on the display screen, turn the ignition switch to OFF and then Subaru Select Monitor switch to OFF.

#### NOTE:

- Initial diagnosis of electronic control throttle is performed after memory clearance. For this reason, start the engine after 10 seconds or more have elapsed since the ignition switch was turned to ON.
- For detailed operation procedures, refer to the SUBARU SELECT MONITOR OPERATION MANUAL.

#### 2. SUBARU SELECT MONITOR (OBD MODE)

- 1) On the «Main Menu» display screen, select the {Each System Check} and press the [YES] key.
- 2) On the «System Selection Menu» display screen, select the {Engine} and press the [YES] key.
- 3) Press the [YES] key after the information of engine type was displayed.
- 4) On the «Engine Diagnosis» display screen, select the {OBD System} and press the [YES] key.
- 5) On the «OBD Menu» display screen, select the {DTC Clear} and press the [YES] key.
- 6) When the “Perform Diagnostic Code(s) Clear?” is shown on the screen, press the [YES] key.
- 7) Turn the ignition switch to OFF and then turn off the Subaru Select Monitor.

#### NOTE:

- Initial diagnosis of electronic control throttle is performed after memory clearance. For this reason, start the engine after 10 seconds or more have elapsed since the ignition switch was turned to ON.
- For detailed operation procedures, refer to the SUBARU SELECT MONITOR OPERATION MANUAL.


#### 3. OBD-II GENERAL SCAN TOOL

For clear memory procedures using the OBD-II general scan tool, refer to the OBD-II General Scan Tool Instruction Manual.

## 14. Compulsory Valve Operation Check Mode


### A: OPERATION

1) Prepare the Subaru Select Monitor kit. <Ref. to EN(H6DO)(diag)-7, PREPARATION TOOL, General Description.>




2) Connect the diagnosis cable to Subaru Select Monitor.


3) Insert the cartridge to Subaru Select Monitor. <Ref. to EN(H6DO)(diag)-7, PREPARATION TOOL, General Description.>



4) Connect the test mode connector (A) located at the lower portion of glove box.




5) Connect the Subaru Select Monitor to data link connector located in the lower portion of the instrument panel (on the driver's side).



### CAUTION:

**Do not connect the scan tools except for Subaru Select Monitor or OBD-II general scan tool.**

6) Turn ignition switch to ON (engine OFF) and turn on the Subaru Select Monitor switch.



(A) Power switch

7) On the «Main Menu» display screen, select the {Each System Check} and press the [YES] key.

8) On the «System Selection Menu» display screen, select the {Engine} and press the [YES] key.

9) Press the [YES] key after the information of engine type was displayed.

10) On the «Engine Diagnosis» display screen, select the {System Operation Check Mode} and press the [YES] key.

11) On the «System Operation Check Mode» display screen, select the {Actuator ON/OFF Operation} and press the [YES] key.

12) Select the desired actuator on the «Actuator ON/OFF Operation» display screen and press the [YES] key.

13) Pressing the [NO] key completes the compulsory valve operation check mode. The display will then return to the «Actuator ON/OFF Operation» screen.

# Compulsory Valve Operation Check Mode

## ENGINE (DIAGNOSTICS)

---

- A list of the support data is shown in the following table.

DESCRIPTION	Display
Compulsory fuel pump relay operation check	Fuel Pump
Compulsory radiator fan relay operation check	Radiator Fan Relay
Compulsory air conditioning relay operation check	A/C Compressor Relay
Compulsory purge control solenoid valve operation check	CPC Solenoid

### NOTE:

- The following parts will be displayed but not functional.

Display
EGR Solenoid
ASV Solenoid
FICD Solenoid
Pressure Switching Solenoid 1
Pressure Switching Solenoid 2
Supercharger Control Solenoid
PCV Solenoid
Vent Control Solenoid
AAI Solenoid
Atmospheric pressure switching solenoid
Exhaust Bypass Valve Control Permit Flag

- For detailed operation procedures, refer to the SUBARU SELECT MONITOR OPERATION MANUAL.

## 15. Malfunction Indicator Light

### A: PROCEDURE


1. Activation of malfunction indicator light. <Ref. to EN(H6DO)(diag)-43, ACTIVATION OF MALFUNCTION INDICATOR LIGHT, Malfunction Indicator Light.>
↓
2. Malfunction indicator light does not come on. <Ref. to EN(H6DO)(diag)-45, MALFUNCTION INDICATOR LIGHT DOES NOT COME ON, Malfunction Indicator Light.>
↓
3. Malfunction indicator light does not go off. <Ref. to EN(H6DO)(diag)-47, MALFUNCTION INDICATOR LIGHT DOES NOT GO OFF., Malfunction Indicator Light.>
↓
4. Malfunction indicator light does not blink. <Ref. to EN(H6DO)(diag)-48, MALFUNCTION INDICATOR LIGHT DOES NOT BLINK., Malfunction Indicator Light.>
↓
5. Malfunction indicator light keep blinking. <Ref. to EN(H6DO)(diag)-50, MALFUNCTION INDICATOR LIGHT REMAINS BLINKING., Malfunction Indicator Light.>

### B: ACTIVATION OF MALFUNCTION INDICATOR LIGHT


1) When the ignition switch is turned to ON (engine off), the malfunction indicator light (A) in the combination meter illuminates.

**NOTE:**

If the malfunction indicator light does not illuminate, perform the diagnosis of malfunction indicator light circuit or the combination meter circuit. <Ref. to EN(H6DO)(diag)-45, MALFUNCTION INDICATOR LIGHT DOES NOT COME ON, Malfunction Indicator Light.>



2) After starting the engine, the malfunction indicator light goes out. If it does not, either the engine or the emission control system is malfunctioning.



- (1) No faulty
- (2) Trouble occurs
- (3) ON
- (4) OFF
- (5) Ignition switch ON
- (6) Engine start

3) Turn the ignition switch to OFF and connect the test mode connector.


- (1) When the ignition switch is turned to ON (engine OFF), the malfunction indicator light illuminates.
- (2) After the engine starts, malfunction indicator light blinks in a cycle of 0.5 Hz. (During diagnosis)

# Malfunction Indicator Light

## ENGINE (DIAGNOSTICS)

---

(3) After the diagnosis is completed, malfunction indicator light does not blink at a cycle of 3 Hz if there is no fault. Malfunction indicator light illuminates when the trouble occurs.



- (1) ON
- (2) OFF
- (3) Ignition switch ON
- (4) 1 second

# Malfunction Indicator Light

ENGINE (DIAGNOSTICS)

## C: MALFUNCTION INDICATOR LIGHT DOES NOT COME ON


### DIAGNOSIS:

The malfunction indicator light circuit is open or shorted.

### TROUBLE SYMPTOM:

When the ignition switch is turned to ON (engine OFF), malfunction indicator light does not come on.

### WIRING DIAGRAM:



Step	Check	Yes	No
<b>1</b> <b>CHECK OUTPUT SIGNAL FROM ECM.</b> 1) Turn the ignition switch to ON. 2) Measure the voltage between ECM connector and chassis ground. <b>Connector &amp; terminal</b> <b>(B134) No. 17 (+) — Chassis ground (-):</b>	Is the voltage less than 1 V?	Go to step 4.	Go to step 2.
<b>2</b> <b>CHECK POOR CONTACT.</b> Check for poor connection when shaking or pulling ECM connector and harness.	Does the malfunction indicator light illuminate?	Repair the poor contact in ECM connector.	Go to step 3.

## Malfunction Indicator Light

### ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<b>3 CHECK ECM CONNECTOR.</b> Check the connection of ECM connector.	Is the ECM connector correctly connected?	Replace the ECM. <Ref. to FU(H6DO)-34, Engine Control Module (ECM).>	Repair the connection of ECM connector.
<b>4 CHECK HARNESS BETWEEN COMBINATION METER AND ECM CONNECTOR.</b> 1) Turn the ignition switch to OFF. 2) Remove the combination meter. <Ref. to IDI-16, Combination Meter Assembly.> 3) Disconnect the connector from ECM and combination meter. 4) Measure the resistance of harness between ECM and combination meter connector.  <b>Connector &amp; terminal</b> <b>(B134) No. 17 — (i10) No. 16:</b>	Is the resistance less than 1 $\Omega$ ?	Go to step 5.	Repair the harness and connector.  <b>NOTE:</b> In this case repair the following: <ul style="list-style-type: none"> <li>• Open circuit in harness between ECM and combination meter connector</li> <li>• Poor contact in coupling connector</li> </ul>
<b>5 CHECK POOR CONTACT.</b> Check poor contact in combination meter connector.	Is there poor contact in combination meter connector?	Repair the poor contact in combination meter connector.	Go to step 6.
<b>6 CHECK HARNESS BETWEEN COMBINATION METER AND IGNITION SWITCH CONNECTOR.</b> 1) Turn the ignition switch to ON. 2) Measure the voltage between combination meter connector and chassis ground.  <b>Connector &amp; terminal</b> <b>(i10) No. 3 (+) — Chassis ground (-):</b> <b>(i10) No. 4 (+) — Chassis ground (-):</b>	Is the voltage more than 10 V?	Replace the board of combination meter. <Ref. to IDI-16, Combination Meter Assembly.>	Check the following and repair if necessary.  <b>NOTE:</b> <ul style="list-style-type: none"> <li>• Brown out fuse (No. 5)</li> <li>• Open or short circuit in harness between fuse (No. 5) and battery terminal</li> <li>• Poor contact in ignition switch connector</li> </ul>

# Malfunction Indicator Light

ENGINE (DIAGNOSTICS)

## D: MALFUNCTION INDICATOR LIGHT DOES NOT GO OFF.


### DIAGNOSIS:

The malfunction indicator light circuit is shorted.

### TROUBLE SYMPTOM:

Although malfunction indicator light comes on when the engine runs, DTC is not shown on the Subaru Select Monitor display.

### WIRING DIAGRAM:



Step	Check	Yes	No
<b>1</b> <b>CHECK HARNESS BETWEEN COMBINATION METER AND ECM CONNECTOR.</b> 1) Turn the ignition switch to OFF. 2) Disconnect the connector from ECM. 3) Turn the ignition switch to ON.	Does the malfunction indicator light illuminate?	Repair the short circuit in harness between combination meter and ECM connector.	Replace the ECM. <Ref. to FU(H6DO)-34, Engine Control Module (ECM).>



# Malfunction Indicator Light

ENGINE (DIAGNOSTICS)

## E: MALFUNCTION INDICATOR LIGHT DOES NOT BLINK.


### DIAGNOSIS:

- The malfunction indicator light circuit is open or shorted.
- Test mode connector circuit is in open.

### TROUBLE SYMPTOM:

Malfunction indicator light does not blink during inspection mode.

### WIRING DIAGRAM:



EN-02491

# Malfunction Indicator Light

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<b>1 CHECK STATUS OF MALFUNCTION INDICATOR LIGHT.</b> 1) Turn the ignition switch to OFF. 2) Disconnect the test mode connectors. 3) Turn the ignition switch to ON. (engine OFF)	Does the malfunction indicator light illuminate?	Go to step 2.	Repair the malfunction indicator light circuit. <Ref. to EN(H6DO)(diag)-45, MALFUNCTION INDICATOR LIGHT DOES NOT COME ON, Malfunction Indicator Light.>
<b>2 CHECK HARNESS BETWEEN COMBINATION METER AND ECM CONNECTOR.</b> 1) Turn the ignition switch to OFF. 2) Disconnect the connector from ECM. 3) Turn the ignition switch to ON.	Does the malfunction indicator light illuminate?	Repair the short circuit in harness between combination meter and ECM connector.	Go to step 3.
<b>3 CHECK HARNESS BETWEEN TEST MODE CONNECTOR AND CHASSIS GROUND.</b> 1) Turn the ignition switch to OFF. 2) Disconnect the connector from ECM. 3) Measure the resistance of harness between test mode connector and chassis ground.  <i>Connector &amp; terminal (B76) No. 1 — Chassis ground:</i>	Is the resistance less than 1 $\Omega$ ?	Go to step 4.	Repair the harness and connector.  NOTE: In this case repair the following: • Open circuit in harness between test mode connector and chassis ground
<b>4 CHECK POOR CONTACT.</b> Check poor contact in ECM connector.	Is the poor contact in ECM connector?	Repair the poor contact in ECM connector.	Go to step 5.
<b>5 CHECK HARNESS BETWEEN ECM AND TEST MODE CONNECTOR.</b> 1) Connect the test mode connector. 2) Measure the resistance of harness between ECM and chassis ground.  <i>Connector &amp; terminal (B137) No. 15 — Chassis ground:</i>	Is the resistance less than 1 $\Omega$ ?	Go to step 6.	Repair the open circuit in harness between ECM and test mode connector.
<b>6 CHECK POOR CONTACT.</b> Check poor contact in ECM connector.	Is the poor contact in ECM connector?	Repair the poor contact in ECM connector.	Replace the ECM. <Ref. to FU(H6DO)-34, Engine Control Module (ECM).>

# Malfunction Indicator Light

ENGINE (DIAGNOSTICS)

## F: MALFUNCTION INDICATOR LIGHT REMAINS BLINKING.


### DIAGNOSIS:

Test mode connector circuit is shorted.

### TROUBLE SYMPTOM:

Malfunction indicator light blinks without test mode connector connected.

### WIRING DIAGRAM:



	Step	Check	Yes	No
<b>1</b>	<p><b>CHECK TEST MODE CONNECTOR.</b></p> <p>1) Disconnect the test mode connectors.</p> <p>2) Turn the ignition switch to ON.</p>	Does the malfunction indicator light blink?	Go to step 2.	<p>System is in good order.</p> <p><b>NOTE:</b> Malfunction indicator light blinks when test mode connector is connected.</p>

# Malfunction Indicator Light

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<b>2</b> <b>CHECK HARNESS BETWEEN ECM CONNECTOR AND CHASSIS GROUNDING TERMINAL.</b> 1) Turn the ignition switch to OFF. 2) Disconnect the connector from ECM. 3) Measure the resistance of harness between ECM connector and chassis ground. <b>Connector &amp; terminal</b> <b>(B137) No. 15 — Chassis ground:</b>	Is the resistance less than 5 $\Omega$ ?	Repair the short circuit in harness between ECM and test mode connector.	Replace the ECM. <Ref. to FU(H6DO)-34, Engine Control Module (ECM).>

# Diagnostics for Engine Starting Failure

ENGINE (DIAGNOSTICS)

## 16. Diagnostics for Engine Starting Failure

### A: PROCEDURE


1. Check for fuel amount.
↓
2. Inspection of starter motor circuit <Ref. to EN(H6DO)(diag)-53, STARTER MOTOR CIRCUIT, Diagnostics for Engine Starting Failure.>
↓
3. Inspection of ECM power supply and ground line. <Ref. to EN(H6DO)(diag)-56, CHECK POWER SUPPLY AND GROUND LINE OF ENGINE CONTROL MODULE (ECM), Diagnostics for Engine Starting Failure.>
↓
4. Inspection of ignition control system. <Ref. to EN(H6DO)(diag)-59, IGNITION CONTROL SYSTEM, Diagnostics for Engine Starting Failure.>
↓
5. Inspection of fuel pump circuit. <Ref. to EN(H6DO)(diag)-62, FUEL PUMP CIRCUIT, Diagnostics for Engine Starting Failure.>
↓
6. Inspection of fuel injector circuit. <Ref. to EN(H6DO)(diag)-64, FUEL INJECTOR CIRCUIT, Diagnostics for Engine Starting Failure.>

## B: STARTER MOTOR CIRCUIT

### CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H6DO)(diag)-40, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H6DO)(diag)-33, PROCEDURE, Inspection Mode.>.

### WIRING DIAGRAM:



**B72**

1	2	3
4	5	6

**B225**

1	2	9	13	17	21
3	4	10	14	18	22
5	6	11	12	15	16
7	8	19	20	23	24
25	29	33	37		
26	30	34	38		
27	28	31	32		
35	36	39	40		

**B: B135**

1	2	3	4	5	6	7
8	9	10	11	12	13	14
15	16	17	18	19	20	21
22	23	24	25	26	27	28
29	30	31	32	33	34	35

**D: B137**

1	2	3	4	5	6	7
8	9	10	11	12	13	14
15	16	17	18	19	20	21
22	23	24	25	26	27	28
29	30	31	32	33	34	35

## Diagnostics for Engine Starting Failure

### ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<b>1 CHECK BATTERY.</b> Check the battery voltage.	Is the voltage more than 12 V?	Go to step 2.	Charge or replace the battery.
<b>2 CHECK OPERATION OF STARTER MOTOR.</b>	Does the starter motor operate?	Go to step 3.	Go to step 4.
<b>3 CHECK DTC.</b>	Is DTC displayed? <Ref. to EN(H6DO)(diag)-32, OPERATION, Read Diagnostic Trouble Code (DTC).>	Inspect the relevant DTC using List of Diagnostic Trouble Code (DTC). <Ref. to EN(H6DO)(diag)-66, List of Diagnostic Trouble Code (DTC).>	Repair the poor contact in ECM connector.
<b>4 CHECK INPUT SIGNAL FOR STARTER MOTOR.</b> 1) Turn the ignition switch to OFF. 2) Disconnect the connector from starter motor. 3) Turn the ignition switch to START. 4) Measure the power supply voltage between starter motor connector terminal and engine ground.  <b>Connector &amp; terminal</b> <b>(B14) No. 1 (+) — Engine ground (-):</b>  NOTE: Shift the select lever to "P" or "N" range.	Is the voltage more than 10 V?	Go to step 5.	Go to step 6.
<b>5 CHECK GROUND CIRCUIT OF STARTER MOTOR.</b> 1) Turn the ignition switch to OFF. 2) Disconnect the ground cable terminal from starter motor. 3) Measure the resistance of ground cable between ground cable terminal and engine ground.	Is the resistance less than 5 $\Omega$ ?	Check the starter motor. <Ref. to SC(H6DO)-6, Starter.>	Repair the open circuit of ground cable.
<b>6 CHECK HARNESS BETWEEN BATTERY AND IGNITION SWITCH CONNECTOR.</b> 1) Disconnect the connector from ignition switch. 2) Measure the power supply voltage between ignition switch connector and chassis ground.  <b>Connector &amp; terminal</b> <b>(B72) No. 3 (+) — Chassis ground (-):</b>	Is the voltage more than 10 V?	Go to step 7.	Repair the open circuit in harness between ignition switch and battery, and check fuse SBF No.7 and SBF No.1.
<b>7 CHECK IGNITION SWITCH.</b> 1) Disconnect the connector from ignition switch. 2) Measure the resistance between ignition switch terminals while turning the ignition switch to START position.  <b>Terminals</b> <b>No. 2 — No. 3:</b>	Is the resistance less than 5 $\Omega$ ?	Go to step 8.	Replace the ignition switch.

# Diagnostics for Engine Starting Failure

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<p><b>8 CHECK INPUT VOLTAGE OF STARTER RELAY.</b></p> <p>1) Turn the ignition switch to OFF.                      2) Disconnect the connector from starter relay.                      3) Connect the connector to ignition switch.                      4) Measure the input voltage between starter relay connector and chassis ground while turning the ignition switch to START position.</p> <p><b>Connector &amp; terminal</b>  <b>LHD model</b>                      (B225) No. 13 (+) — Chassis ground (-):                      (B225) No. 15 (+) — Chassis ground (-):  <b>RHD model</b>                      (B225) No. 14 (+) — Chassis ground (-):                      (B225) No. 16 (+) — Chassis ground (-):</p>	Is the voltage more than 10 V?	Go to step 9.	Repair the open circuit in harness between starter relay and ignition switch.
<p><b>9 CHECK STARTER RELAY.</b></p> <p>1) Connect the battery to starter relay terminals No. 15 and No. 16.                      2) Measure the resistance between starter relay terminals.</p> <p><b>Terminals</b>  <b>No. 13 — No. 14:</b></p>	Is the resistance less than 1 $\Omega$ ?	Go to step 10.	Replace the starter relay.
<p><b>10 CHECK INPUT VOLTAGE FROM ECM.</b></p> <p>1) Turn the ignition switch to OFF.                      2) Connect the connector to starter relay.                      3) Disconnect the connectors from ECM.                      4) Measure the voltage between ECM and chassis ground.</p> <p><b>Connector &amp; terminal</b>                      (B135) No. 32 (+) — Chassis ground (-):                      (B137) No. 8 (+) — Chassis ground (-):</p>	Is the voltage more than 10 V?	Replace the ECM. <Ref. to FU(H6DO)-34, Engine Control Module (ECM).>	Repair the open or ground short circuit in harness between ECM and starter relay.



# Diagnostics for Engine Starting Failure


ENGINE (DIAGNOSTICS)

## C: CHECK POWER SUPPLY AND GROUND LINE OF ENGINE CONTROL MODULE (ECM)

### CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H6DO)(diag)-40, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H6DO)(diag)-33, PROCEDURE, Inspection Mode.>.

### WIRING DIAGRAM:



EN-02493

# Diagnostics for Engine Starting Failure

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<p><b>1 CHECK MAIN RELAY.</b>                      1) Turn the ignition switch to OFF.                      2) Remove the main relay.                      3) Connect the battery to main relay terminals No. 1 and No. 2.                      4) Measure the resistance between main relay terminals.</p> <p><b>Terminals</b>  <b>No. 3 — No. 5:</b>  <b>No. 4 — No. 6:</b></p>	Is the resistance less than 10 $\Omega$ ?	Go to step 2.	Replace the main relay.
<p><b>2 CHECK GROUND CIRCUIT FOR ECM.</b>                      1) Disconnect the connector from ECM.                      2) Measure the resistance of harness between ECM and chassis ground.</p> <p><b>Connector &amp; terminal</b>  <b>(B134) No. 4 — Chassis ground:</b>  <b>(B134) No. 5 — Chassis ground:</b>  <b>(B134) No. 6 — Chassis ground:</b>  <b>(B134) No. 7 — Chassis ground:</b>  <b>(B135) No. 1 — Chassis ground:</b>  <b>(B135) No. 4 — Chassis ground:</b>  <b>(B135) No. 12 — Chassis ground:</b>  <b>(B137) No. 1 — Chassis ground:</b>  <b>(B137) No. 2 — Chassis ground:</b>  <b>(B137) No. 3 — Chassis ground:</b>  <b>(B137) No. 7 — Chassis ground:</b></p>	Is the resistance less than 5 $\Omega$ ?	Go to step 3.	Repair the open circuit in harness between ECM connector and engine grounding terminal.
<p><b>3 CHECK INPUT VOLTAGE OF ECM.</b>                      Measure the voltage between ECM connector and chassis ground.</p> <p><b>Connector &amp; terminal</b>  <b>(B135) No. 19 (+) — Chassis ground (-):</b></p>	Is the voltage more than 10 V?	Go to step 4.	Repair the open or ground short circuit of power supply circuit.
<p><b>4 CHECK INPUT VOLTAGE OF ECM.</b>                      1) Turn the ignition switch to ON.                      2) Measure the voltage between ECM connector and chassis ground.</p> <p><b>Connector &amp; terminal</b>  <b>(B137) No. 14 (+) — Chassis ground (-):</b></p>	Is the voltage more than 10 V?	Go to step 5.	Repair the open or ground short circuit of power supply circuit.
<p><b>5 CHECK INPUT VOLTAGE OF MAIN RELAY.</b>                      Measure the voltage between main relay connector and chassis ground.</p> <p><b>Connector &amp; terminal</b>  <b>(B47) No. 2 (+) — Chassis ground (-):</b></p>	Is the voltage more than 10 V?	Go to step 6.	Repair the open circuit in harness between ECM connector and main relay connector.
<p><b>6 CHECK INPUT VOLTAGE OF ECM.</b>                      1) Connect the connectors to ECM and main relay.                      2) Turn the ignition switch to ON.                      3) Measure the voltage between ECM connector and chassis ground.</p> <p><b>Connector &amp; terminal</b>  <b>(B137) No. 16 (+) — Chassis ground (-):</b></p>	Is the voltage more than 10 V?	Go to step 7.	Repair the open or ground short circuit in harness between ECM connector and main relay connector.
<p><b>7 CHECK INPUT VOLTAGE OF MAIN RELAY.</b>                      Measure the voltage between main relay connector and chassis ground.</p> <p><b>Connector &amp; terminal</b>  <b>(B47) No. 5 (+) — Chassis ground (-):</b>  <b>(B47) No. 6 (+) — Chassis ground (-):</b></p>	Is the voltage more than 10 V?	Go to step 8.	Repair the open or ground short circuit in harness of power supply circuit.

## Diagnostics for Engine Starting Failure

ENGINE (DIAGNOSTICS)


Step	Check	Yes	No
<b>8</b> <b>CHECK INPUT VOLTAGE OF ECM.</b> 1) Turn the ignition switch to ON. 2) Measure the voltage between ECM connector and chassis ground. <b>Connector &amp; terminal</b> <i>(B135) No. 5 (+) — Chassis ground (-):</i> <i>(B135) No. 6 (+) — Chassis ground (-):</i>	Is the voltage more than 10 V?	Check ignition control system. <Ref. to EN(H6DO)(diag)-59, IGNITION CONTROL SYSTEM, Diagnostics for Engine Starting Failure.>	Repair the open or ground short circuit in harness between ECM connector and main relay connector.

## D: IGNITION CONTROL SYSTEM

### CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H6DO)(diag)-40, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H6DO)(diag)-33, PROCEDURE, Inspection Mode.>.

### WIRING DIAGRAM:



EN-02494

Step	Check	Yes	No	
1	<b>CHECK SPARK PLUG CONDITION.</b> 1) Remove the spark plug. <Ref. to IG(H6DO)-4, REMOVAL, Spark Plug.> 2) Check the spark plug condition. <Ref. to IG(H6DO)-5, INSPECTION, Spark Plug.>	Is the spark plug's status OK?	Go to step 2.	Replace the spark plug.

## Diagnostics for Engine Starting Failure

### ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<p><b>2 CHECK IGNITION SYSTEM FOR SPARKS.</b></p> <p>1) Connect the spark plug to ignition coil.                      2) Release the fuel pressure.                      3) Contact the spark plug's thread portion on engine.                      4) While opening the throttle valve fully, start the engine to check that spark occurs at each cylinder.</p>	Does spark occur at each cylinder?	Check fuel pump system. <Ref. to EN(H6DO)(diag)-62, FUEL PUMP CIRCUIT, Diagnostics for Engine Starting Failure.>	Go to step 3.
<p><b>3 CHECK POWER SUPPLY CIRCUIT FOR IGNITION COIL &amp; IGNITOR ASSY.</b></p> <p>1) Turn the ignition switch to OFF.                      2) Disconnect the connector from ignition coil &amp; ignitor ASSY.                      3) Turn the ignition switch to ON.                      4) Measure the power supply voltage between ignition coil &amp; ignitor ASSY connector and engine ground.</p> <p><b>Connector &amp; terminal</b></p> <p><b>(E31) No. 3 (+) — Engine ground (-):</b>  <b>(E32) No. 3 (+) — Engine ground (-):</b>  <b>(E33) No. 3 (+) — Engine ground (-):</b>  <b>(E34) No. 3 (+) — Engine ground (-):</b>  <b>(E45) No. 3 (+) — Engine ground (-):</b>  <b>(E46) No. 3 (+) — Engine ground (-):</b></p>	Is the voltage more than 10 V?	Go to step 4.	Repair the harness and connector. NOTE: In this case repair the following: • Open circuit in harness between ignition coil & ignitor ASSY, and ignition switch connector • Poor contact in coupling connector
<p><b>4 CHECK HARNESS OF IGNITION COIL &amp; IGNITOR ASSY GROUND CIRCUIT.</b></p> <p>1) Turn the ignition switch to OFF.                      2) Measure the resistance between ignition coil &amp; ignitor ASSY connector and engine ground.</p> <p><b>Connector &amp; terminal</b></p> <p><b>(E31) No. 2 — Engine ground:</b>  <b>(E32) No. 2 — Engine ground:</b>  <b>(E33) No. 2 — Engine ground:</b>  <b>(E34) No. 2 — Engine ground:</b>  <b>(E45) No. 2 — Engine ground:</b>  <b>(E46) No. 2 — Engine ground:</b></p>	Is the resistance less than 5 $\Omega$ ?	Go to step 5.	Repair the harness and connector. NOTE: In this case repair the following: • Open circuit in harness between ignition coil & ignitor ASSY connector and engine grounding terminal
<p><b>5 CHECK HARNESS BETWEEN ECM AND IGNITION COIL &amp; IGNITOR ASSY CONNECTOR.</b></p> <p>1) Turn the ignition switch to OFF.                      2) Disconnect the connector from ECM.                      3) Disconnect the connector from ignition coil &amp; ignitor ASSY.                      4) Measure the resistance of harness between ECM and ignition coil &amp; ignitor ASSY connector.</p> <p><b>Connector &amp; terminal</b></p> <p><b>(B135) No. 18 — (E31) No. 1:</b>  <b>(B135) No. 17 — (E32) No. 1:</b>  <b>(B135) No. 16 — (E33) No. 1:</b>  <b>(B135) No. 15 — (E34) No. 1:</b>  <b>(B135) No. 14 — (E45) No. 1:</b>  <b>(B135) No. 13 — (E46) No. 1:</b></p>	Is the resistance less than 1 $\Omega$ ?	Go to step 6.	Repair the harness and connector. NOTE: In this case repair the following: • Open circuit in harness between ECM and ignition coil & ignitor ASSY connector. • Poor contact in coupling connector

# Diagnostics for Engine Starting Failure

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<p><b>6</b>     <b>CHECK HARNESS BETWEEN ECM AND IGNITION COIL &amp; IGNITOR ASSY CONNECTOR.</b>                      Measure the resistance of harness between ECM and engine ground.  <b>Connector &amp; terminal:</b>  <i>(B135) No. 18 — Engine ground:</i>  <i>(B135) No. 17 — Engine ground:</i>  <i>(B135) No. 16 — Engine ground:</i>  <i>(B135) No. 15 — Engine ground:</i>  <i>(B135) No. 14 — Engine ground:</i>  <i>(B135) No. 13 — Engine ground:</i></p>	Is the resistance more than 1 MΩ?	Go to step 7.	Repair the ground short circuit in harness between ECM and ignition coil & ignitor ASSY connector.
<p><b>7</b>     <b>CHECK POOR CONTACT.</b>                      Check poor contact in ECM connector.</p>	Is the poor contact in ECM connector?	Repair the poor contact in ECM connector.	Check fuel pump circuit. <Ref. to EN(H6DO)(diag)-62, FUEL PUMP CIRCUIT, Diagnostics for Engine Starting Failure.>

# Diagnostics for Engine Starting Failure


ENGINE (DIAGNOSTICS)

## E: FUEL PUMP CIRCUIT

### CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H6DO)(diag)-40, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H6DO)(diag)-33, PROCEDURE, Inspection Mode.>.

### WIRING DIAGRAM:



EN-02504

# Diagnostics for Engine Starting Failure

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<p><b>1</b>     <b>CHECK OPERATING SOUND OF FUEL PUMP.</b> Make sure that fuel pump is in operation for two seconds when turning the ignition switch to ON.</p> <p>NOTE: Fuel pump operation can also be executed using Subaru Select Monitor. Refer to "Compulsory Valve Operation Check Mode" for procedures. &lt;Ref. to EN(H6DO)(diag)-41, Compulsory Valve Operation Check Mode.&gt;</p>	Does the fuel pump produce operating sound?	Check the fuel injector circuit. <Ref. to EN(H6DO)(diag)-64, FUEL INJECTOR CIRCUIT, Diagnostics for Engine Starting Failure.>	Display DTC. <Ref. to EN(H6DO)(diag)-32, OPERATION, Read Diagnostic Trouble Code (DTC).>



# Diagnostics for Engine Starting Failure


ENGINE (DIAGNOSTICS)

## F: FUEL INJECTOR CIRCUIT

### CAUTION:

- Check or repair only faulty parts.
- After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H6DO)(diag)-40, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H6DO)(diag)-33, PROCEDURE, Inspection Mode.>.

### WIRING DIAGRAM:



EN-02505

Step	Check	Yes	No	
1	<p><b>CHECK OPERATION OF EACH FUEL INJECTOR.</b></p> <p>While cranking the engine, check that each fuel injector emits operating sound. Use a sound scope or apply a screwdriver to the injector for this check.</p>	<p>Does the fuel injector emit operating sound?</p>	<p>Check the fuel pressure. &lt;Ref. to ME(H6DO)-27, INSPECTION, Fuel Pressure.&gt;</p>	<p>Go to step 2.</p>

# Diagnostics for Engine Starting Failure

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<p><b>2</b>      <b>CHECK POWER SUPPLY TO EACH FUEL INJECTOR.</b>                      1) Turn the ignition switch to OFF.                      2) Disconnect the connector from fuel injector.                      3) Turn the ignition switch to ON.                      4) Measure the power supply voltage between fuel injector terminal and engine ground.  <b>Connector &amp; terminal</b>  <b>#1 (E5) No. 2 (+) — Engine ground (-):</b>  <b>#2 (E16) No. 2 (+) — Engine ground (-):</b>  <b>#3 (E6) No. 2 (+) — Engine ground (-):</b>  <b>#4 (E17) No. 2 (+) — Engine ground (-):</b>  <b>#5 (E43) No. 2 (+) — Engine ground (-):</b>  <b>#6 (E44) No. 2 (+) — Engine ground (-):</b></p>	Is the voltage more than 10 V?	Go to step 3.	Repair the harness and connector. <b>NOTE:</b> In this case repair the following: • Open circuit in harness between main relay and fuel injector connector • Poor contact in main relay connector • Poor contact in coupling connector • Poor contact in fuel injector connector
<p><b>3</b>      <b>CHECK HARNESS BETWEEN ECM AND FUEL INJECTOR CONNECTOR.</b>                      1) Disconnect the connector from ECM.                      2) Measure the resistance of harness between ECM and fuel injector connector.  <b>Connector &amp; terminal</b>  <b>#1 (B136) No. 6 — (E5) No. 1:</b>  <b>#2 (B136) No. 5 — (E16) No. 1:</b>  <b>#3 (B136) No. 4 — (E6) No. 1:</b>  <b>#4 (B136) No. 3 — (E17) No. 1:</b>  <b>#5 (B136) No. 2 — (E43) No. 1:</b>  <b>#6 (B136) No. 1 — (E44) No. 1:</b></p>	Is the resistance less than 1 $\Omega$ ?	Go to step 4.	Repair the harness and connector. <b>NOTE:</b> In this case repair the following: • Open circuit in harness between ECM and fuel injector connector • Poor contact in coupling connector
<p><b>4</b>      <b>CHECK HARNESS BETWEEN ECM AND FUEL INJECTOR CONNECTOR.</b>                      Measure the resistance of harness between ECM and fuel injector connector.  <b>Connector &amp; terminal</b>  <b>#1 (B136) No. 6 — Chassis ground:</b>  <b>#2 (B136) No. 5 — Chassis ground:</b>  <b>#3 (B136) No. 4 — Chassis ground:</b>  <b>#4 (B136) No. 3 — Chassis ground:</b>  <b>#5 (B136) No. 2 — Chassis ground:</b>  <b>#6 (B136) No. 1 — Chassis ground:</b></p>	Is the resistance more than 1 M $\Omega$ ?	Go to step 5.	Repair the ground short circuit in harness between ECM and fuel injector connector.
<p><b>5</b>      <b>CHECK EACH FUEL INJECTOR.</b>                      1) Turn the ignition switch to OFF.                      2) Measure the resistance between each fuel injector terminals.  <b>Terminals</b>  <b>No. 1 — No. 2:</b></p>	Is the resistance 5 — 20 $\Omega$ ?	Go to step 6.	Replace the faulty fuel injector.
<p><b>6</b>      <b>CHECK POOR CONTACT.</b>                      Check poor contact in ECM connector.</p>	Is the poor contact in ECM connector?	Repair the poor contact in ECM connector.	Inspection using "General Diagnostics Table". <Ref. to EN(H6DO)(diag)-265, INSPECTION, General Diagnostic Table.>

## List of Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

### 17. List of Diagnostic Trouble Code (DTC)

#### A: LIST

DTC	Item	Reference
P0011	"A" Camshaft Position-Timing Over-Advanced or System Performance (Bank 1)	<Ref. to EN(H6DO)(diag)-72, DTC P0011 "A" CAMSHAFT POSITION - TIMING OVER-ADVANCED OR SYSTEM PERFORMANCE (BANK 1), Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0021	"A" Camshaft Position-Timing Over-Advanced or System Performance (Bank 2)	<Ref. to EN(H6DO)(diag)-73, DTC P0021 "A" CAMSHAFT POSITION - TIMING OVER-ADVANCED OR SYSTEM PERFORMANCE (BANK 2), Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0030	HO2S Heater Control Circuit (Bank 1 Sensor 1)	<Ref. to EN(H6DO)(diag)-74, DTC P0030 HO2S HEATER CONTROL CIRCUIT (BANK 1 SENSOR 1), Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0031	HO2S Heater Control Circuit Low (Bank 1 Sensor 1)	<Ref. to EN(H6DO)(diag)-76, DTC P0031 HO2S HEATER CONTROL CIRCUIT LOW (BANK 1 SENSOR 1), Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0032	HO2S Heater Control Circuit High (Bank 1 Sensor 1)	<Ref. to EN(H6DO)(diag)-79, DTC P0032 HO2S HEATER CONTROL CIRCUIT HIGH (BANK 1 SENSOR 1), Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0037	HO2S Heater Control Circuit Low (Bank 1 Sensor 2)	<Ref. to EN(H6DO)(diag)-81, DTC P0037 HO2S HEATER CONTROL CIRCUIT LOW (BANK 1 SENSOR 2), Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0038	HO2S Heater Control Circuit High (Bank 1 Sensor 2)	<Ref. to EN(H6DO)(diag)-84, DTC P0038 HO2S HEATER CONTROL CIRCUIT HIGH (BANK 1 SENSOR 2), Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0050	HO2S Heater Control Circuit (Bank 2 Sensor 1)	<Ref. to EN(H6DO)(diag)-86, DTC P0050 HO2S HEATER CONTROL CIRCUIT (BANK 2 SENSOR 1), Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0051	HO2S Heater Control Circuit Low (Bank 2 Sensor 1)	<Ref. to EN(H6DO)(diag)-88, DTC P0051 HO2S HEATER CONTROL CIRCUIT LOW (BANK 2 SENSOR 1), Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0052	HO2S Heater Control Circuit High (Bank 2 Sensor 1)	<Ref. to EN(H6DO)(diag)-91, DTC P0052 HO2S HEATER CONTROL CIRCUIT HIGH (BANK 2 SENSOR 1), Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0057	HO2S Heater Control Circuit Low (Bank 2 Sensor 2)	<Ref. to EN(H6DO)(diag)-93, DTC P0057 HO2S HEATER CONTROL CIRCUIT LOW (BANK 2 SENSOR 2), Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0058	HO2S Heater Control Circuit High (Bank 2 Sensor 2)	<Ref. to EN(H6DO)(diag)-96, DTC P0058 HO2S HEATER CONTROL CIRCUIT HIGH (BANK 2 SENSOR 2), Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0076	Intake Valve Control Solenoid Circuit Low (Bank 1)	<Ref. to EN(H6DO)(diag)-98, DTC P0076 INTAKE VALVE CONTROL SOLENOID CIRCUIT LOW (BANK 1), Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0077	Intake Valve Control Solenoid Circuit High (Bank 1)	<Ref. to EN(H6DO)(diag)-100, DTC P0077 INTAKE VALVE CONTROL SOLENOID CIRCUIT HIGH (BANK 1), Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0082	Intake Valve Control Solenoid Circuit Low (Bank 2)	<Ref. to EN(H6DO)(diag)-102, DTC P0082 INTAKE VALVE CONTROL SOLENOID CIRCUIT LOW (BANK 2), Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0083	Intake Valve Control Solenoid Circuit High (Bank 2)	<Ref. to EN(H6DO)(diag)-104, DTC P0083 INTAKE VALVE CONTROL SOLENOID CIRCUIT HIGH (BANK 2), Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0101	Mass or Volume Air Flow Circuit Range/Performance	<Ref. to EN(H6DO)(diag)-106, DTC P0101 MASS OR VOLUME AIR FLOW CIRCUIT RANGE/PERFORMANCE, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0102	Mass or Volume Air Flow Circuit Low Input	<Ref. to EN(H6DO)(diag)-108, DTC P0102 MASS OR VOLUME AIR FLOW CIRCUIT LOW INPUT, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>

# List of Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

DTC	Item	Reference
P0103	Mass or Volume Air Flow Circuit High Input	<Ref. to EN(H6DO)(diag)-111, DTC P0103 MASS OR VOLUME AIR FLOW CIRCUIT HIGH INPUT, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0107	Manifold Absolute Pressure/Barometric Pressure Circuit Low Input	<Ref. to EN(H6DO)(diag)-113, DTC P0107 MANIFOLD ABSOLUTE PRESSURE/BAROMETRIC PRESSURE CIRCUIT LOW INPUT, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0108	Manifold Absolute Pressure/Barometric Pressure Circuit High Input	<Ref. to EN(H6DO)(diag)-116, DTC P0108 MANIFOLD ABSOLUTE PRESSURE/BAROMETRIC PRESSURE CIRCUIT HIGH INPUT, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0112	Intake Air Temperature Circuit Low Input	<Ref. to EN(H6DO)(diag)-119, DTC P0112 INTAKE AIR TEMPERATURE CIRCUIT LOW INPUT, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0113	Intake Air Temperature Circuit High Input	<Ref. to EN(H6DO)(diag)-121, DTC P0113 INTAKE AIR TEMPERATURE CIRCUIT HIGH INPUT, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0117	Engine Coolant Temperature Circuit Low Input	<Ref. to EN(H6DO)(diag)-124, DTC P0117 ENGINE COOLANT TEMPERATURE CIRCUIT LOW INPUT, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0118	Engine Coolant Temperature Circuit High Input	<Ref. to EN(H6DO)(diag)-126, DTC P0118 ENGINE COOLANT TEMPERATURE CIRCUIT HIGH INPUT, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0122	Throttle/Pedal Position Sensor/Switch "A" Circuit Low Input	<Ref. to EN(H6DO)(diag)-129, DTC P0122 THROTTLE/PEDAL POSITION SENSOR/SWITCH "A" CIRCUIT LOW INPUT, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0123	Throttle/Pedal Position Sensor/Switch "A" Circuit High Input	<Ref. to EN(H6DO)(diag)-131, DTC P0123 THROTTLE/PEDAL POSITION SENSOR/SWITCH "A" CIRCUIT HIGH INPUT, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0125	Insufficient Coolant Temperature For Closed Loop Fuel Control	<Ref. to EN(H6DO)(diag)-133, DTC P0125 INSUFFICIENT COOLANT TEMPERATURE FOR CLOSED LOOP FUEL CONTROL, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0131	O2 Sensor Circuit Low Voltage (Bank 1 Sensor 1)	<Ref. to EN(H6DO)(diag)-134, DTC P0131 O2 SENSOR CIRCUIT LOW VOLTAGE (BANK 1 SENSOR 1), Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0132	O2 Sensor Circuit High Voltage (Bank 1 Sensor 1)	<Ref. to EN(H6DO)(diag)-136, DTC P0132 O2 SENSOR CIRCUIT HIGH VOLTAGE (BANK 1 SENSOR 1), Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0133	O2 Sensor Circuit Slow Response (Bank 1 Sensor 1)	<Ref. to EN(H6DO)(diag)-138, DTC P0133 O2 SENSOR CIRCUIT SLOW RESPONSE (BANK 1 SENSOR 1), Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0134	O2 Sensor Circuit No Activity Detected (Bank 1 Sensor 1)	<Ref. to EN(H6DO)(diag)-140, DTC P0134 O2 SENSOR CIRCUIT NO ACTIVITY DETECTED (BANK 1 SENSOR 1), Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0137	O2 Sensor Circuit Low Voltage (Bank 1 Sensor 2)	<Ref. to EN(H6DO)(diag)-143, DTC P0137 O2 SENSOR CIRCUIT LOW VOLTAGE (BANK 1 SENSOR 2), Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0138	O2 Sensor Circuit High Voltage (Bank 1 Sensor 2)	<Ref. to EN(H6DO)(diag)-146, DTC P0138 O2 SENSOR CIRCUIT HIGH VOLTAGE (BANK 1 SENSOR 2), Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0151	O2 Sensor Circuit Low Voltage (Bank 2 Sensor 1)	<Ref. to EN(H6DO)(diag)-149, DTC P0151 O2 SENSOR CIRCUIT LOW VOLTAGE (BANK 2 SENSOR 1), Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0152	O2 Sensor Circuit High Voltage (Bank 2 Sensor 1)	<Ref. to EN(H6DO)(diag)-151, DTC P0152 O2 SENSOR CIRCUIT HIGH VOLTAGE (BANK 2 SENSOR 1), Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0153	O2 Sensor Circuit Slow Response (Bank 2 Sensor 1)	<Ref. to EN(H6DO)(diag)-153, DTC P0153 O2 SENSOR CIRCUIT SLOW RESPONSE (BANK 2 SENSOR 1), Diagnostic Procedure with Diagnostic Trouble Code (DTC).>

## List of Diagnostic Trouble Code (DTC)

### ENGINE (DIAGNOSTICS)

DTC	Item	Reference
P0154	O2 Sensor Circuit No Activity Detected (Bank 2 Sensor 1)	<Ref. to EN(H6DO)(diag)-155, DTC P0154 O2 SENSOR CIRCUIT NO ACTIVITY DETECTED (BANK 2 SENSOR 1), Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0157	O2 Sensor Circuit Low Voltage (Bank 2 Sensor 2)	<Ref. to EN(H6DO)(diag)-158, DTC P0157 O2 SENSOR CIRCUIT LOW VOLTAGE (BANK 2 SENSOR 2), Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0158	O2 Sensor Circuit High Voltage (Bank 2 Sensor 2)	<Ref. to EN(H6DO)(diag)-161, DTC P0158 O2 SENSOR CIRCUIT HIGH VOLTAGE (BANK 2 SENSOR 2), Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0171	System Too Lean (Bank 1)	<Ref. to EN(H6DO)(diag)-163, DTC P0171 SYSTEM TOO LEAN (BANK 1), Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0172	System Too Rich (Bank 1)	<Ref. to EN(H6DO)(diag)-163, DTC P0172 SYSTEM TOO RICH (BANK 1), Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0174	System Too Lean (Bank 2)	<Ref. to EN(H6DO)(diag)-163, DTC P0174 SYSTEM TOO LEAN (BANK 2), Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0175	System Too Rich (Bank 2)	<Ref. to EN(H6DO)(diag)-164, DTC P0175 SYSTEM TOO RICH (BANK 2), Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0197	Engine Oil Temperature Sensor Circuit Low	<Ref. to EN(H6DO)(diag)-166, DTC P0197 ENGINE OIL TEMPERATURE SENSOR CIRCUIT LOW, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0198	Engine Oil Temperature Sensor Circuit High	<Ref. to EN(H6DO)(diag)-168, DTC P0198 ENGINE OIL TEMPERATURE SENSOR CIRCUIT HIGH, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0222	Throttle/Pedal Position Sensor/Switch "B" Circuit Low Input	<Ref. to EN(H6DO)(diag)-170, DTC P0222 THROTTLE/PEDAL POSITION SENSOR/SWITCH "B" CIRCUIT LOW INPUT, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0223	Throttle/Pedal Position Sensor/Switch "B" Circuit High Input	<Ref. to EN(H6DO)(diag)-172, DTC P0223 THROTTLE/PEDAL POSITION SENSOR/SWITCH "B" CIRCUIT HIGH INPUT, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0230	Fuel Pump Primary Circuit	<Ref. to EN(H6DO)(diag)-174, DTC P0230 FUEL PUMP PRIMARY CIRCUIT, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0301	Cylinder 1 Misfire Detected	<Ref. to EN(H6DO)(diag)-177, DTC P0301 CYLINDER 1 MISFIRE DETECTED, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0302	Cylinder 2 Misfire Detected	<Ref. to EN(H6DO)(diag)-177, DTC P0302 CYLINDER 2 MISFIRE DETECTED, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0303	Cylinder 3 Misfire Detected	<Ref. to EN(H6DO)(diag)-177, DTC P0303 CYLINDER 3 MISFIRE DETECTED, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0304	Cylinder 4 Misfire Detected	<Ref. to EN(H6DO)(diag)-177, DTC P0304 CYLINDER 4 MISFIRE DETECTED, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0305	Cylinder 5 Misfire Detected	<Ref. to EN(H6DO)(diag)-177, DTC P0305 CYLINDER 5 MISFIRE DETECTED, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0306	Cylinder 6 Misfire Detected	<Ref. to EN(H6DO)(diag)-178, DTC P0306 CYLINDER 6 MISFIRE DETECTED, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0327	Knock Sensor 1 Circuit Low Input (Bank 1 or Single Sensor)	<Ref. to EN(H6DO)(diag)-185, DTC P0327 KNOCK SENSOR 1 CIRCUIT LOW INPUT (BANK 1 OR SINGLE SENSOR), Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0328	Knock Sensor 1 Circuit High Input (Bank 1 or Single Sensor)	<Ref. to EN(H6DO)(diag)-187, DTC P0328 KNOCK SENSOR 1 CIRCUIT HIGH INPUT (BANK 1 OR SINGLE SENSOR), Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0332	Knock Sensor 2 Circuit Low Input (Bank 2)	<Ref. to EN(H6DO)(diag)-189, DTC P0332 KNOCK SENSOR 2 CIRCUIT LOW INPUT (BANK 2), Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0333	Knock Sensor 2 Circuit High Input (Bank 2)	<Ref. to EN(H6DO)(diag)-191, DTC P0333 KNOCK SENSOR 2 CIRCUIT HIGH INPUT (BANK 2), Diagnostic Procedure with Diagnostic Trouble Code (DTC).>

# List of Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

DTC	Item	Reference
P0335	Crankshaft Position Sensor "A" Circuit	<Ref. to EN(H6DO)(diag)-193, DTC P0335 CRANKSHAFT POSITION SENSOR "A" CIRCUIT, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0340	Camshaft Position Sensor "A" Circuit (Bank 1 or Single Sensor)	<Ref. to EN(H6DO)(diag)-195, DTC P0340 CAMSHAFT POSITION SENSOR "A" CIRCUIT (BANK 1 OR SINGLE SENSOR), Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0345	Camshaft Position Sensor "A" Circuit (Bank 2)	<Ref. to EN(H6DO)(diag)-197, DTC P0345 CAMSHAFT POSITION SENSOR "A" CIRCUIT (BANK 2), Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0400	Exhaust Gas Recirculation Flow	<Ref. to EN(H6DO)(diag)-199, DTC P0400 EXHAUST GAS RECIRCULATION FLOW, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0420	Catalyst System Efficiency Below Threshold (Bank 1)	<Ref. to EN(H6DO)(diag)-202, DTC P0420 CATALYST SYSTEM EFFICIENCY BELOW THRESHOLD (BANK 1), Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0458	Evaporative Emission Control System Purge Control Valve Circuit Low	<Ref. to EN(H6DO)(diag)-203, DTC P0458 EVAPORATIVE EMISSION CONTROL SYSTEM PURGE CONTROL VALVE CIRCUIT LOW, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0459	Evaporative Emission Control System Purge Control Valve Circuit High	<Ref. to EN(H6DO)(diag)-205, DTC P0459 EVAPORATIVE EMISSION CONTROL SYSTEM PURGE CONTROL VALVE CIRCUIT HIGH, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0462	Fuel Level Sensor Circuit Low Input	<Ref. to EN(H6DO)(diag)-207, DTC P0462 FUEL LEVEL SENSOR CIRCUIT LOW INPUT, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0463	Fuel Level Sensor Circuit High Input	<Ref. to EN(H6DO)(diag)-207, DTC P0463 FUEL LEVEL SENSOR CIRCUIT HIGH INPUT, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0500	Vehicle Speed Sensor	<Ref. to EN(H6DO)(diag)-207, DTC P0500 VEHICLE SPEED SENSOR, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0512	Starter Request Circuit	<Ref. to EN(H6DO)(diag)-208, DTC P0512 STARTER REQUEST CIRCUIT, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0519	Idle Control System Malfunction (Fail-Safe)	<Ref. to EN(H6DO)(diag)-211, DTC P0519 IDLE CONTROL SYSTEM MALFUNCTION (FAIL-SAFE), Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0558	Alternator Circuit Low	<Ref. to EN(H6DO)(diag)-211, DTC P0558 ALTERNATOR CIRCUIT LOW, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0559	Alternator Circuit High	<Ref. to EN(H6DO)(diag)-212, DTC P0559 ALTERNATOR CIRCUIT HIGH, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0600	Serial Communication Link	<Ref. to EN(H6DO)(diag)-213, DTC P0600 SERIAL COMMUNICATION LINK, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0604	Internal Control Module Random Access Memory (RAM) Error	<Ref. to EN(H6DO)(diag)-214, DTC P0604 INTERNAL CONTROL MODULE RANDOM ACCESS MEMORY (RAM) ERROR, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0605	Internal Control Module Read Only Memory (ROM) Error	<Ref. to EN(H6DO)(diag)-215, DTC P0605 INTERNAL CONTROL MODULE READ ONLY MEMORY (ROM) ERROR, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0607	Control Module Performance	<Ref. to EN(H6DO)(diag)-216, DTC P0607 CONTROL MODULE PERFORMANCE, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0638	Throttle Actuator Control Range/Performance (Bank 1)	<Ref. to EN(H6DO)(diag)-217, DTC P0638 THROTTLE ACTUATOR CONTROL RANGE/PERFORMANCE (BANK 1), Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0691	Cooling Fan 1 Control Circuit Low	<Ref. to EN(H6DO)(diag)-218, DTC P0691 COOLING FAN 1 CONTROL CIRCUIT LOW, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0692	Cooling Fan 1 Control Circuit High	<Ref. to EN(H6DO)(diag)-218, DTC P0692 COOLING FAN 1 CONTROL CIRCUIT HIGH, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>

## List of Diagnostic Trouble Code (DTC)

### ENGINE (DIAGNOSTICS)

DTC	Item	Reference
P0700	Transmission Control System (MIL Request)	<Ref. to EN(H6DO)(diag)-218, DTC P0700 TRANSMISSION CONTROL SYSTEM (MIL REQUEST), Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P1026	VVL System 1 Performance	<Ref. to EN(H6DO)(diag)-219, DTC P1026 VVL SYSTEM 1 PERFORMANCE, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P1028	VVL System 2 Performance	<Ref. to EN(H6DO)(diag)-221, DTC P1028 VVL SYSTEM 2 PERFORMANCE, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P1160	Return Spring Failure	<Ref. to EN(H6DO)(diag)-223, DTC P1160 RETURN SPRING FAILURE, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P1492	EGR Solenoid Valve Signal #1 Circuit Malfunction (Low Input)	<Ref. to EN(H6DO)(diag)-223, DTC P1492 EGR SOLENOID VALVE SIGNAL #1 CIRCUIT MALFUNCTION (LOW INPUT), Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P1493	EGR Solenoid Valve Signal #1 Circuit Malfunction (High Input)	<Ref. to EN(H6DO)(diag)-223, DTC P1493 EGR SOLENOID VALVE SIGNAL #1 CIRCUIT MALFUNCTION (HIGH INPUT), Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P1494	EGR Solenoid Valve Signal #2 Circuit Malfunction (Low Input)	<Ref. to EN(H6DO)(diag)-223, DTC P1494 EGR SOLENOID VALVE SIGNAL #2 CIRCUIT MALFUNCTION (LOW INPUT), Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P1495	EGR Solenoid Valve Signal #2 Circuit Malfunction (High Input)	<Ref. to EN(H6DO)(diag)-223, DTC P1495 EGR SOLENOID VALVE SIGNAL #2 CIRCUIT MALFUNCTION (HIGH INPUT), Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P1496	EGR Solenoid Valve Signal #3 Circuit Malfunction (Low Input)	<Ref. to EN(H6DO)(diag)-223, DTC P1496 EGR SOLENOID VALVE SIGNAL #3 CIRCUIT MALFUNCTION (LOW INPUT), Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P1497	EGR Solenoid Valve Signal #3 Circuit Malfunction (High Input)	<Ref. to EN(H6DO)(diag)-223, DTC P1497 EGR SOLENOID VALVE SIGNAL #3 CIRCUIT MALFUNCTION (HIGH INPUT), Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P1498	EGR Solenoid Valve Signal #4 Circuit Malfunction (Low Input)	<Ref. to EN(H6DO)(diag)-224, DTC P1498 EGR SOLENOID VALVE SIGNAL #4 CIRCUIT MALFUNCTION (LOW INPUT), Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P1499	EGR Solenoid Valve Signal #4 Circuit Malfunction (High Input)	<Ref. to EN(H6DO)(diag)-226, DTC P1499 EGR SOLENOID VALVE SIGNAL #4 CIRCUIT MALFUNCTION (HIGH INPUT), Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P1518	Starter Switch Circuit Low Input	<Ref. to EN(H6DO)(diag)-228, DTC P1518 STARTER SWITCH CIRCUIT LOW INPUT, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P1560	Back-Up Voltage Circuit Malfunction	<Ref. to EN(H6DO)(diag)-231, DTC P1560 BACK-UP VOLTAGE CIRCUIT MALFUNCTION, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P2088	OCV Solenoid Valve Signal A Circuit Open (Bank 1)	<Ref. to EN(H6DO)(diag)-233, DTC P2088 OCV SOLENOID VALVE SIGNAL A CIRCUIT OPEN (BANK 1), Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P2089	OCV Solenoid Valve Signal A Circuit Short (Bank 1)	<Ref. to EN(H6DO)(diag)-235, DTC P2089 OCV SOLENOID VALVE SIGNAL A CIRCUIT SHORT (BANK 1), Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P2092	OCV Solenoid Valve Signal A Circuit Open (Bank 2)	<Ref. to EN(H6DO)(diag)-237, DTC P2092 OCV SOLENOID VALVE SIGNAL A CIRCUIT OPEN (BANK 2), Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P2093	OCV Solenoid Valve Signal A Circuit Short (Bank 2)	<Ref. to EN(H6DO)(diag)-239, DTC P2093 OCV SOLENOID VALVE SIGNAL A CIRCUIT SHORT (BANK 2), Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P2101	Throttle Actuator Control Motor Circuit Range/Performance	<Ref. to EN(H6DO)(diag)-241, DTC P2101 THROTTLE ACTUATOR CONTROL MOTOR CIRCUIT RANGE/PERFORMANCE, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P2102	Throttle Actuator Control Motor Circuit Low	<Ref. to EN(H6DO)(diag)-246, DTC P2102 THROTTLE ACTUATOR CONTROL MOTOR CIRCUIT LOW, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>

# List of Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

DTC	Item	Reference
P2103	Throttle Actuator Control Motor Circuit High	<Ref. to EN(H6DO)(diag)-248, DTC P2103 THROTTLE ACTUATOR CONTROL MOTOR CIRCUIT HIGH, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P2109	Throttle Angle Sensor Closed Position Error	<Ref. to EN(H6DO)(diag)-249, DTC P2109 THROTTLE ANGLE SENSOR CLOSED POSITION ERROR, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P2122	Throttle/Pedal Position Sensor/Switch "D" Circuit Low Input	<Ref. to EN(H6DO)(diag)-250, DTC P2122 THROTTLE/PEDAL POSITION SENSOR/SWITCH "D" CIRCUIT LOW INPUT, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P2123	Throttle/Pedal Position Sensor/Switch "D" Circuit High Input	<Ref. to EN(H6DO)(diag)-252, DTC P2123 THROTTLE/PEDAL POSITION SENSOR/SWITCH "D" CIRCUIT HIGH INPUT, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P2127	Throttle/Pedal Position Sensor/Switch "E" Circuit Low Input	<Ref. to EN(H6DO)(diag)-254, DTC P2127 THROTTLE/PEDAL POSITION SENSOR/SWITCH "E" CIRCUIT LOW INPUT, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P2128	Throttle/Pedal Position Sensor/Switch "E" Circuit High Input	<Ref. to EN(H6DO)(diag)-256, DTC P2128 THROTTLE/PEDAL POSITION SENSOR/SWITCH "E" CIRCUIT HIGH INPUT, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P2135	Throttle/Pedal Position Sensor/Switch "A"/"B" Voltage Rationality	<Ref. to EN(H6DO)(diag)-258, DTC P2135 THROTTLE/PEDAL POSITION SENSOR/SWITCH "A" / "B" VOLTAGE RATIONALITY, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P2138	Throttle/Pedal Position Sensor/Switch "D"/"E" Voltage Rationality	<Ref. to EN(H6DO)(diag)-261, DTC P2138 THROTTLE/PEDAL POSITION SENSOR/SWITCH "D" / "E" VOLTAGE RATIONALITY, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>