

**ENGINE SECTION 1**

This service manual has been prepared to provide SUBARU service personnel with the necessary information and data for the correct maintenance and repair of SUBARU vehicles.

This manual includes the procedures for maintenance, disassembling, reassembling, inspection and adjustment of components and diagnostics for guidance of experienced mechanics.

Please peruse and utilize this manual fully to ensure complete repair work for satisfying our customers by keeping their vehicle in optimum condition. When replacement of parts during repair work is needed, be sure to use SUBARU genuine parts.

All information, illustration and specifications contained in this manual are based on the latest product information available at the time of publication approval.

<b>FUEL INJECTION (FUEL SYSTEMS)</b>	<b>FU(H4SO 2.0)</b>
<b>EMISSION CONTROL (AUX. EMISSION CONTROL DEVICES)</b>	<b>EC(H4SO 2.0)</b>
<b>INTAKE (INDUCTION)</b>	<b>IN(H4SO 2.0)</b>
<b>MECHANICAL</b>	<b>ME(H4SO 2.0)</b>
<b>EXHAUST</b>	<b>EX(H4SO 2.0)</b>
<b>COOLING</b>	<b>CO(H4SO 2.0)</b>
<b>LUBRICATION</b>	<b>LU(H4SO 2.0)</b>
<b>SPEED CONTROL SYSTEMS</b>	<b>SP(H4SO 2.0)</b>
<b>IGNITION</b>	<b>IG(H4SO 2.0)</b>
<b>STARTING/CHARGING SYSTEMS</b>	<b>SC(H4SO 2.0)</b>
<b>ENGINE (DIAGNOSTICS)</b>	<b>EN(H4SO 2.0) (diag)</b>
<b>FUEL INJECTION (FUEL SYSTEMS)</b>	<b>FU(H4SO 2.5)</b>
<b>EMISSION CONTROL (AUX. EMISSION CONTROL DEVICES)</b>	<b>EC(H4SO 2.5)</b>
<b>INTAKE (INDUCTION)</b>	<b>IN(H4SO 2.5)</b>
<b>MECHANICAL</b>	<b>ME(H4SO 2.5)</b>
<b>EXHAUST</b>	<b>EX(H4SO 2.5)</b>
<b>COOLING</b>	<b>CO(H4SO 2.5)</b>

ENGINE SECTION 1

LUBRICATION LU(H4SO 2.5)

SPEED CONTROL SYSTEMS SP(H4SO 2.5)

IGNITION IG(H4SO 2.5)

STARTING/CHARGING SYSTEMS SC(H4SO 2.5)

ENGINE (DIAGNOSTICS) EN(H4SO 2.5)  
(diag)

**EMISSION CONTROL  
(AUX. EMISSION CONTROL DEVICES)**

***EC(H4SO 2.5)***

---

	Page
1. General Description .....	2

## **General Description**

EMISSION CONTROL (AUX. EMISSION CONTROL DEVICES)

---

### **1. General Description**

#### **A: SPECIFICATION**

Specifications for 2.5 L model are included in EC(H4SO 2.0) section. <Ref. to EC(H4SO 2.0)-2, General Description.>